



DEEP SEA ELECTRONICS

DSE8660 MKII Configuration Suite

PC Software Manual

Document Number: 057-257

Author: Ashley Senior





Deep Sea Electronics Ltd.

Highfield House
Hunmanby
North Yorkshire
YO14 0PH
England

Sales Tel: +44 (0) 1723 890099

E-mail: sales@deepseaelectronics.com

Website: www.deepseaelectronics.com

DSE8660 MKII Configuration Suite PC Software Manual

© Deep Sea Electronics Ltd.

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Ltd. at the address above.

The DSE logo and the names DSEGenSet®, DSEATS®, DSEPower® and DSEControl® are UK registered trademarks of Deep Sea Electronics Ltd.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Ltd. reserves the right to change the contents of this document without prior notice.

Amendments Since Last Publication

Amd. No.	Comments
1	Initial Release
2	Updated to include features added in module firmware V2.0 and V3.0
3	Updated to include features added in modules Firmware V5
4	Updated to include features added in module firmware V5.1
5	Updated to module firmware V6.1, features include: Fault Ride Through, Advanced PLC Editor, Disable Auto MSC-ID Allocation, new Load Demand Scheme
6	Updated to module firmware V7, features include: Manual Bus Adjust, Load Demand Compatibility option, MSC PLC Data, and more...
7	Updated to include features added in module firmware V7.2
8	Updated to module firmware V7.7, features include: Commissioning Screens in the SCADA...

Typeface: The typeface used in this document is *Arial*. Care must be taken not to mistake the upper-case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

TABLE OF CONTENTS

Section	Page
1 INTRODUCTION.....	6
1.1 CLARIFICATION OF NOTATION.....	7
1.2 GLOSSARY OF TERMS.....	7
1.3 BIBLIOGRAPHY	8
1.3.1 INSTALLATION INSTRUCTIONS.....	8
1.3.2 MANUALS	8
1.3.3 TRAINING GUIDES	9
1.3.4 THIRD PARTY DOCUMENTS	10
1.4 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE	10
2 EDITING THE CONFIGURATION	11
2.1 SCREEN LAYOUT	11
2.2 MODULE	12
2.2.1 MODULE OPTIONS.....	12
2.2.2 CONFIGURABLE STATUS SCREENS	17
2.2.3 EVENT LOG.....	19
2.2.4 DATA LOGGING	21
2.2.4.1 CONFIGURATION	22
2.2.4.2 OPTIONS	23
2.3 DIGITAL INPUTS	24
2.3.1 DIGITAL INPUTS	24
2.3.2 INPUT FUNCTIONS.....	26
2.4 OUTPUTS.....	31
2.4.1 DIGITAL OUTPUTS	31
2.4.2 VIRTUAL LEDS	32
2.4.3 OUTPUT SOURCES.....	33
2.5 TIMERS	41
2.5.1 START TIMERS	41
2.5.2 LOAD / STOPPING TIMERS	42
2.5.3 MODULE TIMERS	42
2.6 MAINS	43
2.6.1 MAINS OPTIONS.....	44
2.6.2 MAINS VOLTAGE ALARMS	46
2.6.3 MAINS SEQUENCE ALARMS.....	47
2.6.4 MAINS FREQUENCY ALARMS.....	49
2.6.5 CURRENT	50
2.6.6 MAINS DECOUPLING	52
2.6.6.1 LOSS OF MAINS	53
2.6.6.2 VOLTAGE ALARMS	54
2.6.6.3 FREQUENCY.....	56
2.6.7 FAULT RIDE THROUGH	58
2.7 BUS.....	61
2.7.1 BUS OPTIONS	62
2.7.2 BUS NOMINALS	64
2.7.3 BUS SEQUENCE ALARMS	65
2.7.4 CHECK SYNC	67
2.7.5 MULTISSET	69
2.7.6 LOAD CONTROL	74
2.7.7 POWER CONTROL	76
2.7.7.1 CREATING / EDITING THE POWER MODE CURVE	79
2.7.8 VOLTAGE AND REACTIVE POWER CONTROL	80
2.8 SYSTEM.....	83
2.8.1 SYSTEM OPTIONS	83
2.8.2 PLANT BATTERY	86
2.9 COMMUNICATIONS.....	87
2.9.1 COMMUNICATIONS OPTIONS.....	87

2.9.2	RS232 PORT.....	88
2.9.2.1	BASIC.....	89
2.9.2.2	ADVANCED.....	92
2.9.2.3	SMS CONTROL.....	94
2.9.2.4	TROUBLESHOOTING MODEM COMMUNICATIONS.....	95
2.9.2.4.1	MODEM COMMUNICATION SPEED SETTING.....	95
2.9.2.4.2	GSM MODEM CONNECTION.....	95
2.9.3	RS485 PORTS.....	96
2.9.4	ETHERNET.....	97
2.9.4.1	FIREWALL CONFIGURATION FOR INTERNET ACCESS.....	99
2.9.4.2	INCOMING TRAFFIC (VIRTUAL SERVER).....	99
2.9.5	NOTIFICATIONS.....	100
2.9.5.1	SNMP.....	100
2.9.5.2	NOTIFICATIONS.....	101
2.10	SCHEDULER.....	102
2.10.1	SCHEDULER OPTIONS.....	102
2.10.2	BANK 1 / BANK 2.....	103
2.11	EXPANSION.....	104
2.11.1	DSE2130 INPUT MODULES.....	105
2.11.1.1	ANALOGUE INPUT CONFIGURATION.....	106
2.11.1.2	ANALOGUE INPUTS.....	106
2.11.1.2.1	CREATING / EDITING THE SENSOR CURVE.....	108
2.11.1.3	DIGITAL INPUTS.....	110
2.11.1.3.1	DIGITAL INPUTS.....	111
2.11.1.3.2	ANALOGUE INPUTS.....	112
2.11.2	DSE2131 INPUT MODULES.....	113
2.11.2.1	ANALOGUE INPUT CONFIGURATION.....	114
2.11.2.2	ANALOGUE INPUTS.....	115
2.11.2.3	DIGITAL INPUTS.....	117
2.11.3	DSE2133 INPUT MODULES.....	119
2.11.3.1	ANALOGUE INPUTS.....	120
2.11.4	DSE2152 OUTPUT MODULES.....	122
2.11.4.1	ANALOGUE OUTPUTS.....	123
2.11.4.2	CREATING / EDITING THE OUTPUT CURVE.....	124
2.11.5	DSE2157 RELAY MODULES.....	126
2.11.6	DSE2548 ANNUCIATOR MODULES.....	127
2.11.7	BATTERY CHARGERS.....	129
2.12	ADVANCED.....	131
2.12.1	ADVANCED OPTIONS.....	132
2.12.2	PLC.....	135
2.12.3	CONFIGURABLE GENCOMM PAGES 166 TO 169.....	136
2.12.4	CONFIGURABLE EDITOR SCREENS.....	138
3	SCADA.....	139
3.1	MAINS IDENTITY.....	140
3.2	MIMIC.....	140
3.3	DIGITAL INPUTS.....	141
3.4	DIGITAL OUTPUTS.....	142
3.5	VIRTUAL LEDS.....	143
3.6	BUS.....	144
3.6.1	FREQUENCY AND VOLTAGES.....	144
3.6.2	LOAD.....	145
3.6.3	MSC LINK.....	146
3.6.4	SYNC.....	147
3.6.5	LOAD LEVELS.....	149
3.7	MAINS.....	152
3.7.1	FREQUENCY AND VOLTAGES.....	152
3.7.2	POWER.....	153
3.8	ALARMS.....	154
3.9	STATUS.....	155

3.10	EVENT LOG	156
3.11	REMOTE CONTROL	157
3.12	MAINTENANCE.....	158
3.12.1	EXPANSION CALIBRATION	159
3.12.2	TIME	160
3.12.3	ACCUMULATED INSTRUMENTATION	161
3.12.4	MODULE PIN	162
3.13	COMMUNICATIONS INFORMATION.....	163
3.14	DATA LOG	164
3.15	PLC	165
3.15.1	PLC LOGIC	165
3.15.2	PLC STORES.....	166
3.16	EXPANSION	167
4	ALARM TYPES.....	168
5	ALARM ARMING	169
5.1	NEVER	169
5.2	ALWAYS	169
5.3	ACTIVE FROM MAINS PARALLEL	169

1 INTRODUCTION

This document details the use of the *DSE Configuration Suite PC Software* with the DSE8660 MKII module, which is part of the DSE Genset® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. DSE do not automatically inform on updates. Any future updates of this document are included on the DSE website at www.deepseaelectronics.com




The *DSE Configuration Suite PC Software* allows the DSE8660 MKII module to be connected to a PC via USB A to USB B cable (USB printer cable). Once connected, the software allows easy, controlled access to various operating parameters within the module which can then be viewed and edited as required.

The *DSE Configuration Suite PC Software* must only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the panel to which it is fitted. Access to critical operational sequences and settings for use by qualified engineers, may be barred by a security code set by the Generator / panel provider.

The information contained in this manual must be read in conjunction with the information contained in the appropriate module documentation. This manual only detail which settings are available and how they may be used. Separate manuals deal with the operation of the individual module and its ancillaries, refer to section entitled *Bibliography* elsewhere in this document for further information.

1.1 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

 NOTE:	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

1.2 GLOSSARY OF TERMS

Term	Description
DSE8000 MKII, DSE8xxx MKII	All modules in the DSE8xxx MKII range.
DSE8600 MKII, DSE86xx MKII	All modules in the DSE86xx MKII range.
DSE8660 MKII	DSE8660 MKII module/controller
DSE8x10	DSE8610, DSE8610 MKII, DSE8710 and DSE8810 module/controller
DSE8x60	DSE8660, DSE8660 MKII, DSE8760 and DSE8860 module/controller
DSE8x80	DSE8680 module/controller
CAN	Controller Area Network Vehicle standard to allow digital devices to communicate to one another.
CDMA	Code Division Multiple Access. Cell phone access used in small number of areas including parts of the USA and Australia.
CT	Current Transformer An electrical device that takes a large AC current and scales it down by a fixed ratio to a smaller current.
BMS	Building Management System A digital/computer-based control system for a building's infrastructure.
GSM	Global System for Mobile communications. Cell phone technology used in most of the World.
HMI	Human Machine Interface A device that provides a control and visualisation interface between a human and a process or machine.
IDMT	Inverse Definite Minimum Time
IEEE	Institute of Electrical and Electronics Engineers
LED	Light Emitting Diode
MSC	Multi-Set Communication
PLC	Programmable Logic Controller A programmable digital device used to create logic for a specific purpose.
R.O.C.O.F.	Rate Of Change Of Frequency
SCADA	Supervisory Control And Data Acquisition A system that operates with coded signals over communication channels to provide control and monitoring of remote equipment
SIM	Subscriber Identity Module. The small card supplied by the GSM/CDMA provider that is inserted into the cell phone, GSM modem or DSEGateway device to give GSM/GPRS connection.
SMS	Short Message Service The text messaging service of mobile/cell phones.
SNMP	Simple Network Management Protocol An international standard protocol for managing devices on IP networks.

1.3 BIBLIOGRAPHY

This document refers to, and is referred by the following DSE publications which are obtained from the DSE website: www.deepseaelectronics.com or by contacting DSE technical support: support@deepseaelectronics.com.

1.3.1 INSTALLATION INSTRUCTIONS

Installation instructions are supplied with the product in the box and are intended as a 'quick start' guide only.

DSE Part	Description
053-032	DSE2548 LED Expansion Annunciator Installation Instructions
053-033	DSE2130 Input Expansion Installation Instructions
053-034	DSE2157 Output Expansion Installation Instructions
053-049	DSE9xxx Battery Charger Installation Instructions
053-082	DSE8680 Installation Instructions
053-125	DSE2131 Ratio-metric Input Expansion Installation Instructions
053-126	DSE2133 RTD/Thermocouple Input Expansion Installation Instructions
053-134	DSE2152 Ratio-metric Output Expansion Installation Instructions
053-147	DSE9460 & DSE9461 Battery Charger Installation Instructions
053-182	DSE8610 MKII Installation Instructions
053-184	DSE8660 MKII Installation Instructions
053-185	DSE9473 & DSE9483 Battery Charger Installation Instructions
053-248	DSE8920 Installation Instructions

1.3.2 MANUALS

Product manuals are obtained from the DSE website: www.deepseaelectronics.com or by contacting DSE technical support: support@deepseaelectronics.com.

DSE Part	Description
N/A	DSEGencomm (MODBUS protocol for DSE controllers)
057-045	Guide to Synchronising and Load Sharing Part 1 (Usage of DSE Load Share Controllers in synchronisation / load sharing systems.)
057-046	Guide to Synchronising and Load Sharing Part 2 (Governor & AVR Interfacing)
057-047	Load Share System Design and Commissioning Guide
057-082	DSE2130 Input Expansion Operator Manual
057-083	DSE2157 Output Expansion Operator Manual
057-084	DSE2548 Annunciator Expansion Operator Manual
057-085	DSE9xxx Battery Charger Operator Manual
057-130	DSE8680 Operator Manual
057-131	DSE8680 Configuration Suite PC Software Manual
057-139	DSE2131 Ratio-metric Input Expansion Manual
057-140	DSE2133 RTD/Thermocouple Expansion Manual
057-141	DSE2152 Ratio-metric Output Expansion Manual
057-151	DSE Configuration Suite PC Software Installation & Operation Manual
057-175	PLC Programming Guide for DSE Controllers
057-176	DSE9460 & DSE9461 Battery Charger Operator Manual
057-238	DSE8610 MKII Configuration Suite PC Software Manual
057-257	DSE8660 MKII Configuration Suite PC Software Manual
057-259	DSE8660 MKII Operator Manual
057-305	DSSE8910 Configuration Suite PC Software Manual
057-310	DSSE8910 Operators Manual
057-312	DSEAssistant PC Software Manual
057-314	Advanced PLC Software Manual

1.3.3 TRAINING GUIDES

Training guides are provided as 'hand-out' sheets on specific subjects during training sessions and contain specific information regarding to that subject.

DSE Part	Description
056-001	Four Steps To Synchronising
056-005	Using CTs With DSE Products
056-006	Introduction to Comms
056-011	MSC Link
056-013	Load Demand Scheme
056-021	Mains Decoupling
056-022	Switchgear Control
056-024	GSM Modem
056-026	kVA, kW, kvar and Power Factor
056-030	Module PIN Codes
056-033	Synchronising Requirements
056-036	Expansion Modules
056-043	Sync Process
056-045	PLC as Load Demand Controller
056-047	Out of Sync and Failed To Close
056-051	Sending DSEGencomm Control Keys
056-053	Recommended Modems
056-069	Firmware Update
056-075	Adding Language Files
056-076	Reading DSEGencomm Alarms
056-079	Reading DSEGencomm Status
056-080	MODBUS
056-081	Screen Heaters
056-082	Override Gencomm PLC Example
056-084	Synchronising & Loadsharing
056-086	G59
056-089	DSE86xx MKI to DSE86xx MKII Conversion
056-091	Equipotential Earth Bonding
056-092	Best Practices for Wiring Restive Sensors
056-094	MSC Compatibility
056-095	Remote Start Input Functions
056-097	USB Earth Loops and Isolation
056-099	Digital Output to Digital Input Connection

1.3.4 THIRD PARTY DOCUMENTS

The following third-party documents are also referred to:

Reference	Description
ISBN 1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Institute of Electrical and Electronics Engineers Inc
ISBN 0-7506-1147-2	Diesel Generator handbook. L.L.J. Mahon
ISBN 0-9625949-3-8	On-Site Power Generation. EGSA Education Committee.



1.4 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE

For information in regards to installing and using the *DSE Configuration Suite PC Software*, refer to DSE publication: **057-151 DSE Configuration Suite PC Software Installation & Operation Manual** which is found on the DSE website: www.deepseaelectronics.com

2 EDITING THE CONFIGURATION


The software is broken down into separate sections to provide simple navigation whilst editing the module's configuration to suit a particular application.

2.1 SCREEN LAYOUT




2.2 MODULE

The *Module* section allows the user to edit options related to the module itself and is subdivided into smaller sections.




2.2.1 MODULE OPTIONS

Description




Parameter	Description
Description	Four free entry boxes to allow the user to give the configuration file a description. Typically used to enter the job number, customer name, site information etc. This text is not shown on the module's display and is only seen in the configuration file.

LED Indicators




Parameter	Description
Function	Allows the user to assign an output source to an LED indicator which are to the right of the module's LCD. For details of possible selections, see section entitled <i>Output Sources</i> elsewhere in this document.
Polarity	Lit: When the output source is true, the LCD indicator activates. Unlit: When the output source is true, the LCD indicator de-activates.
Insert Card Text	Enter custom text to print on the text insert for the LEDs.
Text Insert	Allows the user to print the custom text insert cards for the LEDs.
Logo Insert	Allow the user to choose and print an image for the logo insert above the LCD.


Rear Mount Option






Option	Description
Enable Auto Voltage Sensing	<p>NOTE: For further details on supported displays when the DSE module is mounted into the rear of the panel, contact DSE Technical Support support@deepseaelectronics.com.</p> <p><input type="checkbox"/> = The module's display, fascia buttons and LEDs are enabled and is to be mounted on the fascia of the panel.</p> <p><input checked="" type="checkbox"/> = The <i>Rear Mount Option</i> is enabled. The module's display, fascia buttons and LEDs are disabled to allow the module to be mount in the rear of a panel using the <i>DSE Rear Mount Panel Bracket</i>, Part Number 020-1044. A remote display is required to provide local monitoring and control of the system.</p>

Miscellaneous Options





Parameter	Description
Enable Running On Load Demand <i>IEEE 37.2 - 44 Unit sequence starting</i>	<p><input type="checkbox"/> = The <i>Running on Load Demand</i> is disabled. When remote start request is sent down the MSC link, all the generators run regardless of the amount of load.</p> <p><input checked="" type="checkbox"/> = The <i>Running on Load Demand</i> is enabled. When remote start request is sent down the MSC link, only the generators required to support the load run.</p>
All Warnings Are Latched	<p><input type="checkbox"/> = The <i>All Warnings Are Latched</i> is disabled. The module automatically resets the warning and pre-alarms once the triggering condition has been cleared.</p> <p><input checked="" type="checkbox"/> = The <i>All Warnings Are Latched</i> is enabled. The module does not automatically reset the warning and pre-alarms. Resetting the alarm is performed by either activating a digital input configured for <i>Alarm Reset</i> or, pressing the Stop/Reset Mode  button once the triggering condition has been cleared.</p>
Enable Immediate Mains Dropout	<p><input type="checkbox"/> = The <i>Immediate Mains Dropout</i> is disabled. Upon Mains failure, the Mains switchgear is kept closed until the Generator Bus is up to speed and volts.</p> <p><input checked="" type="checkbox"/> = The <i>Immediate Mains Dropout</i> is enabled. Upon Mains failure, the Mains switchgear is opened immediately, subject to the setting of the <i>Mains Transient</i> timer.</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Inhibit Retransfer to Mains IEEE 37.2 - 3 Checking or interlocking relay	<p><input type="checkbox"/> = The <i>Inhibit Retransfer to Mains</i> is disabled. When the Generator Bus is running on load and fails, the load is transferred back to the mains.</p> <p><input checked="" type="checkbox"/> = The <i>Inhibit Retransfer to Mains</i> is enabled. The load is prevented from being transferred back to the Mains supply, only in the event of the Generator Bus failure. This is used in peak lopping systems where the cost of using the Mains to supply the load is so prohibitive that the customer does not want to transfer back to the Mains supply.</p>
Enable Forced Peak Lop Inhibit	<p>NOTE: This option only has effect in <i>Manual Mode</i>. If the module is <i>Peak Lopping in Auto Mode</i> and another DSExx60 requests to control the Generator Bus following a Mains failure, the <i>Peak Lopping</i> operation is suspended.</p> <p><input type="checkbox"/> = The <i>Forced Peak Lop Inhibit</i> is disabled. The module continues to control the Generator Bus regardless if another DSExx60 requests control.</p> <p><input checked="" type="checkbox"/> = The <i>Forced Peak Lop Inhibit</i> is enabled. If the DSExx60 (1) is in <i>Manual Mode</i> controlling the Generator Bus for peak lopping and another DSExx60 (2) requests the generators to power its load following a Mains failure, the DSExx60 MKII (1) relinquishes control over the Generator Bus to the other DSExx60 MKII (2).</p>
Support Right-To-Left Languages in Module Strings	<p><input type="checkbox"/> = The <i>Support Right-To-Left Languages in Module Strings</i> is disabled. The module displays user configured strings in the order left to right.</p> <p><input checked="" type="checkbox"/> = The <i>Support Right-To-Left Languages in Module Strings</i> is enabled. The module displays user configured strings in the order right to left.</p>
Enable Bus Failure Detection When in Parallel	<p><input type="checkbox"/> = The <i>Bus Failure Detection When in Parallel</i> is disabled. The module does not act upon the Bus being live when in parallel with the Mains with no generators on load.</p> <p><input checked="" type="checkbox"/> = The <i>Bus Failure Detection When in Parallel</i> is enabled. The module monitors the MSC link when the Mains and Bus switchgear is closed. This is to check that the generators are closed making the Bus live, and not a case of the Bus being made live from the mains.</p>
Power Up in Mode	<p>Select the mode which the module enters once DC power is applied.</p> <p>Auto: The module powers up in the <i>Auto Mode</i> .</p> <p>Manual: The module powers up in the <i>Manual Mode</i> .</p> <p>Stop: The module powers up in the <i>Stop/Reset Mode</i> .</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Filter Mains Voltage Display	<p> NOTE: The Mains voltage is only filtered on the module's display and not on the SCADA or any other remote monitoring device.</p> <p><input type="checkbox"/> = The <i>Filter Mains Voltage Display</i> is disabled. The rate at which the Mains voltage instruments are refreshed is fast in order to display all voltage fluctuations.</p> <p><input checked="" type="checkbox"/> = The <i>Filter Mains Voltage Display</i> is enabled. The rate at which the Mains voltage instruments are refreshed is configurable based on the <i>Filter Constant</i>. A larger <i>Filter Constant</i> leads to a slower refresh rate, filtering out the fluctuations on the Mains voltage instruments.</p>
Filter Bus Voltage Display	<p> NOTE: The Bus voltage is only filtered on the module's display and not on the SCADA or any other remote monitoring device.</p> <p><input type="checkbox"/> = The <i>Filter Bus Voltage Display</i> is disabled. The rate at which the Bus voltage instruments are refreshed is fast in order to display all voltage fluctuations.</p> <p><input checked="" type="checkbox"/> = The <i>Filter Bus Voltage Display</i> is enabled. The rate at which the Bus voltage instruments are refreshed is configurable based on the <i>Filter Constant</i>. A larger <i>Filter Constant</i> leads to a slower refresh rate, filtering out the fluctuations on the Bus voltage instruments.</p>
Inhibit Remote Start of 8610	<p>Inhibits the module sending any start commands (including Mains failure) being transmitted down the MSC link to the DSExx10 units. This enables the user to decide when to start / stop the generators based on other conditions.</p> <p>Never: Start commands are always sent down the MSC link.</p> <p>Always: Start commands are never sent down the MSC link.</p> <p>On Input: Start commands are not sent down the MSC link when a digital input configured for <i>Inhibit Remote Start of 8610</i> is active.</p>








Breaker Control

Breaker Control

Enable Alternative Breaker Button Control


Enable Manual Breaker Control

Active Always ▾

Parameter	Description
Enable Alternative Breaker Button Control	<p>▲ NOTE: For more detailed information on the <i>Alternative Breaker Control Button</i> operation, refer to DSE Publication: 057-259 DSE8660 MKII Operator Manual.</p> <p><input type="checkbox"/> = The <i>Alternative Breaker Control Button</i> is disabled. Pressing the Transfer to Mains  or Transfer to Bus  buttons requests a transfer of load to the respective supply, if it is available.</p> <p><input checked="" type="checkbox"/> = The <i>Alternative Breaker Control Button</i> is enabled. Pressing the Transfer to Mains  or Transfer to Bus  buttons requests the respective switchgear to open or close, causing a transfer of load to occur if required, if the supply is available.</p>
Enable Manual Breaker Control	<p><input type="checkbox"/> = The <i>Manual Breaker Control</i> is disabled. When the module is in the Manual Mode , activation of any automatic on load request (such as <i>Remote Start on Load</i> or <i>Mains Failure</i>) causes the Bus switchgear to close.</p> <p><input checked="" type="checkbox"/> = The <i>Manual Breaker Control</i> is enabled. When the module is in the Manual Mode , only the following load requests cause the Bus switchgear to close:</p> <ul style="list-style-type: none"> • Pressing the Transfer to Bus  button. • Activating a digital input configured for <i>Transfer to Bus / Open Mains</i> <p>The <i>Manual Breaker Control</i> is activated: Always: <i>Manual Breaker Control</i> is always active. On Input: <i>Manual Breaker Control</i> is only active when a digital input configured for <i>Manual Breaker Mode</i> is active.</p>

2.2.2 CONFIGURABLE STATUS SCREENS

Home Page



Parameter	Description
Home Page	<p style="text-align: center;"> </p> <p>Mode: When no Navigation buttons are pressed for the duration of the <i>Page Timer</i>, the module's display reverts back to show the <i>Control Mode Page</i>. The <i>Configurable Status Screens</i> are not displayed automatically but is still</p> <p style="text-align: center;"> </p> <p>accessible by manually pressing the Navigation buttons.</p> <p>Instrumentation: When no Navigation buttons are pressed for the duration of the <i>Page Timer</i>, the module's display scrolls through the <i>Configurable Status Screens</i>. Each of the <i>Configurable Status Screens</i> remains on the display for the duration of the <i>Scroll Timer</i>. The <i>Control Mode</i> page is not displayed</p> <p style="text-align: center;"> </p> <p>automatically but is still accessible by manually pressing the Navigation buttons.</p>

Displayed Pages

Displayed Pages			
Page 1	Summary Screen	Page 6	Not Used
Page 2	Not Used	Page 7	Not Used
Page 3	Not Used	Page 8	Not Used
Page 4	Not Used	Page 9	Not Used
Page 5	Not Used	Page 10	Not Used

Parameter	Description
Page 1 to 10	Select the instrumentation parameter that is to be displayed for the specific <i>Configurable Status Screen</i> .

Example

In the example below, the *Home Page* is configured to *Instrumentation* so will scroll through the *Configurable Status Screens*. Depending on the application, the system designer selects the instrumentation parameters that are most important to constantly show on the module.

Home Page			
Home Page		Instrumentation	
Displayed Pages			
Page 1	Mains Total kW	Page 6	Not Used
Page 2	Bus Total kW	Page 7	Not Used
Page 3	Not Used	Page 8	Not Used
Page 4	Not Used	Page 9	Not Used
Page 5	Not Used	Page 10	Not Used

2.2.3 EVENT LOG

Logging Options

NOTE: Sending events by SMS is only available when the module is configured to communicate to a supported modem by RS232. Refer to section entitled *RS232 Port* elsewhere in this document for further details.

Parameter	Description
Power-Up	<input type="checkbox"/> = <i>Power-Up</i> events are not logged. <input checked="" type="checkbox"/> = <i>Power-Up</i> events are logged when the DC Supply is applied to the module.
Mains Fail	<input type="checkbox"/> = <i>Mains Fail</i> events are not logged. <input checked="" type="checkbox"/> = <i>Mains Fail</i> events are logged when the Mains voltage/frequency rise above/falls below the configured trip levels for the duration of the <i>Mains Transient Delay</i> timer.
Mains Return	<input type="checkbox"/> = <i>Mains Return</i> events are not logged. <input checked="" type="checkbox"/> = <i>Mains Return</i> events are logged when the Mains voltage/frequency falls below/rise above the configured return levels for the duration of the <i>Mains Transient Delay</i> timer.
Bus Off Load	<input type="checkbox"/> = <i>Bus Off Load</i> events are not logged. <input checked="" type="checkbox"/> = <i>Bus Off Load</i> events are logged when the Generator Bus switchgear opens.
Bus On Load	<input type="checkbox"/> = <i>Bus On Load</i> events are not logged. <input checked="" type="checkbox"/> = <i>Bus On Load</i> events are logged when the Generator Bus switchgear closes.
Incorrect Password Entered	<input type="checkbox"/> = <i>Incorrect Password Entered</i> events are not logged. <input checked="" type="checkbox"/> = <i>Incorrect Password Entered</i> events are logged when the four digit PIN password is entered incorrectly via the <i>Front Panel Editor Configurator</i> , or PC configuration read/write.
Electrical Trip Alarms	<input type="checkbox"/> = <i>Electrical Trip Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Electrical Trip Alarms</i> are logged when the moment they activate.
Electrical Trip Alarms Repeat SMS	<input type="checkbox"/> = <i>Electrical Trip Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Electrical Trip Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.


Parameter descriptions are continued overleaf...

Editing the Configuration

Parameter	Description
Latched Warnings	<input type="checkbox"/> = <i>Latched Warnings Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Latched Warnings Alarms</i> are logged when the moment they activate.
Unlatched Warnings	<input type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are logged when the moment they activate.
Unlatched Warnings Alarms Repeat SMS	<input type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.

2.2.4 DATA LOGGING

The *Data Logging* section is subdivided into smaller sections.



The module has the ability to record up to twenty parameters and is saved as a *Data Log File* to the module's internal memory or an external USB storage device. If 20 parameters were configured to be logged, each with a *Log Interval* of 1 second, the length of each *Data Log File* would be 6 hours and 21 minutes. This time is extendable as the length of each *Data Log File* varies upon the number of selected parameters and their configured *Log Interval*.

The module has the ability to store only one *Data Log File* to its internal memory. The number of *Data Log Files* increases when an external USB storage device is connected to the module's USB Host port. The increased number of *Data Log Files* is dependent upon the size of the USB storage device connected. When using the maximum size USB storage device of 16 GB, the number of *Data Log Files* is increased to 8200. This results in a total *Data Log* length of 46 weeks, 2 days, 6 hours and 24 minutes (assuming 20 parameters were configured to be logged, each with a *Log Interval* of 1 second).

The *Data Logging* is viewed using the *Data Log Viewer* application, which is accessed from the DSE Configuration Suite PC Software under the *Tools* menu.


2.2.4.1 CONFIGURATION

Data Logging

	Logged data	Log Interval
1	DC Power On	1 minute
2	Mains Total Power	1 second
3	Mains Current L1	1 second
4	Mains Volts (L1-N)	1 second
5	<Not Used>	1 second
6	<Not Used>	1 second
7	<Not Used>	1 second
8	<Not Used>	1 second
9	<Not Used>	1 second
10	<Not Used>	1 second
11	<Not Used>	1 second
12	<Not Used>	1 second
13	<Not Used>	1 second
14	<Not Used>	1 second
15	<Not Used>	1 second
16	<Not Used>	1 second
17	<Not Used>	1 second
18	<Not Used>	1 second
19	<Not Used>	1 second
20	<Not Used>	1 second

Parameter	Description
Logged Data	Select the instrument required to be logged
Log Interval	Select the logging interval of the data


2.2.4.2 OPTIONS




Parameter	Description
Only Log When Start is Requested	<input type="checkbox"/> = The module logs data regardless if the Generator Bus has been requested to run. <input checked="" type="checkbox"/> = The module only logs data when the Generator Bus has been requested to run.
Log to USB Drive	<input type="checkbox"/> = The module logs data to the modules internal memory. <input checked="" type="checkbox"/> = The module logs data to an external USB memory device connect to the USB host socket on the module.
Keep Oldest Data	<input type="checkbox"/> = When the logging memory is full, the module overwrites the oldest data first with the new data. <input checked="" type="checkbox"/> = When the logging memory is full, the module stops recording new data.

2.3 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.




2.3.1 DIGITAL INPUTS



Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: Electrical Trip Indication Warning</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Arming	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> <p>Select when the input becomes active: <i>Active From Mains Parallel</i> <i>Always</i> <i>Never</i></p>
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.


2.3.2 INPUT FUNCTIONS

Where a digital input is NOT configured as “user configured”, a selection is made from a list of predefined functions. The selections are as follows:



Under the scope of IEEE 37.2, function numbers are also used to represent functions in microprocessor devices and software programs. Where the DSE input functions are represented by IEEE 37.2, the function number is listed below.

Function	Description
Alarm Mute	This input is used to silence the audible alarm from an external source, such as a remote mute switch.
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the Generator Bus.
Alternative Language Select	This input is used to instruct the module to display the alternative Language instead of the default module display language.
Auto Restore Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	In the event of a remote start/Mains failure, the Generator Bus is instructed to start and take load. On removal of the remote start signal/Mains return the module continues to run the Generator Bus on load until the <i>Auto Restore Inhibit</i> input is removed. This input allows the controller to be fitted as part of a system where the restoration to Mains is controlled remotely or by an automated system.
Auto Run Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide an over-ride function to prevent the controller from starting/running the Generator Bus in the event of a remote start/scheduled run condition occurring. If this input is active and a remote start signal/scheduled run occurs the module does not give a start command to the Generator Bus or stops the Generator Bus if it is already running. If this input signal is then removed, the controller operates as if a remote start/scheduled run has occurred, starting and loading the Generator Bus. This function is used to give an ' AND ' function so that a Generator Bus is only called to start/run if a remote start request and another condition exists which requires the Generator Bus to run. If the 'Auto Run Inhibit' signal becomes active while the Generator Bus is running, a controlled shutdown sequence begins. If the Generator Bus is running in a load demand scheme, this input takes priority and begins the controlled shutdown sequence, causing another Generator Bus to start (if available). This input does not prevent starting of the Generator Bus in MANUAL/TEST mode.
Auto Start Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide an over-ride function to prevent the controller from starting the Generator Bus in the event of a remote start/Mains out of limits condition occurring. If this input is active and a remote start signal/Mains failure occurs the module does not give a start command to the Generator Bus. If this input signal is then removed, the controller operates as if a remote start/Mains failure has occurred, starting and loading the Generator Bus. This function is used to give an ' AND ' function so that a Generator Bus is only called to start if the Mains fails and another condition exists which requires the Generator Bus to run. If the 'Auto start Inhibit' signal becomes active once more it is ignored until the module has returned the Mains supply on load and shutdown. This input does not prevent starting of the Generator Bus in MANUAL mode.

Parameter descriptions are continued overleaf...

Function	Description
Auxiliary Mains Fail	The module monitors the incoming single or three phase supply for Over voltage, Under Voltage, Over Frequency or Under frequency. It may be required to monitor a different Mains supply or some aspect of the incoming Mains not monitored by the controller (such as a G59 or G99 Mains decoupling relay). If the devices providing this additional monitoring are connected to operate this input, the controller operates as if the incoming Mains supply has fallen outside of limits, the Generator Bus is instructed to start and take the load if not already running. Removal of the input signal causes the module to act if the Mains has returned to within limits providing that the Mains sensing also indicates that the Mains is within limits.
Bus Closed Auxiliary IEEE 37.2 - 3 Checking or Interlocking Relay	This input is used to provide feedback to allow the module to give true indication of the contactor or circuit breaker switching status. It must be connected to the Bus load switching device auxiliary contact.
Bus Load Inhibit IEEE 37.2 - 52 AC Circuit Breaker	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: This input only operates to control the Bus switchgear if the module load switching logic is attempting to load the Bus. </div> <p>This input is used to prevent the module from loading the Generator Bus. If the Generator Bus is already on load, activating this input causes the module to unload the Generator Bus without ramping. Removing the input allows the Generator Bus to be loaded again.</p>
Clear Mains Decoupling Alarms	This input is used to reset the module following a Mains Decoupling Alarm (ROCOF, Vector Shift, Mains Voltage Alarm, Mains Frequency Alarm). The input must switch from inactive to active to reset the trip, it is not to be left permanently active.
EJP1	For the French EJP (Effacement Jours de Pointe) tariff system. This input is functionally identical to <i>Remote Start Off Load</i> . When this input is active, operation is similar to the 'Remote Start on load' function except that the Generator Bus is not instructed to take the load. This function is also used where the Generator Bus only run is required e.g. for exercise.
EJP2	For the French EJP (Effacement Jours de Pointe) tariff system. This input is functionally identical to <i>Remote Start In Island Mode</i> . In auto mode, the module performs the start sequence and transfers load to the Generator Bus. In Manual mode, the load is transferred to the Generator Bus if the Generator Bus is already running, however in manual mode, this input does not generate start/stop requests of the generator Bus.
Enable Power Mode 1 Constant Power (Default)	This input is used to instruct the module to switch to <i>Power Mode 1 Constant Power (Default)</i>
Enable Power Mode 2 Frequency-Power	This input is used to instruct the module to switch to <i>Power Mode 2 Frequency-Power</i>
Enable Power Mode 3 Voltage-Power	This input is used to instruct the module to switch to <i>Power Mode 3 Voltage-Power</i>
Enable Power Mode 1 Constant Power Factor	This input is used to instruct the module to switch to <i>Power Mode 1 Constant Power Factor</i>
Enable Reactive Mode 2 Voltage-Reactive Power	This input is used to instruct the module to switch to <i>Reactive Mode 2 Voltage-Reactive Power</i>
Enable Reactive Mode 3 Power-Power Factor	This input is used to instruct the module to switch to <i>Reactive Mode 3 Power-Power Factor</i>
Enable Reactive Mode 4 Constant Reactive Power (Default)	This input is used to instruct the module to switch to <i>Reactive Mode 4 Constant Reactive Power (Default)</i>

Parameter descriptions are continued overleaf...

Function	Description
External Panel Lock	<p> NOTE: External control sources (i.e. Simulate Start Button) are not affected by the external panel lock input and continue to operate normally.</p> <p>This input is used to provide security to the installation. When the External Panel lock input is active, the module does not respond to operation of the Mode select or Start buttons. This allows the module to be placed into a specific mode (such as Auto) and then secured. The operation of the module is not affected, and the operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is still possible while the system lock is active</i>).</p>
Inhibit Remote Start of 8610	This input is used to provide a mean of disabling all start commands over the MSC link to the DSExx10 modules, including in the event of a Mains failure.
Inhibit Retransfer To Mains IEEE 37.2 - 3 Checking Or Interlocking Relay	When active, the input prevents the load from being transferred back to the Mains supply, only in the event of a Generator Bus failure. This is used in peak lopping systems where the cost of using the Mains to supply the load is so prohibitive that the customer does not want to transfer back to the Mains supply.
Inhibit Scheduled Run IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide a mean of disabling a scheduled run.
Inhibit SMS Remote Start	This input is used to provide a means of disabling remote starts by SMS
Keep Control of 8610s	This input is used to keep control over the DSExx10 modules and their generators, preventing another DSExx60 or DSExx80 taking control for synchronising and parallel operation.
Lamp Test	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LEDs illuminate.
Mains Closed Auxiliary IEEE 37.2 - 3 Checking or Interlocking Relay	This input is used to provide feedback to allow the module to give true indication of the contactor or circuit breaker switching status. It must be connected to the Mains load switching device auxiliary contact.
Mains Load Inhibit IEEE 37.2 - 52 AC Circuit Breaker	<p> NOTE: This input only operates to control the Mains switchgear if the module load switching logic is attempting to load the mains.</p> <p>This input is used to prevent the module from loading the mains. If the Mains is already on load, activating this input causes the module to unload the Mains without ramping. Removing the input allows the Mains to be loaded again.</p>
Manual Breaker Mode	When breaker control is set to <i>Active On Input</i> , this input is used to activate the <i>Manual Breaker Control</i> .
Manual Restore Contact	This input is used to manually allow back-sync to the Mains without removing the Auto-Restore Inhibit input.

Parameter descriptions are continued overleaf...

Function	Description
MSC Alarms Inhibit	<p>▲NOTE: The MSC Old Version alarm is not inhibited when this input is active.</p> <p>If this input is active, all MSC failure related alarms are inhibited from activating even if the fault is active.</p>
Paralleling Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	<p>This input is used to prevent the Generator Bus from running in parallel with the Mains supply and in turn, forces a break transfer to occur. If the input becomes active while in parallel, the transfer is completed and paralleling ends.</p>
Remote Start Dead Bus Synchronising	<p>▲NOTE: For further details, refer to the section entitled <i>Advanced Options</i> elsewhere in this document.</p> <p>This input is used to enable a Dead Bus Synchronising start and must be used in conjunction with another starting signal such as <i>Remote Start on Load</i>.</p>
Remote Start In Island Mode	<p>When in <i>Auto Mode</i>, the module performs the start sequence and transfer the load to the Generator Bus. The Mains switchgear is left open and the Generator Bus runs in island mode.</p> <p>In <i>Manual Mode</i>, the load is transferred to the Generator Bus if it is already running and available; however in <i>Manual Mode</i>, this input does not generate start/stop requests to the Generator Bus.</p>
Remote Start Off Load	<p>If this input is active, operation is similar to the 'Remote Start on load' function except that the Generator Bus is not instructed to take the load. This function is used where the Generator Bus only run is required e.g. for exercise.</p>
Remote Start On Load	<p>When in auto mode, the module performs the start sequence and places the Generator Bus in parallel with the mains.</p> <p>In Manual mode, the Generator Bus is placed in parallel with the Mains if it was already running; however in manual mode, this input does not generate start/stop requests.</p>
Simulate Auto Button	<p>▲NOTE: If a call to start is present when AUTO MODE is entered, the starting sequence begins. Call to Start comes from a number of sources depending upon module type and configuration and includes (but is not limited to) : Remote start input present, Mains failure, Scheduled run, Auxiliary Mains failure input present, Telemetry start signal from remote locations.</p> <p>This input mimics the operation of the 'Auto' button and is used to provide a remotely located Auto mode push button.</p>
Simulate Lamp Test / Alarm Mute Button	<p>This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LED's illuminate. The input also serves a second function, in that it also provides a mute signal to silence the audible alarm. The input is recognised by the module as though it was the Push button on the module itself being operated.</p>
Simulate Mains Available.	<p>This function is provided to override the module's internal monitoring function. If this input is active, the module does not respond to the state of the incoming AC Mains supply.</p>
Simulate Manual Button	<p>This input mimics the operation of the 'Manual' button and is used to provide a remotely located Manual mode push button.</p>

Parameter descriptions are continued overleaf...

Function	Description
Simulate Start Button	This input mimics the operation of the 'Start' button and is used to provide a remotely located start push button.
Simulate Stop Button	This input mimics the operation of the 'Stop' button and is used to provide a remotely located stop/reset push button.
Simulate Test On Load Button	This input mimics the operation of the 'Test' button and is used to provide a remotely located Test on load mode push button.
Stop and Panel Lock	Combined function input that instructs the module to enter <i>STOP</i> mode and also perform the <i>Panel Lock</i> function. Once the input is active, the module does not respond to operation of the mode select or start buttons. The operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is still possible while the system lock is active</i>).
Telemetry Panel Lock	Once the input is active, the module does not respond to mode changes or breaker control by telemetry. The operator is still able to control and view the various instrumentation pages through the front panel buttons.
Transfer To Bus / Open Mains IEEE 37.2 - 52 AC Circuit Breaker	This input is used to transfer the load to the Generator Bus when running in Manual Mode. Once synchronised, the Generator Bus and Mains are paralleled. The second press of the button causes the Generator Bus to take full load and open the Mains switchgear.
Transfer to Mains / Open Bus IEEE 37.2 - 52 AC Circuit Breaker	This input is used to transfer the load to the Mains when running in Manual Mode. Once synchronised, the Generator Bus and Mains are paralleled. The second press of the button causes the Mains to take full load and open the Generator Bus switchgear.

2.4 OUTPUTS

The *Outputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.4.1 DIGITAL OUTPUTS

The screenshot shows a configuration window for 'Relay Outputs'. It is divided into two sections: 'Relay Outputs (Volts Free)' and 'Relay Outputs (DC Supply Out)'. Each section has a table with columns for 'Output', 'Source', and 'Polarity'. A callout bubble points to the 'Output D' label in the first section, containing the text: 'These labels match the typical wiring'.

Relay Outputs (Volts Free)		
Output	Source	Polarity
Output C (N/C)	Close Mains Output	De-Energise
Output D	Close Bus Output	Energise

Relay Outputs (DC Supply Out)		
Output	Source	Polarity
Output E	Sufficient Sets Available	Energise
Output F	Common Alarm	Energise
Output G	System In Auto Mode	Energise
Output H	Mains Failure	Energise
Output I	Mains Failed To Close	Energise
Output J	Bus Failed To Close	Energise

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital output polarity: De-Energise: When the output source is true, the output deactivates. Energise: When the output source is true, the output activates.

2.4.2 VIRTUAL LEDS

The virtual LEDs provide a configuration of 'status' items. These items are not available for viewing on the module but are seen in the SCADA section of the PC software, or read by third party systems (i.e. BMS or PLCs) using the ModBus protocol.

LED Configuration		
	Source	Polarity
LED 1	Mains Failure	Lit
LED 2	Not Used	Lit
LED 3	Not Used	Lit
LED 4	Not Used	Lit
LED 5	Not Used	Lit
LED 6	Not Used	Lit
LED 7	Not Used	Lit
LED 8	Not Used	Lit
LED 9	Not Used	Lit
LED 10	Not Used	Lit
LED 11	Not Used	Lit
LED 12	Not Used	Lit
LED 13	Not Used	Lit
LED 14	Not Used	Lit
LED 15	Not Used	Lit
LED 16	Not Used	Lit
LED 17	Not Used	Lit
LED 18	Not Used	Lit
LED 19	Not Used	Lit
LED 20	Not Used	Lit

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital input polarity: Lit: When the output source is true, the virtual LED activates Unlit: When the output source is true, the virtual LED deactivates.

2.4.3 OUTPUT SOURCES

The list of output sources available for configuration of the module digital outputs.

Under the scope of IEEE 37.2, function numbers is also used to represent functions in microprocessor devices and software programs. Where the DSE output functions is represented by IEEE 37.2, the function number is listed below.

Output Source	Activates...	Is Not Active....
Not Used	The output does not change state (Unused)	
1 Constant Power Factor Mode	Active when the <i>Reactive Mode 1 Constant Power Factor</i> is selected.	
1 Constant Power Mode (Default)	Active when the <i>Power Mode 1 Constant Power (Default)</i> is selected.	
2 Frequency-Power Mode	Active when the <i>Power Mode 2 Frequency Power</i> is selected.	
2 Voltage-Reactive Power Mode	Active when the <i>Reactive Mode 2 Voltage Reactive Power</i> is selected.	
3 Power-Power Factor Mode	Active when the <i>Reactive Mode 3 Power Power Factor</i> is selected.	
3 Voltage-Power Mode	Active when the <i>Power Mode 3 Voltage Power</i> is selected.	
4 Constant Reactive Power Mode (Default)	Active when the <i>Reactive Mode 4 Constant Reactive Power (Default)</i> is selected.	
8660 Controls 8610s	Active when the module is controlling the DSExx10 modules and their generators, preventing another DSExx60 or DSExx80 taking control for synchronising and parallel operation.	
Alarm Mute	This input is used to silence the audible alarm from an external source such as a remote mute switch.	
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the Generator Bus.	
Alternative Language Selected	Active when the configured <i>Alternative Language Select</i> digital input is active	
Audible Alarm IEEE 37.2 – 74 Alarm Relay	Use this output to activate an external sounder or external alarm indicator. Operation of the Mute pushbutton resets this output once activated	Inactive if no alarm condition is active or if the Mute pushbutton was pressed
Auto Restore Inhibit	Active when the <i>Auto Restore Inhibit</i> digital input is active.	
Auto Run Inhibited	Active when the <i>Auto Run Inhibit</i> function is active	
Auto Start Inhibit	Active when the <i>Auto-Start Inhibit</i> function is active	
Auxiliary Mains Failure	Active when the <i>Auxiliary Mains Failure</i> input function is active	
Battery High Voltage IEEE 37.2 – 59 DC Overvoltage Relay	This output indicates that a Battery Over voltage alarm has occurred	Inactive when battery voltage is not High
Battery Low Voltage IEEE 37.2 – 27 DC Undervoltage Relay	This output indicates that a Battery Under Voltage alarm has occurred.	Inactive when battery voltage is not Low
Bus And Mains In Parallel	This output is active whenever the Bus and Mains are in parallel.	
Bus Asymmetry High IEEE 37.2 – 59 Overvoltage Relay	Active when the Bus Asymmetry Alarm is active	
Bus Closed Auxiliary	Active when the <i>Bus Closed Auxiliary</i> input is active	
Bus Failed To Close IEEE 37.2 - 48 Incomplete Sequence Relay	This output source is intended to be used to indicate a failure of the Bus contactor or breaker. It is only used if the module is configured to use 'Bus Closed Auxiliary' feedback.	

Parameter descriptions are continued overleaf...

Output Source	Activates...	Is Not Active....
Bus Failed To Open IEEE 37.2 - 48 Incomplete Sequence Relay	This output source is intended to be used to indicate a failure of the Bus contactor or breaker. It is only used if the module is configured to use 'Bus Closed Auxiliary' feedback.	
Bus Live	This output indicates that a voltage has been detected on the Generator Bus. Once the voltage on the Generator Bus is detected above the "Dead Bus relay setting", it is no longer considered a 'dead-bus' and the Mains needs to synchronise with the Bus.	
Bus Load Inhibit	Active when the digital input <i>Bus Load Inhibit</i> is active.	
Bus Negative Sequence Voltage High IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Bus Negative Sequence Voltage Alarm is active	
Bus Phase Rotation Alarm	This output indicates that the module has detected a phase sequence error on the Bus.	
Bus Positive Sequence Voltage Low IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Bus Positive Sequence Alarm is active	
Bus Zero Sequence Voltage High IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Bus Zero Sequence Alarm is active	
Calling For Scheduled Run	Active during a <i>Scheduled Run</i> request from the inbuilt <i>Scheduler</i> .	
Charger ID0, ID1, ID2, ID3 Common Shutdown	Active when the DSE module detects a Common Shutdown alarm on the relevant DSE Intelligent Charger connected to the DSEnet with the respective ID.	
Charger ID0, ID1, ID2, ID3 Common Warning	Active when the DSE module detects a Common Warning alarm on the relevant DSE Intelligent Charger connected to the DSEnet with the respective ID.	
Check Sync IEEE 37.2 – 25 Synchronising Or Synchronising Check Relay	Indicates that the internal check synchroscope has determined that the supplies are in sync.	
Clear Mains Decoupling	Active when the <i>Clear Mains Decoupling Alarms</i> digital input is active.	
Clock Pulse	Also called 'heartbeat', it activates and deactivates every few milliseconds to indicate that the module is powered up. It stops energising during write configuration to the module.	
Close Bus Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Generator Bus load switching device. Whenever the module selects the Generator Bus to be on load this control source is activated.	Inactive whenever the Generator Bus is not required to be on load
Close Bus Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Generator Bus load switching device. Whenever the module selects the Generator Bus to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Close Mains Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Mains load switching device. Whenever the module selects the Mains to be on load this control source is activated.	Inactive whenever the Mains is not required to be on load

Parameter descriptions are continued overleaf...

Output Source	Activates...	Is Not Active....
Close Mains Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the load switching device. Whenever the module selects the Mains to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Closed To Mains State	Active when the status of the Mains breaker is closed.	
Combined Mains Failure	Active when the Mains supply is out of limits OR the input for Auxiliary Mains Failure is active	
Combined Remote Start Request	Indicates that a remote start request is active.	
Common Alarm	Active when one or more alarms (of any type) are active	The output is inactive when no alarms are present
Common Electrical Trip	Active when one or more <i>Electrical Trip</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Mains Decoupling Alarm	Indicates 1 or more of the decoupling alarm have activated	
Common Warning	Active when one or more <i>Warning</i> alarms are active	The output is inactive when no warning alarms are present
Data Logging Active	Active when data is being logged	Inactive when: Data logging is disabled The Generator Bus is at rest and the option <i>Only Log When Start is Requested</i> is enabled The internal memory of the module becomes full and the option <i>Keep Oldest Data</i> is enabled
DC Power On	Active when DC power is supplied to the module	
Dead Bus Synchronise Enabled	Active when Dead Bus Synchronising is enabled.	
Dead Bus Synchronise In Progress	Active when the Generator Bus is running dead Bus synchronising.	
Digital Input A, B, C, D, E, F, G H, I, J, K & L	Active when the relevant digital input is active	
Display Heater Fitted and On	Active when the display heater is on	
EJP1 / EJP2	Active when an input configured for <i>EJP1</i> or <i>EJP2</i> is active	
Expansion 2130 Address 0 to 3 Analogue Input E to H (Digital)	Active when the relevant analogue input on the relevant DSE2130 is configured as a digital input and is active	
Expansion 2130 Address 0 to 3 Analogue Input A to D (Digital)	Active when the relevant digital input on the relevant DSE2130 is active	
Expansion 2130 Address 0 to 3 Input E to H High Shutdown	Active when the relevant analogue input on the relevant DSE2130 high alarm is active	
Expansion 2130 Address 0 to 3 Input E to H High Warning	Active when the relevant analogue input on the relevant DSE2130 high pre-alarm is active	
Expansion 2130 Address 0 to 3 Input E to H Low Shutdown	Active when the relevant analogue input on the relevant DSE2130 low alarm is active	

Parameter descriptions are continued overleaf...


Editing the Configuration

Output Source	Activates...	Is Not Active....
Expansion 2130 Address 0 to 3 Input E to H Low Warning	Active when the relevant analogue input on the relevant DSE2130 low pre-alarm is active	
Expansion 2131 Address 0 to 3 Analogue Input A to J (Digital)	Active when the relevant analogue input on the relevant DSE2131 is configured as a digital input and is active	
Expansion 2131 Address 0 to 3 Input A to J High Shutdown	Active when the relevant analogue input on the relevant DSE2131 high alarm is active	
Expansion 2131 Address 0 to 3 Input A to J High Warning	Active when the relevant analogue input on the relevant DSE2131 high pre-alarm is active	
Expansion 2131 Address 0 to 3 Input A to J Low Shutdown	Active when the relevant analogue input on the relevant DSE2131 low alarm is active	
Expansion 2131 Address 0 to 3 Input A to J Low Warning	Active when the relevant analogue input on the relevant DSE2131 low pre-alarm is active	
Expansion 2133 Address 0 to 3 Input A to H High Shutdown	Active when the relevant analogue input on the relevant DSE2133 high alarm is active	
Expansion 2133 Address 0 to 3 Input A to H High Warning	Active when the relevant analogue input on the relevant DSE2133 high pre-alarm is active	
Expansion 2133 Address 0 to 3 Input A to H Low Shutdown	Active when the relevant analogue input on the relevant DSE2133 low alarm is active	
Expansion 2133 Address 0 to 3 Input A to H Low Warning	Active when the relevant analogue input on the relevant DSE2133 low pre-alarm is active	
Fail to Synchronise <i>IEEE 37.2 - 48 Incomplete Sequence Relay</i>	Becomes active if the module fails to synchronise after the <i>fail to sync</i> timer.	
Fault Ride Through Event	Becomes active during a <i>Fault Ride Through</i> event, the module generates a Warning alarm.	Becomes inactive when there is no <i>Fault Ride Through</i> event.
Inhibit Retransfer To Mains	Indicates that the load is prevented from being transferred back to the Mains supply in the event of a Generator Bus failure. This is used in peak lopping systems where the cost of using the Mains to supply the load is so prohibitive that the customer does not want to transfer back to the Mains supply.	
Inhibit Scheduled Run	Active when the Inhibit Scheduled run input is active	
Inhibit SMS Start	Active when the input Inhibit SMS Start input is active	
Insufficient Capacity Available	Indicates that during parallel operation, it has been determined that the Generator Bus is not capable of providing the power configured to deliver.	
Interlock Override	<p>Activates when the <i>Synchronising Delay</i> timer begins.</p> <p>Used to disable external interlock between the Mains and Bus switchgear when the supplies are requested in to be in parallel.</p>	De-activates when the <i>Interlock Override Delay</i> timer expires after the changeover has completed.
Keep Control Of 8610s	Active when the <i>Keep Control of 8610s</i> input is active	
Lamp Test	Active when the lamp test is activated by a digital input or by pressing the <i>Mute/Lamp Test</i> control button	


Parameter descriptions are continued overleaf...

Output Source	Activates...	Is Not Active....
Mains Asymmetry High IEEE 37.2 – 59 Overvoltage Relay	Active when the Mains Asymmetry Alarm is active	
Mains Closed Aux	Active when the <i>Mains Closed Auxiliary</i> input is active	
Mains Decoupling High Frequency Stage 1,2	This output indicates that the relevant Mains decoupling high frequency alarm has been triggered.	
Mains Decoupling High Voltage Stage 1,2	This output indicates that the relevant Mains decoupling high voltage alarm has been triggered.	
Mains Decoupling Low Frequency Stage 1,2	This output indicates that the relevant Mains decoupling low frequency alarm has been triggered.	
Mains Decoupling Low Voltage Stage 1,2	This output indicates that the relevant Mains decoupling low voltage alarm has been triggered.	
Mains Failed To Close	This output indicates the Mains breaker failed to close	
Mains Failed To Open	This output indicates the Mains breaker failed to open	
Mains Failure IEEE 37.2 - 81 Frequency Relay IEEE 37.2 – 27AC Under Voltage Relay IEEE 37.2 – 59AC Over Voltage Relay	The output indicates that one or more of the module's sources of determining Mains failure is active. The output is inactive when the Mains supply is healthy	
Mains High Frequency IEEE 37.2 - 81 Frequency Relay	Active when the Mains frequency exceeds the <i>High Frequency</i> setting	
Mains High Voltage IEEE 37.2 – 59AC Overvoltage Relay	Active when the Mains voltage exceeds the <i>High Voltage</i> setting	
Mains Load Inhibited	Active when the <i>Mains Load Inhibit</i> digital input is active	
Mains Low Frequency IEEE 37.2 - 81 Frequency Relay	Active when the Mains frequency falls below the <i>Low Frequency</i> setting	
Mains Low Voltage IEEE 37.2 – 27AC Under Voltage Relay	Active when the Mains voltage falls below the <i>Low Voltage</i> setting	
Mains Negative Sequence Voltage High IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Mains Negative Sequence Voltage Alarm is active	
Mains Phase Rotation Alarm IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Mains phase rotation alarm is active	
Mains Positive Sequence Voltage Low IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Mains Positive Sequence Alarm is active	
Mains ROCOF	Indicates that the ROCOF protection (when in parallel with mains) has triggered.	
Mains Vector Shift	Indicates that the Vector Shift protection (when in parallel with mains) has triggered.	
Mains Zero Sequence Voltage High IEEE 37.2 – 47 Phase-Sequence Or Phase Balance Voltage Relay	Active when the Mains Zero Sequence Alarm is active	
Minimum Sets Not Reached	Indicates that the required number of generators that are closed on to the Bus has not been met to allow the module to close the Bus switchgear.	
MSC Alarms Disabled	Active when the MSC Alarms Inhibit digital input function is active.	

Parameter descriptions are continued overleaf...

Output Source	Activates...	Is Not Active....
MSC Data Error	Indicates bad data transfer on both of the MultiSet Comms (MSC) Links.	
MSC Electrical Trip	Active when any MSC Alarm is active.	
MSC Failure	Indicates when the <i>MSC Failure</i> alarm is active on both MultiSet Comms (MSC) Links.	
MSC ID Error	Active when another controller is using the same <i>MSC ID</i> on either of the MultiSet Comms (MSC) Links.	
MSC Link 1 or 2 Data Error	Indicates bad data transfer on the first or second MultiSet Comms (MSC) Link.	
MSC Link 1 or 2 Failure	Active when the <i>MSC Failure</i> alarm is active on the first or second MultiSet Comms (MSC) Link.	
MSC Link 1 or 2 Too Few Sets	Indicates that the number of DSExx10s connected on the first or second MultiSet Comms (MSC) Link is lower than the <i>Minimum Sets Required</i> setting.	
MSC Old Units On the Bus	Active when any MSC versions are incorrect/incompatible on either MultiSet Comms (MSC) Links.	
MSC Priority Error	Active when another DSExx60 or DSExx80 module is using the same <i>MSC Priority</i> on either of the MultiSet Comms (MSC) Links.	
MSC Too Few Sets	Indicates that the number of sets connected on the MultiSet Comms (MSC) Link is lower than the <i>Minimum Sets Required</i> setting.	
Mute / Lamp Test Button Pressed	This output indicates that the Alarm Mute / Lamp Test push button is being operated. Once the button is released, the output becomes inactive.	
New Coil x	<div style="border: 3px double black; padding: 5px;">  NOTE: The PLC Coil may be renamed in the PLC Editor which effects on the function name listed in the Output Sources. For more details refer to DSE Publication: 057-314 Advanced PLC Software Manual which is found on our website: www.deepseaelectronics.com </div>	
	Active when the relevant <i>PLC Coil</i> is active.	
No Loading Command	This output indicates that the module is not calling for the Generator Bus switchgear to be closed. When the module closes the Generator Bus switchgear, this output becomes inactive.	
Open Bus Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Generator Bus load switching device. Whenever the module selects the Generator Bus to be off load this control source is activated.	Inactive whenever the Generator Bus is required to be on load
Open Bus Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Generator Bus switchgear device. Whenever the module selects the Generator Bus to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	
Open Mains Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Mains load switching device. Whenever the module selects the Generator Bus to be off load this control source is activated.	Inactive whenever the Mains is required to be on load
Open Mains Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the Mains switchgear device. Whenever the module selects the Generator Bus to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	
Out of Sync	Indicates that the <i>Out of Sync</i> alarm has been triggered.	
Out of Sync Bus	Indicates that the Bus supply were out of limits and <i>Out of Sync Bus</i> alarm was triggered when both supply breakers were closed.	

Parameter descriptions are continued overleaf...

Output Source	Activates...	Is Not Active....
Out of Sync Mains	Indicates that the Mains supply was out of limits and <i>Out of Sync Mains</i> alarm was triggered when both supply breakers were closed.	
Panel Locked	This output indicates that the module ' <i>Panel Lock</i> ' is active. If the Panel lock input is active, the module does not respond to operation of the Mode select or start buttons. This allows the module to be placed into a specific mode (such as Auto) and then secured. The operation of the module is not affected and the operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is barred while system lock is active</i>).	
Panel Locked By Digital Input	This output indicates that a digital input that has been configured as ' <i>Panel Lock</i> ' is active. If the Panel lock input is active, the module does not respond to operation of the Mode select or start buttons. This allows the module to be placed into a specific mode (such as Auto) and then secured. The operation of the module is not affected and the operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is barred while system lock is active</i>). Refer to the ' <i>Edit Inputs</i> ' section of this manual for details.	
Panel Locked By Telemetry	This output indicates that remote ' <i>Panel Lock</i> ' via telemetry is active. If the Panel lock is active, the module does not respond to operation of the Mode select or start buttons. This allows the module to be controller remotely without local interference. The operation of the module is not affected and the local operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is barred while system lock is active</i>).	
Parallel Inhibit	Active when the <i>Parallel Inhibit</i> digital input is active.	
PLC Output Flag 1 to 100	<div style="border: 1px solid black; padding: 5px;">  NOTE: PLC Output Flags are supported on module versions up to and including v5.1 </div> Active when the <i>PLC Flag</i> is active	
Remote Control 1 to 10	A series of output sources that are controlled by remote control in the SCADA section of the software, used to control external circuits.	
Remote Start From Digital Input	Active when any configured <i>Remote Start</i> digital input is active.	
Remote Start In Island Mode	This output indicates that a digital input that has been configured as ' <i>Remote Start in island mode</i> ' is active. This output could be used to pass the start signal on to elsewhere in the control system.	
Remote Start Off Load	Active when the <i>Remote Start Off Load</i> input is active	
Remote Start On Load	Active when the <i>Remote Start On Load</i> input is active	
Remote Start Over MSC	Indicates that the module has activated a remote start command over the MSC link	
Return Delay In Progress	This output source is active to indicate that the return timer is running.	
Scheduled Auto Start Inhibit	Active during a <i>Scheduled Auto Start Inhibit</i> request from the inbuilt <i>Scheduler</i> .	
Simulate Auto Button	Active when the <i>Simulate Auto Button</i> digital input is active	
Simulate Mains Available	Active when the <i>Simulate Mains Available</i> digital input is active	
Simulate Start Button	Active when a digital input configured to <i>Simulate Start Button</i> is active	
Simulate Stop Button	Active when the <i>Simulate Stop Button</i> digital input is active	
Simulate Test On Load Button	Active when the <i>Simulate Test On Load Button</i> digital input is active.	
Simulate Transfer To Generator Button	Active when the <i>Transfer To Bus / Open Mains</i> digital input is active.	


Parameter descriptions are continued overleaf...

Editing the Configuration

Output Source	Activates...	Is Not Active....
Simulate Transfer To Mains Button	Active when the <i>Transfer To Mains / Open Bus</i> digital input is active.	
SMS Remote Start in Island Mode	Active when the module receives an SMS message to start and run in island mode	
SMS Remote Start Off Load	Active when the module receives an SMS message to start and run off load	
SMS Remote Start On Load	Active when the module receives an SMS message to start and run load	
Stop and Panel lock	Active when the <i>Stop And Panel Lock</i> digital input is active	
Stop Button Pressed	This output indicates that the stop pushbutton is being operated. Once the button is released, the output becomes inactive.	
Sufficient Sets Available	This output indicates that there are sufficient generators available on the Bus.	
Synching Enabled	This output indicates that the synchronisation feature has been enabled.	
System Healthy	This output indicates that the module is in Auto Mode and there are no alarms present.	
System in Auto Mode	Active when Auto mode is selected	
System in Manual Mode	Active when Manual mode is selected	
System in Stop Mode	Active when Stop mode is selected	
System in Test Mode	Active when Test mode is selected	
Telemetry Active	Active when the communication port is live and for a short time after transmission stops. Used as a relay or LED source.	
Telemetry Data Active	Active when data is being transmitted. This output changes continuously state (flash) upon data transfer. Normally used as an LED source rather than a relay source as the signal flashes repeatedly. For a similar source more suited to drive a relay, see <i>Telemetry Active</i> .	
Telemetry Panel Lock	Active when the <i>Telemetry Panel Lock</i> digital input is active	
Telemetry Start in Auto Mode	Active when a <i>Remote Start Request</i> is sent over by communication	
Trip Bus in Parallel	This output indicates that the module has been forced to remove the generators Bus from its load to pass control of the generators over to another DSExx60 that has detected a Mains failure. This only occurs if the <i>Enable Forced Peak Lop Inhibit</i> has been enabled.	
Waiting For Manual Restore IEEE 37.2 – 3 Checking or Interlocking Relay	Becomes active when the Generator Bus is on load and the Mains supply is healthy but an input configured to <i>Manual Restore</i> is active. This is used to signal to an operator that action is required before the load transfers back to the Mains supply.	


2.5 TIMERS

Many timers are associated with alarms. Where this occurs, the timer for the alarm is located on the same page as the alarm setting. Timers not associated with an alarm are located on the timers page. The *Timers* page is subdivided into smaller sections. Select the required section with the mouse.



2.5.1 START TIMERS

Start Delay




Click and drag to change the setting.
Timers increment in steps of 1 second up to one minute, then in steps of 30 seconds up to 30minutes, then in steps of 30 minutes thereafter (where allowed by the limits of the timer).

Timer	Description
Remote Start Off Load	The amount of time delay before starting in AUTO mode. This timer is activated upon the <i>Remote Start Off Load</i> command being issued. Typically this timer is applied to prevent starting upon fleeting start signals.
Remote Start On Load	The amount of time delay before starting in AUTO mode. This timer is activated upon the <i>Remote Start On Load</i> command being issued. Typically this timer is applied to prevent starting upon fleeting start signals.
Telemetry Start	The amount of time delay before starting in AUTO mode. This timer is activated upon a <i>Remote Start</i> command being received from a MODBUS master. Typically this timer is applied to prevent starting upon fleeting start signals.
Mains Fail	The amount of time delay before starting in AUTO mode. This timer is activated upon a Mains failure detection.
Mains Transient Delay	Used to give a delay between sensing Mains failure and acting upon it. This is used to prevent dropouts of the Mains load switch and operation of the system due to Mains supply transient conditions.


2.5.2 LOAD / STOPPING TIMERS

Load Timers




Timer	Description
Transfer Time / Load Delay	The delay time between the Mains switchgear opening to the Bus switchgear closing.
Breaker Close Pulse	The amount of time that <i>Breaker Close Pulse</i> signal is present when the request to close the load switch is given.
Breaker Trip Pulse	The amount of time that <i>Breaker Open Pulse</i> signal is present when the request to open the load switch is given.
Bus Close Delay	The time from the Mains breaker becoming open to the Bus Breaker being requested to close. This is used to allow the Generator Bus voltage/frequency to stabilise before taking load.
Parallel Run Time	This timer dictates how long the Generator Bus runs in parallel with the Mains supply after ramping up or before ramping down.

Stopping Timers



Timer	Description
Return Delay	A delay, used in auto mode only, that allows for short term removal of the request to stop the Generator Bus before action is taken. This is usually used to ensure the Generator Bus remains on load before accepting that the start request has been removed.


2.5.3 MODULE TIMERS



Timer	Description
Page	If the module is left unattended for the duration of the <i>LCD Page Timer</i> it reverts to show the <i>Status</i> page.
Scroll	The scroll time between parameters on a selected page

2.6 MAINS

The *Mains* section is subdivided into smaller sections.
Select the required section with the mouse



2.6.1 MAINS OPTIONS

AC System

AC System

AC System 3 Phase, 4 Wire

L1(R)

N

L3(T)

L2(S)

45

46

47

VT fitted


Primary 11000 110 Secondary vPhPh

Select your AC system. A schematic is shown below with connection details from the alternator to the module.

Click to enable or disable the feature. The relevant values below appear *greyed out* when the alarm is disabled.


Parameter	Description
AC System	<p>Select the AC topology of the Mains from the following list:</p> <ul style="list-style-type: none"> 2 Phase, 3 Wire L1 - L2 2 Phase, 3 Wire L1 - L3 3 Phase, 3 Wire 3 Phase, 3 Wire NVD 3 Phase, 4 Wire 3 Phase, 4 Wire Delta L1 - N - L2 3 Phase, 4 Wire Delta L1 - N - L3 3 Phase, 4 Wire Delta L2 - N - L3 Single Phase, 2 Wire Single Phase, 3 Wire L1 - L2 Single Phase, 3 Wire L1 - L3
VT Fitted	<p><input type="checkbox"/> = The voltage sensing to the controller is direct from the alternator</p> <p><input checked="" type="checkbox"/> = The voltage sensing to the controller is via Voltage Transformers (VTs or PTs)</p> <p>This is used to step down the generated voltage to be within the controller voltage specifications.</p> <p>By entering the <i>Primary</i> and <i>Secondary</i> voltages of the transformer, the controller displays the <i>Primary</i> voltage rather than the actual measured voltage.</p> <p>This is typically used to interface the DSE module to high voltage systems (i.e. 11kV)</p>

Phase Rotation




Parameter	Description
Phase Rotation IEEE 37.2 – 47 Phase Sequence Relay	An electrical trip alarm is generated when the measured phase rotation is not as configured.

Breaker Control



Parameter	Description
Enable Breaker Alarms	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The <i>Mains Breaker Alarms</i> are enabled.
Fail To Open Delay	When the <i>Open Mains</i> output is activated, if the configured <i>Mains Closed Auxiliary</i> digital input does not become inactive within the <i>Mains Fail To Open Delay</i> timer, the alarm is activated
Fail To Close Delay	When the <i>Close Mains</i> output is activated, if the configured <i>Mains Closed Auxiliary</i> digital input does not become active within the <i>Mains Fail To Close Delay</i> timer, the alarm is activated
Fail To Open Action	The alarm activates when the mains switchgear fails to open. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: Electrical Trip Warning


Phase Offset



Parameter	Description
Allow Editing	<input type="checkbox"/> = <i>Phase Offset</i> for the Mains VTs is disabled <input checked="" type="checkbox"/> = The <i>Phase Offset</i> for the Mains VTs is enabled.
Phase Offset	Set the phase angle between the main's VT primary and secondary


2.6.2 MAINS VOLTAGE ALARMS

Under Voltage Alarms




Alarm	Description
Mains Under Voltage IEEE 37.2 – 27 AC Undervoltage Relay	<input type="checkbox"/> = Mains Under Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Under Voltage gives an alarm in the event of the Mains voltage falling below the configured <i>Under Voltage Trip</i> value. The <i>Under Voltage Trip</i> value is adjustable to suit the application. The alarm is reset and the Mains is considered within limits when the Mains voltage rises above the configured <i>Under Voltage Return</i> level.

Nominal Voltage



Parameter	Description
Nominal Voltage	This is used to calculate the percentages of the alarm set points. It is also used when the Bus and Mains VTs have different ratios, to synchronise the voltage of both supplies.

Over Voltage Alarms



Parameter	Description
Mains Over Voltage IEEE 37.2 – 59 AC Overvoltage Relay	<input type="checkbox"/> = Mains Over Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Over Voltage gives an alarm in the event of the Mains voltage rising above the configured <i>Over Voltage Trip</i> value. The <i>Over Voltage Trip</i> value is adjustable to suit the application. The alarm is reset and the Mains is considered within limits when the Mains voltage falls below the configured <i>Over Voltage Return</i> level.

2.6.3 MAINS SEQUENCE ALARMS

Zero Sequence Alarm

Parameter	Description
Zero Sequence Alarm IEEE 37.2 – 47H Phase-Sequence Or Phase Balance Voltage Relay	<p>NOTE: The Zero Sequence Alarm must be set to a third of the required Neutral Voltage Displacement (NVD) value. This is because the summation of the three Zero Sequence vector components is equal to the NVD value.</p> <p>This is also known as Neutral Voltage Displacement. <input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the difference in potential between the Earth and the calculated Neutral position of a 3 wire delta exceeds the configured <i>Zero Sequence Alarm Trip</i> level for the configured <i>Delay</i> time.</p>
Action	Select the type of alarm required from the list: Auxiliary Mains Fail Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Positive Sequence Alarm

Parameter	Description
Positive Sequence Alarm IEEE 37.2 – 47L Phase-Sequence Or Phase Balance Voltage Relay	<p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the <i>Positive Sequence</i> voltage falls below the configured <i>Positive Sequence Alarm Trip</i> level for the configured <i>Delay</i> time.</p>
Action	Select the type of alarm required from the list: Auxiliary Mains Fail Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Negative Sequence Alarm


Parameter	Description
Negative Sequence Alarm IEEE 37.2 – 47H Phase-Sequence Or Phase Balance Voltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the <i>Negative Sequence</i> voltage exceeds the configured <i>Negative Sequence Alarm</i> level for the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Auxiliary Mains Fail Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Asymmetry Alarm

Parameter	Description
Asymmetry Alarm IEEE 37.2 – 59 Overvoltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the voltage between any two phases exceeds the configured <i>Asymmetry Alarm Trip</i> level for the configured <i>Delay</i> time. For example: L1 = 230 V, L2 = 235 V, L3 = 226V Asymmetry is <i>largest value – smallest value</i> = 235 V – 226 V = 9 V
Action	Select the type of alarm required from the list: Auxiliary Mains Fail Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.


2.6.4 MAINS FREQUENCY ALARMS

Under Frequency Alarms



Parameter	Description
Mains Under Frequency IEEE 37.2 – 81 Frequency Relay	<input type="checkbox"/> = Mains Under Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Under Frequency gives an alarm in the event of the Mains frequency falling below the configured <i>Under Frequency Trip</i> value. The <i>Under Frequency Trip</i> value is adjustable to suit the application. The alarm is reset and the Mains is considered within limits when the Mains frequency rises above the configured <i>Under Frequency Return</i> level.

Over Frequency Alarms



Parameter	Description
Mains Over Frequency IEEE 37.2 – 81 Frequency Relay	<input type="checkbox"/> = Mains Over Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Over Frequency gives an alarm in the event of the Mains frequency rising above the configured <i>Over Frequency Trip</i> value. The <i>Over Frequency Trip</i> value is adjustable to suit the application. The alarm is reset and the Mains is considered within limits when the Mains frequency falls below the configured <i>Over Frequency Return</i> level.

2.6.5 CURRENT

CT Options

CT Options

Single CT on Mains *CT must be fitted to L1*

Parameter	Description
Single CT on Mains	<input type="checkbox"/> = <i>Single CT on Mains</i> disabled. A CTs is required on each phase for measuring Mains current, <input checked="" type="checkbox"/> = <i>Single CT on Mains</i> enabled. Only one CT for measuring Mains current is required. The system assumes a balanced kw & kvar load and all phases, mirroring the values seen on L1.

Mains Current Options

Mains Current Options

CT Primary (L1,L2,L3) A

CT Secondary

Full Load Rating kW


Full KVAr Rating kVAr

Parameter	Description
CT Primary	Primary rating of the three phase current transformers.
CT Secondary	Secondary rating of all the current transformers, options are: 1 Amp 5 Amp
Full Load Rating	The kW rating of the Mains incoming supply. This is used for calculating the power control when the Generator Bus is in long term parallel with the mains
Full kvar Rating	The kvar rating of the Mains incoming supply. This is used for calculating the power control when the Generator Bus is in long term parallel with the mains. To calculate the kvar rating of a mains: <ul style="list-style-type: none"> Most Mains supplies are rated for a lagging power factor (kW / kVA) of 0.8, though contact the Mains supplier for further details. From Pythagoras: $\cos \Phi = \frac{\text{kW}}{\text{kVA}}$ $\cos \Phi = 0.8$ $\Phi = \cos^{-1} 0.8 = 36.87^\circ$ From this, the kvar rating of the typical 0.8 pf rated Mains supply s: $\tan \Phi = \frac{\text{kvar}}{\text{kW}}$ $\text{kvar} = \tan 36.87^\circ \times \text{kW}$ $\text{kvar} = 0.75 \times \text{kW}$ Or to simplify this, the kvar rating of a 0.8 pf rated Mains supply is $\frac{3}{4}$ of the kW rating (kvar rating = 75% of kW rating)

Export Power

Parameter	Description
Export Power	<input type="checkbox"/> = The module does not protect against excessive kW export into the mains. <input checked="" type="checkbox"/> = The module monitors the kW exported to the Mains supply and provides an alarm condition if the <i>Exported Power</i> exceeds the <i>Trip</i> value for the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Electrical Trip None Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

2.6.6 MAINS DECOUPLING



The *Mains Decoupling* section is subdivided into smaller sections. Select the required section with the mouse.

The controller includes “Mains decoupling” detection to be used with generators paralleling with the Mains (utility) supply.

When the Generator Bus is in parallel with the Mains supply it is important that failure of the Mains is detected as soon as possible otherwise problems arise. It is not possible to simply monitor the Mains voltage and frequency as the sensing of this is now being fed by the Generator Bus itself!


Because of this and other possible dangerous situations, the power supply companies impose regulations when generators are in parallel. This is to detect Mains failure during parallel operation and to remove the Generator from the grid in this situation.

Failure to detect and act upon loss of Mains supply when in parallel leads to the following effects:

- The Generator feeds the site load and attempts to feed the load of the grid. Depending upon the Generator Bus size and the location of the network fault, this causes problems to the Generator Bus in terms of capacity and stability.
- If the Generator Bus is able to supply the load, Engineers working on the supposedly dead network would be in fact working on live cables, supplied by the Generator Bus. This is potentially fatal.
- When the Mains supply is reconnected and the Generator Bus is still connected to the grid, the network would be connected to the Generator Bus but not synchronised with it, with damaging results (mechanical failure, rotating diode failure, overloaded cables, pole slip etc)

2.6.6.1 LOSS OF MAINS

Options




Parameter	Description
Action	<p>Select the required action when the module detects a Mains decoupling event:</p> <p>Auxiliary Mains Fail: Opens the Mains switchgear and allows the Generator Bus to continue providing power to the load.</p> <p>Electrical Trip: The Generator Bus switchgear is opened and the generators are allowed to perform a cooling run before being stopped. If the Mains is within limits after the decoupling event, it continues to supply the load.</p> <p>Warning: Audible alarm is generated but the switchgear is are not opened.</p> <p>For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p>

R.O.C.O.F. Alarm



Parameter	Function
R.O.C.O.F. IEEE 37.2 - 81 Frequency relay	<p><input type="checkbox"/> = R.O.C.O.F. protection is disabled</p> <p><input checked="" type="checkbox"/> = R.O.C.O.F. protection is enabled when the Generator Bus is in parallel with the Mains supply.</p> <p>R.O.C.O.F. detection senses sudden, fast changes in the frequency of the waveform. During the failure of the Mains supply when in parallel with the Generator bus, the frequency changes faster than is usual by either the on load Generator bus, or by the Mains supply.</p>

Vector Shift Alarm



Parameter	Function
Vector Shift	<p><input type="checkbox"/> = Vector Shift protection is disabled</p> <p><input checked="" type="checkbox"/> = Vector Shift protection is enabled. The <i>Vector Shift Alarm</i> activates when the generator/Mains voltage vector changes by more than the <i>Trip</i> setting. The <i>Vector Shift Alarm</i> is only enabled when the generator is in parallel with the Mains supply.</p> <p>Vector Shift detection measures the length of each cycle of the voltage wave. When the Mains fails in parallel with the Generator bus, the sudden change in load creates a change in the length of the cycle length.</p>

2.6.6.2 VOLTAGE ALARMS

Options

Options
Alarm Action: Electrical Trip

Parameter	Description
Alarm Action	The <i>Alarm Action</i> is locked to the same configuration as in the <i>Loss Of Mains</i> . This section is displayed for clarification purposes only.

Limits

Limits
Impose IEEE 1547 Limits: No Limits

Parameter	Description
Impose IEEE 1547 Limits	<p>NOTE: Category Limits are only applicable for 60Hz nominal frequency.</p> <p>Limit the Mains Decoupling Alarms as imposed by IEEE rules, options are:</p> <p>No Limits Category I Limit Category II Limit Category III Limit</p>

Under Voltage Alarms

Under Voltage Alarms

Stage 2 Enable Trip 50 V PhN 21.7% 50V PhN Delay 0.0 s

Stage 1 Enable Trip 184 V PhN 80.0% 184V PhN Delay 2.5 s


Parameter	Description
Mains Under Voltage, Stage 1 to Stage 2 IEEE 37.2 - 27AC Undervoltage Relay	<p>These are '2 stage' alarms.</p> <p>Stage 1 allows for a delayed operation should the voltage stray by a small amount.</p> <p>Stage 2 allows for a faster trip should the voltage change by a larger amount.</p> <p><input type="checkbox"/> = Mains Under Voltage does NOT give an alarm <input checked="" type="checkbox"/> = Mains Under Voltage protection is enabled when the Generator Bus is in parallel with the Mains supply. The alarm activates when the Mains voltage falls below the configured <i>Under Voltage Alarm Trip</i> value for longer than the <i>Delay</i>. The <i>Under Voltage Alarm Trip</i> value is adjustable to suit user requirements.</p>

Nominal Voltage



Parameter	Description
Mains Nominal Voltage	The <i>Mains Nominal Voltage</i> is locked to the same configuration as the <i>Bus Nominal Voltage</i> . This section is displayed for clarification purposes only.

Over Voltage Alarms



Parameter	Description
Mains Over Voltage, Stage 1 to Stage 2 IEEE 37.2 - 59AC Overvoltage Relay	<p>These are '2 stage' alarms.</p> <p>Stage 1 allows for a delayed operation should the voltage stray by a small amount.</p> <p>Stage 2 allows for a faster trip should the voltage change by a larger amount.</p> <p><input type="checkbox"/> = Mains Over Voltage does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Over Voltage protection is enabled when the Generator Bus is in parallel with the Mains supply. The alarm activates when the Mains voltage rises above the configured <i>Over Voltage Alarm Trip</i> value for longer than the <i>Delay</i>. The <i>Over Voltage Alarm Trip</i> value is adjustable to suit user requirements.</p>

2.6.6.3 FREQUENCY

Options

The 'Options' panel contains a label 'Alarm Action' followed by a dropdown menu currently set to 'Electrical Trip'.

Parameter	Description
Alarm Action	The <i>Alarm Action</i> is locked to the same configuration as in the <i>Loss Of Mains</i> . This section is displayed for clarification purposes only.

Limits

The 'Limits' panel contains a label 'Impose IEEE 1547 Limits' followed by a dropdown menu currently set to 'No Limits'.


Parameter	Description
Impose IEEE 1547 Limits	<p>NOTE: Category Limits are only applicable for 60Hz nominal frequency.</p> <p>The <i>Limits</i> is locked to the same configuration as in the <i>Mains Decoupling Voltage</i> section's <i>Limits</i>. This section is displayed for clarification purposes only.</p>

Under Frequency Alarms

The 'Under Frequency Alarms' panel shows two stages of configuration. Stage 2 is enabled with a trip set to 47.00 Hz and a delay of 0.50 s. Stage 1 is also enabled with a trip set to 47.50 Hz and a delay of 20.00 s. Each stage includes a checkbox for 'Enable', a 'Trip' value in Hz, a visual frequency scale, and a 'Delay' in seconds.


Parameter	Description
Mains Under Frequency, Stage 1 to Stage 2 IEEE 37.2 – 81L Frequency Relay	<p>These are '2 stage' alarms.</p> <p>Stage 1 allows for a delayed operation should the frequency stray by a small amount.</p> <p>Stage 2 allows for a faster trip should the frequency change by a larger amount.</p> <p><input type="checkbox"/> = Mains Under Frequency does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Under Frequency protection is enabled when the Generator Bus is in parallel with the Mains supply. The alarm activates when the Mains voltage falls below the configured <i>Under Frequency Alarm Trip</i> value for longer than the <i>Delay</i>. The <i>Under Frequency Alarm Trip</i> value is adjustable to suit user requirements.</p>

Nominal Frequency



Parameter	Description
Mains Nominal Frequency	The <i>Mains Nominal Frequency</i> is locked to the same configuration as the <i>Bus Nominal Frequency</i> . This section is displayed for clarification purposes only.


Over Frequency Alarms




Parameter	Description
Mains Over Frequency, Stage 1 to Stage 5 IEEE 37.2 – 81H Frequency Relay	<p>These are '2 stage' alarms.</p> <p>Stage 1 allows for a delayed operation should the frequency stray by a small amount.</p> <p>Stage 2 allows for a faster trip should the frequency change by a larger amount.</p> <p><input type="checkbox"/> = Mains Over Frequency does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Over Frequency protection is enabled when the Generator Bus is in parallel with the Mains supply. The alarm activates when the Mains voltage rises above the configured <i>Over Frequency Alarm Trip</i> value for longer than the <i>Delay</i>. The <i>Over Frequency Alarm Trip</i> value is adjustable to suit user requirements.</p>

2.6.7 FAULT RIDE THROUGH

 **NOTE:** To configure these settings refer to the appropriate grid standard for paralleling with the mains.

 **NOTE:** The *Fault Ride Through* feature is used to prevent the Generator Bus being disconnected from the Mains when in parallel during a momentary Mains Failure. Care **MUST** be taken when configuring the *Fault Ride Through* feature as a prolonged time in parallel with a failed mains might cause a damage to the generators.

 **NOTE:** For details on how the *Fault Ride Through* function operates refer to DSE Publication: 057-259 DSE8660 MKII Operator Manual which is found on our website: www.deepseaelectronics.com.


The *Fault Ride Through* feature is useful to prevent Electrical Trips on voltage dips caused by the grid when the generator bus is running in parallel with the Mains. This feature is also applicable when generators are load sharing in island mode. The feature is to ignore the following alarms:

- *Under Voltage*
- *Over Voltage*
- *Under Frequency*
- *Over Frequency*
- *Mains Decoupling Voltage & Frequency Stage Alarms*
- *Voltage Symmetry*
- *Zero Sequence*
- *Negative Sequence*
- *Positive Sequence*
- *Phase Rotation*

The *Fault Ride Through* curve must be configured which is formed of a sequence of *Connection Point Voltages* which increase after consecutive time intervals. The *Fault Ride Through* curve allows to ignore the undervoltage alarms as long as the voltage dips are above the configured voltage levels defined by setpoints out of one, for the given times in seconds.

The *Fault Ride Through* event activates when the voltage on one or more of the generator phases falls below the *Urec3* level; and it is cleared when the *Trec4* timer expires and the voltage rises above the *Urec3* level.

The *Connection Point Voltages* are configured in *PU (Per Unit)* which represent the percentages of the *Mains Nominal Voltage*; (i.e. 0.30PU = 30%).
All the timers are configured in seconds.



Parameter	Description
Enable Fault Ride Through	<input type="checkbox"/> = <i>Fault Ride Through</i> is disabled when the mains is in parallel with the generators bus <input checked="" type="checkbox"/> = <i>Fault Ride Through</i> is enabled when the mains is in parallel with the generators bus
Enable In Island Mode	<input type="checkbox"/> = <i>Fault Ride Through</i> is disabled when the generators are running on the bus but they are not in parallel with the mains. <input checked="" type="checkbox"/> = <i>Fault Ride Through</i> is enabled when the generators are running on the bus but they are not in parallel with the mains.
Uret	When the <i>Fault Ride Through</i> event starts, the voltage must remain above this level to ignore the <i>Mains Low Voltage Alarm</i> .
Tclear	During the normal operation when the voltage drops below the Urec3 level this timer is started and the <i>Fault Ride Through</i> event is activated. After this time, the DSE module monitors the voltage to ensure it remains above the FRT curve to ignore the alarms. This timer ends at the next <i>Connection Point Voltage</i> (Uclear) of the curve.
Uclear	The next <i>Connection Point Voltage</i> level at the <i>Tclear</i> time, above which the voltage must be to ignore the <i>Mains Low Voltage Alarm</i> .
Trec1	The time in seconds that the <i>FRT</i> event is active for. The voltage must be raised above the <i>Urec1</i> level at this time.
Urec1	The next <i>Connection Point Voltage</i> level after the <i>Trec1</i> time, above which the dipped voltage must be to ignore the <i>Mains Low Voltage Alarm</i> .
Trec2	The time in seconds that the <i>FRT</i> event is active for. After this time, the voltage must be raised above the <i>Urec1</i> level to ignore the <i>Mains Low Voltage Alarm</i> .
Urec2	The next <i>Connection Point Voltage</i> level after the <i>Trec3</i> time, above which the voltage must be to ignore the <i>Mains Low Voltage Alarm</i> .
Trec3	The time in seconds that the <i>FRT</i> event is active for. At this time, the voltage must be raised above the <i>Urec2</i> level, but if the voltage is still below the <i>Urec2</i> , then the <i>Fault Ride Through</i> event terminates and the alarms are no longer ignored.

Parameters detailed overleaf...

Parameter	Description
Urec3	The next <i>Connection Point Voltage</i> level after the <i>Trec4</i> time, above which the voltage must be to terminate the <i>Fault Ride Through</i> event and activate the alarms.
Trec4	The time in seconds after which the DSE module monitors the voltage level to be raised above the <i>Urec3</i> to clear the <i>Fault Ride Through</i> event. After this time, all the alarms are active until another Fault Ride Through event occurs. At this point, if the voltage is still below the <i>Urec3</i> level, then the <i>Fault Ride Through</i> event remains active and the DSE module waits until the voltage is raised above the <i>Urec3</i> to clear the <i>Fault Ride Through</i> event.

Save / Load Curve

This feature is used to import the *Fault Ride Through* settings into another DSE module.

Parameter	Description
Save Curve	This allows saving the current configured settings of the <i>Fault Ride Through</i> into an FRT file.
Load Curve	This allows loading of previously configured settings of the <i>Fault Ride Through</i> saved in FRT format.


2.7 BUS

The *Bus* section is subdivided into smaller sections. Select the required section with the mouse.



2.7.1 BUS OPTIONS


AC System



This is 'read only' for information purposes. The AC system is configured in the *Mains Options* page.


Parameter	Description
AC System	<p>The AC System of the Bus is fixed to the same setting as the mains. These settings are used to detail the type of AC system to which the module is connected:</p> <p>2 Phase, 3 Wire L1 - L2 2 Phase, 3 Wire L1 - L3 3 Phase, 3 Wire 3 Phase, 3 Wire NVD 3 Phase, 4 Wire 3 Phase, 4 Wire Delta L1 - N - L2 3 Phase, 4 Wire Delta L1 - N - L3 3 Phase, 4 Wire Delta L2 - N - L3 Single Phase, 2 Wire Single Phase, 3 Wire L1 - L2 Single Phase, 3 Wire L1 - L3</p>
VT Fitted	<p><input type="checkbox"/> = The voltage sensing to the controller is direct from the Generator bus <input checked="" type="checkbox"/> = The voltage sensing to the controller is via Voltage Transformers (VTs or PTs)</p> <p>This is used to step down the generated voltage to be within the controller voltage specifications. By entering the <i>Primary</i> and <i>Secondary</i> voltages of the transformer, the controller displays the <i>Primary</i> voltage rather than the actual measured voltage.</p> <p>This is typically used to interface the DSE module to high voltage systems (i.e. 11kV)</p>

Breaker Control



Parameter	Description
Bus Breaker Not Fitted	<p>NOTE: This feature is only supported when a single DSExx60 unit is connected to the MSC link.</p> <p>NOTE: When there is no Bus breaker for the module to control, this option MUST be enabled on all modules connected to the MSC link.</p> <p>NOTE: When this feature is enabled, the <i>Immediate Mains Dropout</i> option is greyed out and forced to be enabled.</p> <p><input type="checkbox"/> = Normal operation. When the module ramps the Generator Bus down to zero power, the Bus switchgear opens and the Generator Bus continues running in load share mode until requested to stop.</p> <p><input checked="" type="checkbox"/> = When the module ramps the Generator Bus down to zero power, the Mains switchgear remains closed and the Generator Bus continues to run in base load mode with both kW and kvar levels fixed at 0% until requested to stop.</p> <p>Activation of an Electrical Trip alarm on the module triggers an immediate alarm on the DSExx10 MKII which is <i>Electrical Trip From 8660</i>.</p>
Enable Breaker Alarms	<p><input type="checkbox"/> = Alarm is disabled</p> <p><input checked="" type="checkbox"/> = The <i>Mains Breaker Alarms</i> are enabled.</p>
Fail To Open Delay	When the <i>Open Bus</i> output is activated, if the configured <i>Bus Closed Auxiliary</i> digital input does not become inactive within the <i>Bus Fail To Open Delay</i> timer, the alarm is activated
Fail To Close Delay	When the <i>Close Bus</i> output is activated, if the configured <i>Bus Closed Auxiliary</i> digital input does not become active within the <i>Bus Fail To Close Delay</i> timer, the alarm is activated


Phase Rotation



Parameter	Description
Phase Rotation IEEE 37.2 – 47 Phase Sequence Relay	All the <i>Bus Phase Rotation</i> settings are locked to the same configuration as the <i>Mains Phase Rotation</i> settings. This section is displayed for clarification purposes only.

2.7.2 BUS NOMINALS

Nominal Voltage




Nominal Voltage

Nominal Voltage V PhN

Parameter	Description
Nominal Voltage	This is used to instruct the module what voltage to adjust the Generator Bus to whilst running on load. It is also used when the Bus and Mains VTs have different ratios, to synchronise the voltage of both supplies.

Nominal Frequency



Nominal Frequency

Nominal Frequency Hz

Parameter	Description
Nominal Frequency	This is used to instruct the module what frequency to adjust the Generator Bus to whilst running on load.

2.7.3 BUS SEQUENCE ALARMS


Zero Sequence Alarm

Parameter	Description
Zero Sequence Alarm IEEE 37.2 – 47H Phase-Sequence Or Phase Balance Voltage Relay	<p>NOTE: The Zero Sequence Alarm must be set to a third of the required Neutral Voltage Displacement (NVD) value. This is because the summation of the three Zero Sequence vector components is equal to the NVD value.</p> <p>This is also known as Neutral Voltage Displacement.</p> <p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the difference in potential between the Earth and the calculated Neutral position of a 3 wire delta exceeds the configured <i>Zero Sequence Alarm Trip</i> level for the configured <i>Delay</i> time.</p>
Action	Select the type of alarm required from the list: Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Positive Sequence Alarm


Parameter	Description
Positive Sequence Alarm IEEE 37.2 – 47L Phase-Sequence Or Phase Balance Voltage Relay	<p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the <i>Positive Sequence</i> voltage falls below the configured <i>Positive Sequence Alarm Trip</i> level for the configured <i>Delay</i> time.</p>
Action	Select the type of alarm required from the list: Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Negative Sequence Alarm



Parameter	Description
Negative Sequence Alarm IEEE 37.2 – 47H Phase-Sequence Or Phase Balance Voltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the <i>Negative Sequence</i> voltage exceeds the configured <i>Negative Sequence Alarm</i> level for the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.


Asymmetry Alarm



Parameter	Description
Asymmetry Alarm IEEE 37.2 – 59 Overvoltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The alarm activates when the voltage between any two phases exceeds the configured <i>Asymmetry Alarm Trip</i> level for the configured <i>Delay</i> time. For example: L1 = 230 V, L2 = 235 V, L3 = 226V Asymmetry is <i>largest value – smallest value</i> = 235 V – 226 V = 9 V
Action	Select the type of alarm required from the list: Electrical Trip Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.


2.7.4 CHECK SYNC

Dead Bus



Parameter	Description
Voltage	The Bus is measured when it is to be synchronised with the mains. If the Bus is measured to be below the <i>Dead Bus Voltage</i> , the Bus is assumed to be 'dead' and the synchronising does not begin. If the Bus is measured to be above the <i>Dead Bus Voltage</i> , the module synchronises the Bus to the Mains before both breakers are closed.

Check Sync




During the synchronising process, the module sends commands down the MSC to the DSExx10 modules to adjust their generators frequency and voltage of the to closely match the mains. Typically the oncoming Bus is adjusted to be 0.1 Hz faster than the Mains supply, this causes the phase of the two supplies to change continuously.

Before the breaker is closed, the following configurable conditions must be met.

Parameter	Description
Low Frequency	The difference between the two supplies frequencies must be between the <i>Check Sync Low Frequency</i> and <i>Check Sync High Frequency</i>
High Frequency	
Voltage	The difference between the two supplies voltages must be equal to or below the <i>Check Sync Voltage</i>
Phase Angle	The phase of the two supplies must be equal to or below the <i>Check Sync Phase Angle</i>

Fail to Sync Alarm



Used to detect that the synchronising process is taking a long time. This occurs when changes in the load are making the Generator Bus difficult to control due to changes in its voltage and frequency.

Parameter	Description
Action	Determines the action to take upon a <i>Fail to Sync</i> . Electrical Trip: The Bus breaker opens and the start request to the Generator Bus is removed. Indication: The Generator Bus continues to attempt to synchronise and no alarm is raised. This is for internal use, such as in the <i>PLC Logic</i> or <i>Virtual LEDs</i> . Warning: The Generator Bus continues to attempt to synchronise.
Delay	The time to allow for successful synchronisation to take place. If the process continue longer than <i>Delay</i> , the <i>Action</i> above is taken.

2.7.5 MULTISSET







MSC Link

NOTE: The MSC Link Alarms are disabled by a digital input configured to *MSC Alarms Inhibit* if required.

NOTE: When the MSC2 (*Redundant MSC Link*) is enabled but the MSC1 is not wired, the DSE module issues an *MSC Alarm* preventing communication over the MSC2.

Parameter	Description
MSC Failure Action	Action upon MSC Link Failure: Electrical Trip: The Bus breaker is opened immediately and the stopping sequence is initiated. Indication: The Generator Bus continues to run and no alarm is raised. This is used for internal use, such as in the <i>PLC Logic</i> or <i>Virtual LEDs</i> . Warning: The Generator Bus continues to run and a warning alarm is activated.
MSC Alarms Disabled Action	Action to take when the MSC alarm is disabled by a digital input: Indication: The Generator Bus continues to run and no alarm is raised. This is used for internal use, such as in the <i>PLC Logic</i> or <i>Virtual LEDs</i> . None: Alarm is disabled. Warning: The Generator Bus continues to run and a warning alarm is activated.
Too Few Modules Action	Action to take when the number of modules active on the MSC link is lower than the <i>Minimum Modules on MSC link</i> setting Electrical Trip: The Bus breaker is opened immediately and the stopping sequence is initiated. Indication: The Generator Bus continues to run and no alarm is raised. This is used for internal use, such as in the <i>PLC Logic</i> or <i>Virtual LEDs</i> . None: Alarm is disabled. Warning: The Generator Bus continues to run and a warning alarm is activated.
Minimum Modules On MSC Link	Set the minimum number of modules on the MSC before the <i>Too Few Modules</i> alarm is activated.


Parameters continued overleaf...

Parameter	Description
MSC Compatibility	<p> NOTE: MSC compatibility on this module is not supported with DSE5560 and DSE7560 modules.</p> <p><input type="checkbox"/> = The module is not able to communicate with DSE5510 and DSE7510 modules on the MSC Link <input checked="" type="checkbox"/> = Communication with DSE5510 and DSE7510 series modules is possible. The maximum number of DSExx10 controllers is reduced to 16 and the maximum number of DSExx60 controllers is reduced to 8.</p>
Enable Redundant MSC Link	<p> NOTE: When required, this option must be enabled on all DSE8xxx MKII modules connected on the MSC Link.</p> <p> NOTE: When the <i>Redundant MSC Link</i> is enabled, the <i>PLC MSC Data</i> is no longer available.</p> <p><input type="checkbox"/> = Only one Multi-Set Comms (MSC) Link is active. <input checked="" type="checkbox"/> = This activates the second (redundant) Multi-Set Comms (MSC) Link, allowing for communications redundancy between the controllers.</p>
Disable Auto ID Allocation	<p> NOTE: When required, this option must be enabled on all DSE8xxx MKII modules connected on the MSC Link.</p> <p><input type="checkbox"/> = The MSC system assigns the MSC ID automatically when the DSE module is powered over the MSC network. <input checked="" type="checkbox"/> = The MSC system does not assign the MSC ID automatically when the DSE module is powered up, instead the DSE module uses the <i>MSC ID</i> number configured in this section.</p>
MSC Custom Data Enable	<p> NOTE: It is not possible to Write a configuration file to the module if the <i>Redundant MSC Link</i> is enabled and <i>PLC MSC Data</i> is being transmitted over the MSC.</p> <p> NOTE: For details on how to configure the <i>PLC MSC Data</i>, refer to DSE Publication: <i>057-314 Advanced PLC Software Manual</i> which is found on our website: www.deepseaelectronics.com</p> <p><input type="checkbox"/> = The <i>MSC Custom Data</i> is disabled and there are no <i>PLC MSC</i> items transmitted over the MSC Link <input checked="" type="checkbox"/> = The <i>MSC Custom Data</i> is enabled, and the <i>PLC MSC Data</i> is transmitted on the MSC Link.</p>
MSC Custom Data Transmission Rate	<p>This option is available when the <i>MSC Custom Data</i> is enabled. Select the rate at which the <i>PLC MSC Data</i> is transmitted over the MSC Link.</p>

New Load Demand Scheme


NOTE: The V6 software MSC is not compatible with the previous module versions. For more information contact DSE Technical Support support@deepseaelectronics.com

NOTE: The *Load Demand Scheme* settings in the DSExx60 (excluding *Starting Options*) is only applicable when the module is configured for *Mains Mode* and the Generator Bus is in parallel with the Mains. For all other scenarios (such as a Mains Failure), the load demand scheme in the DSExx10 is used.



Parameter	Description
Compatibility	<p>Select the required <i>Load Demand Scheme</i> compatibility. This is useful when adding a new module to an existing DSE86xx system without the need to upgrade the existing controllers' software version.</p> <p>86xx current: <i>Load Demand Scheme</i> compatible with module versions 6 or later.</p> <p>86xx up to v5.1: <i>Load Demand Scheme</i> compatible with module versions 1 up to 5.1</p> <p>Disabled: The <i>Load Demand Scheme</i> is disabled.</p>
Starting Options	<p>NOTE: When <i>Start All Set Initially</i> is selected, the DSExx10s only start and stop based on the <i>Load Demand Scheme</i> once the Generator Bus switchgear has closed.</p> <p>Determines how the load demand scheme operates upon start-up.</p> <p>Start all sets initially: Upon activation of the load demand scheme, all generators in the system start up and parallel onto the Generator Bus. This option is particularly recommended in Multiset Mains standby applications where the load is likely to be greater than the capacity of a single generator.</p> <p>Start sets as load requires: Upon activation of the load demand scheme, only one Generator will start initially. Other generators in the system are only started according to demand. This option is recommended for mutual standby systems where the load is likely to be less than the capacity of a single generator.</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Load/Start Next Set on Warning	<p> NOTE: Enabling <i>Start Next Set on Warning</i> results with the <i>All Warnings are Latched</i> option being forced on.</p> <p>Whenever a warning occurs, a start/load command is issued over the MSC link to start the next highest priority generator. The Generator with the warning stops once the next highest priority Generator has joined the bus</p>
Allow Set to Start with Warning	<p><input type="checkbox"/> = If the MSC calls to start another generator, generators which display a warning status alarm remain at rest, only generators with no warning alarm are started according to their priority number.</p> <p><input checked="" type="checkbox"/> = Allows a stationary Generator with a warning alarm to start if requested.</p>
Balance Engine Hours	<p>Used in a Multiset system so that the engine's priority changes according to the amount of usage of the generator.</p> <p>For instance, in a two Generator system.</p> <p>Generator 1 has logged 100 running hours Generator 2 has logged 20 running hours Balance engine hours are configured to 75 hours.</p> <p>Generator 2 has logged 80 hours less than Generator 1. As this is greater than the configured 75 hours, Generator 2 is the highest priority set.</p> <p>If all generators are within the configured Balance Engine Hours value, then the set Priority Number (See SCADA Maintenance page) is followed.</p>
Load Demand Delay	<p>After closing into parallel, the Generator is kept running for the period of the <i>Load Demand Delay</i> time before joining the <i>Load Demand Scheme</i>.</p>
Calling For Less Sets	<p>The kW load level at which the module decides that Generator is disconnected from the Generator Bus. The Generator does not disconnect from the Bus when its percentage of kW is below the <i>Calling For Less Sets</i> value. Instead, the Generator disconnects from the Bus when it ensures that the remaining generators' kW percentage is at the <i>Calling For Less Sets</i> value when it disconnects. This prevents the system from reaching a point where the load is such that the Generator starts and stops repeatedly.</p> <p>Once the load is below this level, the lowest priority Generator in the sequence (determined using the <i>Genset Priority</i>) begins its <i>Return Delay</i> timer. Once this has expired, the Generator ramps off and stops.</p> <p>If the load level rises above this set point during the <i>Return Delay</i> timer, the timer is cancelled and the Generator continues to supply power to the load. This caters for short term reductions in kW load demand.</p>

Parameter descriptions are continued overleaf...

Editing the Configuration

Parameter	Description
Calling For More Sets	<p>The kW load level at which the module calls for additional generators to join the Generator Bus.</p> <p>Once the load is above this level, the highest priority Generator that is not running in the sequence (determined using the <i>Genset Priority</i>) begins its <i>Start Delay</i> timer. Once this has expired, the Generator joins the Bus and ramps up.</p> <p>If the load level reduces below this set point during the <i>Start Delay</i> timer, the timer is cancelled and the Generator enters its stops cycle. This caters for short term kW load demand.</p> <p>If the Generator fails to become available, it communicates this using the MSC Link which signals the next Generator in the sequence to take its place.</p>
Minimum Sets to Run	<p>The minimum number of generators that have to remain on the bus regardless of the load level and the <i>Calling For Less Sets</i> value.</p> <p>The MSC system selects the highest priority number Gensets to remain on the bus.</p>

2.7.6 LOAD CONTROL


NOTE: The *Maximum Load Level* are configured within the SCADA section. For further details, refer to section entitled *Load Levels* contained within the SCADA section elsewhere within this document.

NOTE: The ramping procedure changes depending upon the *Alternative Ramping Scheme* setting. For further details, refer section entitled *Advanced* elsewhere within this document.

The module performs a 'soft' load transfer when taking or removing load from the Generator Bus.

Upon the generator bus's switchgear closing, the module controls the Generator Bus's power production starting from the zero. Load is then applied to the Generator Bus at the configured *Ramp Up Rate*. The ramping continues until Generator Bus is producing the power to the load, or to the *Maximum Load Level* when running in *Bus Mode*.

Before the Generator Bus is disconnected, the load is ramped down to the zero at the configured *Ramp Down Rate*. The Generator Bus's switchgear is opened once zero power has been attained, removing the Generator Bus from the load.





'Soft' load transfers of this type have many benefits, the most obvious are:


- When the Generator Bus is removed, the generators in the system are not suddenly unloaded with the load that was being supplied. Instead, the load is slowly ramped, allowing time for the Mains to take up the load.
- Opening of the switchgear occurs at a low load level, helping to reduce arcing of the contacts.

Load Share Ramp

Load Share Ramp


Ramp Up Rate % 


Ramp Down Rate % 


Ramp Off Load 20s 


Parameter	Description
Ramp Up Rate	The rate at which the Generator Bus is ramped onto the load.
Ramp Down Rate	The rate at which the Generator Bus is ramped off the load
Ramp Off Load	<p>This is to set a time limit to the ramp down process, and it is useful when the engines responses are slow or are not capable to ramp off the load.</p> <p>The <i>Ramp Off Load</i> timer starts when the Generator Bus begins to ramp down. When this timer is expired the Bus breaker opens regardless of the actual power on the Bus.</p> <p>It is possible to set the ramp rate slower then this time, so the bus breaker opens prior to the ramp finishes.</p>

2.7.7 POWER CONTROL

 **NOTE:** The *Power Control* modes and *Voltage and Reactive Power Control* modes are to be used in conjunction with the following documents:
- COMMISSION REGULATION (EU) 2016/631 of 14 April 2016 establishing a network code on requirements for grid connection of generators
- P1547 - IEEE Draft Standard for Interconnection and Interoperability of Distributed Energy Resources with Associated Electric Power Systems Interfaces

 **NOTE:** The *Simulation Injection Testing* tool of the DSE Configuration Suite PC Software allows testing the generator's frequency response and check its performance for the *Power Control* curves. For details on how to test the *Simulation Injection* on the DSE8x10 module refer to DSE Publication: 056-123 Simulation Injection Testing document.

 **NOTE:** The *Power Control* parameters only have effect when the module is configured for *Bus Mode* which instructs the module to operate in fixed export mode when in parallel with the Mains supply. For more information on this application, refer to section entitled *Load Levels* elsewhere within this document.

 **NOTE:** Activation of the different *Power Control* modes is done through digital inputs, PLC functions, Front Panel Editor or Modbus; with digital inputs having higher priority over PLC functions, and PLC functions have higher priority over Front Panel Editor and ModBus commands.

 **NOTE:** Simultaneously activating different *Power Control* modes, results in the lowest number taking priority.

Contact Power Mode (Default)


Constant Power Mode (Default)

No additional settings are required

This is the default mode of exporting power to the Mains (utility); where the module holds the amount of power produced by the Generator Bus at a constant level. The amount of power produced by the Generator Bus is irrespective of the load level or any other parameter.

The amount of power produced is defined as *Maximum kW Level* and is set in SCADA/Generator/Load Levels section, through the Front Panel Running Editor, in PLC Functions, or via ModBus messages.

Frequency-Power Mode



In this mode of exporting power to the Mains (utility); the module varies the amount of power produced by the Generator Bus with regards to the Control Curve depending on the measured frequency.

This mode allows the Generator Bus to support the Mains (utility) frequency stability by monitoring the frequency and changing the amount of power produced.

Parameter	Description
Frequency Rolling Average	The measured frequency is averaged over the period of the <i>Frequency Rolling Average</i> . The average frequency is used in the <i>Control Curve</i> to determine the required level of power production.
Control Curve	<p>The <i>Control Curve</i> determines, based on the average frequency, the amount of power the Generator produces. This amount of power is a percentage of the <i>kW Maximum Load Level</i> set within the SCADA section.</p> <p>Select the <i>Control Curve</i> from a pre-defined list or create a user-defined curve</p> <p>RfG GB LFSM_O: Requirements for Generators Network Code in Great Britain, Limited Frequency Sensitive Mode Over frequency</p> <p>RfG GB LFSM_U: Requirements for Generators Network Code in Great Britain, Limited Frequency Sensitive Mode Under frequency</p> <p>RfG GB LFSM_U and LFSM_O: Requirements for Generators Network Code in Great Britain, Limited Frequency Sensitive Mode Under frequency and Over frequency</p> <p>RfG GB FSM 5%: Requirements for Generators Network Code in Great Britain, Frequency Sensitive Mode at 5%</p> <p>P1547 60Hz 50%: Requirements for Generators in United States, Frequency Sensitive Mode at 50%</p> <p>P1547 60Hz 75%: Requirements for Generators in United States, Frequency Sensitive Mode at 75%</p> <p>P1547 60Hz 90%: Requirements for Generators in United States, Frequency Sensitive Mode at 90%</p>

Voltage-Power Mode




In this mode of exporting power to the Mains (utility); the module varies the amount of power produced by the Generator Bus with regards to the Control Curve depending on the measured voltage.

This mode allows the Generator Bus to support the Mains (utility) voltage stability by monitoring the voltage and changing the amount of power produced.

Parameter	Description
Voltage Rolling Average	The measured voltage is averaged over the period of the <i>Voltage Rolling Average</i> . The average voltage is used in the <i>Control Curve</i> to determine the required level of power production.
Control Curve	The <i>Control Curve</i> determines, based on the average voltage, the amount of power the Generator Bus produces. This amount of power is a percentage of the <i>kW Maximum Load Level</i> . Select the <i>Control Curve</i> from a pre-defined list or create a user-defined curve <i>Power Against Voltage</i>

Power Ramp on Setpoint Change



Parameter	Description
Ramp Rate	When changing between <i>Power Control</i> modes or changing the set point, the <i>Ramp Rate</i> defines how fast the output power changes in percentage points per second.

2.7.7.1 CREATING / EDITING THE POWER MODE CURVE

While the *DSE Configuration Suite* holds most commonly used droop curves, occasionally it is required that the module's droop function be configured for a specification application not listed by the *DSE Configuration Suite*. To aid this process, a droop curve editor is provided.

The curve that is to be used or edited.

Click to edit the curve or create a curve if a curve is not selected.

Click and drag the points on the graphs to change the settings

Use the mouse to select the graph point, then enter the value in the box or click up/down to change the value

Double click the left mouse button to add a point or right click on a point to remove it.

Click *Interpolate* then select two points as prompted to draw a straight line between

Click to change the range of the X and Y Axes of the graph and the level of open circuit

Click **SAVE AS**, a prompt to name the curve...

Click OK to accept the changes or **CANCEL** to ignore and lose the changes.

Click OK to save the curve.

Any saved curves become selectable in the *Input Type* selection list.

Hint: Deleting, renaming or editing custom sensor curves that have been added is performed in the main menu, select *Tools | Curve Manager*.

2.7.8 VOLTAGE AND REACTIVE POWER CONTROL

NOTE: The *Power Control* modes and *Voltage and Reactive Power Control* modes are to be used in conjunction with the following documents:
 - COMMISSION REGULATION (EU) 2016/631 of 14 April 2016 establishing a network code on requirements for grid connection of generators
 - P1547 - IEEE Draft Standard for Interconnection and Interoperability of Distributed Energy Resources with Associated Electric Power Systems Interfaces

NOTE: The *Simulation Injection Testing* tool of the DSE Configuration Suite PC Software allows testing the generator's voltage response and check its performance for the *Voltage & Reactive Power Control* curves. For details on how to test the *Simulation Injection* on the DSE8x10 module refer to DSE Publication: 056-123 Simulation Injection Testing document.

NOTE: The *Voltage and Reactive Power Control* parameters only have effect when the module is configured for *Bus Mode* which instructs the module to operate in fixed export mode when in parallel with the Mains supply. For more information on this application, refer to section entitled *Load Levels* elsewhere within this document.

NOTE: Activation of the different *Voltage and Reactive Power Control* modes is done through digital inputs, PLC functions, Front Panel Editor or Modbus; with digital inputs having higher priority over PLC functions, and PLC functions have higher priority over Front Panel Editor and ModBus commands.

NOTE: Simultaneously activating different *Voltage and Reactive Power Control* modes, results in the lowest number taking priority.

Constant Power Factor Mode

Constant Power Factor Mode

Limit Power Factor

Leading Power Factor Limit pf

Lagging Power Factor Limit pf

Power Rolling Average 1.0s

-0.95pf 0.85pf

Leading P.F Lagging P.F

In this mode of exporting power to the Mains (utility); the module varies the amount of reactive power produced by the Generator Bus with regards to maintaining the required power factor. This mode allows the Generator Bus to maintain a constant export power factor if so required. The required power factor is set in SCADA/Generator/Load Levels section, through the Front Panel Running Editor, PLC Functions, or ModBus messages.

Parameters described overleaf...

Parameter	Description
Limit Power Factor	<input type="checkbox"/> = The Generator Bus produces power beyond the power factor limits. Regardless of this setting, the generators do not produce more than their rated kvar. <input checked="" type="checkbox"/> = The Generator Bus produces power within its specified power factor limits
Leading Power Factor Limit	The limit for Generator bus's leading power factor.
Lagging Power Factor Limit	The limit for Generator bus's lagging power factor.
Power Rolling Average	The exported power is averaged over the period of the <i>Power Rolling Average</i> . The average power is then used to determine the required reactive power production to achieve the set power factor.

Voltage-Reactive Power Mode

Voltage-Reactive Power Mode

Limit Power Factor

Leading Power Factor Limit pf

Lagging Power Factor Limit pf

Power Rolling Average 1.0s

Voltage Rolling Average 1.0s


Control Curve Reactive Power Against Voltage

In this mode of exporting power to the Mains (utility); the module varies the amount of reactive power produced by the Generator Bus with regards to the Control Curve depending on the measured voltage.

This mode allows the Generator Bus to support the Mains (utility) voltage stability by monitoring the voltage and changing the amount of reactive power produced.

Parameter	Description
Limit Power Factor	<input type="checkbox"/> = The Generator Bus produces power beyond the power factor limits. Regardless of this setting, the generators do not produce more than their rated kvar. <input checked="" type="checkbox"/> = The Generator Bus produces power within its specified power factor limits.
Leading Power Factor Limit	The limit for Generator bus's leading power factor.
Lagging Power Factor Limit	The limit for Generator bus's lagging power factor.
Power Rolling Average	The exported power is averaged over the period of the <i>Power Rolling Average</i> . The average power is used to calculate the power factor if the option <i>Limit Power Factor</i> is enabled.
Voltage Rolling Average	The measured voltage is averaged over the period of the <i>Voltage Rolling Average</i> . The average voltage is used in the <i>Control Curve</i> to determine the required level of reactive power production.
Control Curve	The <i>Control Curve</i> determines, based on the average voltage, the amount of reactive power the Generator Bus produces. This amount of power is a percentage of the <i>kvar Maximum Load Level</i> . Select the <i>Control Curve</i> from a pre-defined list or create a user-defined curve <i>Reactive Power Against Voltage</i>


Power-Power Factor Mode



In this mode of exporting power to the Mains (utility); the module varies the amount of reactive power produced by the Generator Bus with regards to maintaining the required power factor. This power factor is derived from the averaged power using the *Control Curve*. This mode allows the Generator Bus to support the Mains (utility) stability by varying the power factor depending on the export power.

Parameter	Description
Power Rolling Average	The exported power is averaged over the period of the <i>Power Rolling Average</i> . The average is then used in the <i>Control Curve</i> to determine the required power factor.
Control Curve	The <i>Control Curve</i> determines, based on the average power, the power factor that is required. Select the <i>Control Curve</i> from a pre-defined list or create a user-defined curve Power Factor Against Power


Constant Reactive Power Mode (Default)



This is the default mode of exporting power to the Mains (utility); where the module holds the amount of reactive power produced by the Generator Bus at a constant level. The amount of reactive power produced by the Generator Bus is irrespective of the load level or any other parameter. The amount of reactive power produced is defined as *Maximum kvar Level* and is set in SCADA/Generator/Load Levels section, through the Front Panel Running Editor, in PLC Functions, or via ModBus messages.

Parameter	Description
Limit Power Factor to Generator Rating	<input type="checkbox"/> = The Generator Bus produces power beyond the power factor limits. Regardless of this setting, the generators do not produce more than their rated kvar. <input checked="" type="checkbox"/> = The Generator Bus produces power within its specified power factor limits.


Reactive Power Ramp on Setpoint Change



Parameter	Description
Ramp Rate	When changing between <i>Voltage and Reactive Power Control</i> modes or changing the set point, the <i>Ramp Rate</i> defines how fast the output reactive power changes in percentage points per second.


2.8 SYSTEM

The *System* section is subdivided into smaller sections. Select the required section with the mouse.



2.8.1 SYSTEM OPTIONS

Minimum Number of Sets Not Reach



Parameter	Description
Action	Select the type of alarm required from the list: Electrical Trip Latched Indication Warning Always Latched For details of these, see the section entitled Alarm Types elsewhere in this document.
Minimum Number of Sets	The minimum number of generators that must be closed onto the Bus before the Bus breaker is closed after a start request is given via the MSC link. This is to ensure there is enough Generator capacity to supply the load. If the minimum number of generators closed onto the Bus is not met within the configured <i>Delay</i> time, the alarm <i>Minimum Number of Sets Not Reached</i> activates with the configured <i>Action</i> . Once the Bus breaker has closed, the <i>Minimum Number of Sets</i> is no longer acted upon and the generators turn off if not required.
Set Count	Reserved: For the DSE8x60 module to close its bus breaker, it must first be able to reserve the <i>Minimum Number of Sets</i> (generators closed on the bus) which are not reserved by another DSE8x60 in the system. If there are not enough generators on the bus, the DSE8x60 calls for additional generators to start. This is used to ensure there is enough generation capacity reserved to accept the load step once the bus breaker is closed. Total On Bus: For the DSE8x60 module to close its bus breaker, it must first be able to see the <i>Minimum Number of Sets</i> (generators closed on the bus) regardless if they are reserved by another DSE8x60 in the system. If there are not enough unreserved generators on the bus, the DSE8x60 calls for additional generators to start.

Insufficient Capacity

The screenshot shows a configuration window titled "Insufficient Capacity". It contains two rows of controls. The first row has a label "Action" and a dropdown menu currently showing "Warning". The second row has a label "Delay" and a text field containing "1s". To the right of these fields is a horizontal slider control with a green indicator.

Parameter	Description
Action	<p>Activates when the module is operating in <i>Mains Mode</i> (Peak Lopping/Shaving) and the Generator Bus is producing 100 % of its rated kW for the configured <i>Delay</i> timer.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p><i>Electrical Trip</i> <i>Indication</i> <i>None</i> <i>Warning</i></p>

Load CT


NOTE: For more information on the Load CT, refer to DSE Publication: *056-007 Advantages of Load CT* which is found on our website: www.deepseaelectronics.com

The load CT is only required when there is more than one DSExx60 module connected on the MSC link.

With the load CT fitted, the module transfers the right amount of load back to the Mains before disconnecting the Generator Bus. This prevents the Generator Bus being 'shock loaded'.

Without the load C.T., the module does not know how much load to transfer to the Mains when other DSExx60 modules are also running in island mode. This results in the module transferring a pre-determined amount of load before disconnecting the Generator Bus from the mains. This amount is configured by the *Min Mains Power to Open Bus* setting.


Hence, there is either too much load, or not enough load transferred, and the Generator Bus is 'shock loaded' as it is disconnected from the mains.



Parameter	Description
Load CT Enable	<p><input type="checkbox"/> = The Load CT is disabled and the <i>Min Mains Power to Open Bus</i> is enabled.</p> <p><input checked="" type="checkbox"/> = The Load CT enabled and the <i>Min Mains Power to Open Bus</i> is disabled. There is only one CT for measuring/calculating load current and it must be fitted on L1. The system assumes a balanced kW & kvar load on all phases, mirroring the values seen on L1.</p>
CT Primary	Primary rating of the Current Transformer
CT Secondary	Secondary rating of the Current Transformer
CT Voltage	<p>The supply voltage used to multiply with the load current to calculate the load kW and kvar. This is useful when the system has different voltages for the Bus and Mains sensing.</p> <p>Bus: The Load CT is at the same potential as the Bus sensing.</p> <p>Mains: The Load CT is at the same potential as the Mains sensing.</p>
CT Location	<p>NOTE: For more information on the Load CT location, refer to DSE Publication: <i>057-259 DSE8660 MKII Operator Manual</i> which is found on our website: www.deepseaelectronics.com</p> <p>The location where the L1 'Load CT' is situated:</p> <p>Bus: The 'Load CT' is situated on the L1 feed from the Generator Bus. The load current and power is calculated.</p> <p>Load: The 'Load CT' is situated on the common L1 feed to the load. The load current and power is measured.</p>
Min Mains Power to Open Bus	<p>NOTE: This parameter is only available when the Load CT is not enabled.</p> <p>The amount of Mains power at which the Generator Bus breaker opens when the Generator Bus is ramping down.</p>

2.8.2 PLANT BATTERY


Voltage Alarms



Parameter	Description
Plant Battery Under Voltage IEEE 37.2 -27 DC Undervoltage Relay	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the battery voltage drops below the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage rises above the configured <i>Return</i> level, the alarm is deactivated.
Plant Battery Over Voltage IEEE 37.2 -59 DC Overvoltage Relay	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the battery voltage rises above the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage drops below the configured <i>Return</i> level, the alarm is deactivated.


2.9 COMMUNICATIONS

The *Communications* page is subdivided into smaller sections. Select the required section with the mouse.



2.9.1 COMMUNICATIONS OPTIONS


Provides a means of giving the controller an identity. This is used in the SCADA section to allow the operator to see the site name and site identity that it is currently connected to.



Parameter	Description
Site Identity	A free entry boxes to allow the user to give the DSE module a description of where the site is located. This text is not shown on the module's display and is only seen when performing remote communication. This aids the user in knowing where the site is located.
Genset Identity	A free entry boxes to allow the user to give the DSE module a description of which transfer switch it is connected to. This text is not shown on the module's display and is only seen when performing remote communication. This aids the user in knowing which transfer switch on a specific site is being monitored.

2.9.2 RS232 PORT

The *RS232 Port* page is subdivided into smaller sections. Select the required section with the mouse.




2.9.2.1 BASIC

Serial Port Configuration

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network is required, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

NOTE: When the *RS232 Port Usage* is configured to "PLC Comms", the transmitting module's *Port Usage* must be configured to "Gencomm". This allows the module configured as "PLC Comms" act as a master and read from the module configured to "Gencomm". Every device on the RS232 link must have an individual *Slave ID*. For details on how to configure the *PLC Editor* to read via its RS232, refer to DSE Publication: *057-314 Advanced PLC Software Manual* which is found on our website: www.deepseaelectronics.com



Parameter	Description
Slave ID	Select the Slave ID of the DSE module's RS232 port.
Baud Rate	Select the Baud Rate (speed of communication) of the DSE module's RS232 port. Every device on the RS232 link must have the same Baud Rate. 1200 2400 4800 9600 14400 19200 28800 38400 57600 115200
Port Usage	<p>NOTE: In a system for a <i>PLC Comms</i> application, only one DSE module must be configured to act as the PLC master. For further details and instructions on using <i>the PLC Comms</i>, refer to DSE Publication: <i>057-314 Advanced PLC Software Manual</i> which is found on our website: www.deepseaelectronics.com</p> <p>No Modem: RS232 ports is used for direct RS232 connection to PLC, BMS etc Incoming Modem Calls: RS232 port connected to modem, used to accept incoming calls from a PC only. Incoming And Outgoing Modem (Sequence): RS232 port connected to modem used to accept incoming calls from a PC and also make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module attempts to call that number for the configured number of <i>Retries</i>, before it carries on to the next number.</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Port Usage	<p>Incoming And Outgoing Modem (Cyclic): RS232 port connected to modem used to accept incoming calls from a PC and also make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module completes the cycle and re-attempts to call those numbers for the configured number of <i>Retries</i>.</p> <p>Outgoing Modem Alarms (Sequence): RS232 port connected to modem, used to make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module attempts to call that number for the configured number of <i>Retries</i>, before it carries on to the next number.</p> <p>Outgoing Modem Alarms (Cyclic): RS232 port connected to modem, used to make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module completes the cycle and re-attempts to call those numbers for the configured number of <i>Retries</i>.</p> <p>PLC Comms: RS232 port is used to read the connected controller's registers over the RS232 which are defined in the <i>PLC Editor</i>.</p>

Modem Settings

NOTE: Connecting a modem directly to the module's RS232 is for legacy support only. When a new installation requires remote communication using the cellular network is required, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

Parameter	Description
Alarm Number	The phone number that the module dials upon an event. This number must be connected to a PC modem on a PC running the DSE Configuration Suite Software. Leave this field empty when dial-out to a PC is not required.
GSM Modem	<input type="checkbox"/> = The connected modem is a fixed line telephone modem <input checked="" type="checkbox"/> = The connected modem is a GSM (cellular) modem. The GSM signal strength meter and GSM operator are shown on the module display.
SMS Message Centre Number	The Message centre used to send SMS messages. This number is obtained from the GSM operator.
SMS Recipient Numbers	Numbers of the cell phones to send SMS messages to. Leave blank if SMS function is not required.

2.9.2.2 ADVANCED

NOTE: Connecting a modem directly to the module's RS232 is for legacy support only. When a new installation requires remote communication using the cellular network is required, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

Initialisation Strings

Initialisation Strings	
Init (not auto answer)	E0S7=60S0=0&S0&C1&D3
Init (auto answer)	E0S7=60S0=2&S0&C1&D3
Hangup	H0

The initialisation strings are commands that are sent to the modem upon powering up the DSE module and additionally at regular intervals subsequently, whenever the DSE module *initialises* (resets) the modem.

Factory Set Initialisation Strings

Parameter	Description
E0	Echo off
S7=60	Wait for carrier time 60s
S0=0 (not auto answer)	Do not answer
S0=2 (auto answer)	Answer after two rings
&S0	DSR always on
&C1	DCD is active if modem is online
&D3	Reset (ATZ) on DTR-drop
H0	Hang up (disconnect)

Silent Operation

The modem connected to the DSE controller usually makes dialling noises and 'squeal' in the initial stages of making a data call. To control this noise, add the following command to the end of the initialisation string:

Parameter	Description
M0	Silent operation
M1	Sounds during the initial stages of making a data call
M2	Sounds always when connected (not recommended for troubleshooting)

Sierra/Wavecom Fastrak Supreme GSM Modem Initialisation Strings

When connected to the Wavecom Fastrak Supreme GSM modem, the initialisation strings must be altered by changing the factory set &D3 to &D2.

Initialisation Strings	
Init (not auto answer)	E057=6050=0&S0&C1&D2
Init (auto answer)	E057=6050=2&S0&C1&D2
Hangup	H0

Parameter	Description
&D2 (required for Sierra / Wavecom Fastrak Supreme)	Hang up on DTR-drop
&D3 (DSE module factory settings)	Reset on DTR-drop

Other Modems

When using modems not recommended by DSE, first try either of the options shown above. If problems are still encountered, contact your modem supplier for further advice.


Connection Settings

Connection Settings	
Master inactivity timeout	5s
Connect delay	60s
Retries	4
Retry delay	5s
Repeat cycle delay	10s
Inter-frame delay	0 ms

Parameter	Description
Master Inactivity Timeout	The module monitors by default the USB port for communications. When activity is detected on the RS232 port, the module monitors the port for further data. If no data activity is detected on the port for the duration of the <i>Master Inactivity Timer</i> , it reverts to looking at the USB port. This needs to be set longer than the time between ModBus polls from the master.
Connect Delay	The amount of time that is allowed to elapse between the alarm being registered and the controller dialling out with the fault.
Retries	The number of times the module attempts to contact the remote PC by modem.
Retry Delay	The amount of time between retries
Repeat Cycle Delay	The amount of time between the cycle repeats when dialling out calls to multiple <i>Alarm Numbers</i> fails.
Inter-frame Delay	Set the time delay between the DSE module receiving a MODBUS RTU request and the DSE module's response.

2.9.2.3 SMS CONTROL

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network is required, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.



Parameter	Description
Require PIN	<p><input type="checkbox"/> = A control code sent by SMS does not require a PIN code entered before the code.</p> <p><input checked="" type="checkbox"/> = For security, the configured <i>PIN Prefix</i> must be entered in the SMS prior to the control code.</p>
Start Off Load (Code 1)	<p><input type="checkbox"/> = Sending code 1 to the module via SMS does not issue a <i>Start Off Load</i> command.</p> <p><input checked="" type="checkbox"/> = When in Auto mode, the module performs the start sequence but the Generator Bus is not instructed to take the load when code 1 is sent via SMS. This function is used where the Generator Bus only run is required e.g. for exercise.</p>
Start In Parallel (Code 2)	<p><input type="checkbox"/> = Sending code 2 to the module via SMS does not issue a <i>Start On Load</i> command.</p> <p><input checked="" type="checkbox"/> = When in auto mode, the module performs the start sequence and places the Generator Bus in long term parallel when code 2 is sent via SMS.</p>
Cancel (Code 3)	<p><input type="checkbox"/> = Sending code 3 to the module via SMS does not issue a cancel the start command issued by code 1 or 2.</p> <p><input checked="" type="checkbox"/> = Sending code 3 to the module via SMS cancels the start command issued by code 1 or 2.</p>
Stop Mode (Code 4)	<p><input type="checkbox"/> = Sending code 4 to the module via SMS does not issue place the unit into its <i>Stop Mode</i>.</p> <p><input checked="" type="checkbox"/> = Sending code 4 to the module via SMS mimics the operation of the 'Stop' button and is used to provide a remote SMS stop command.</p>
Auto Mode (Code 5)	<p><input type="checkbox"/> = Sending code 5 to the module via SMS does not issue place the unit into its <i>Auto Mode</i>.</p> <p><input checked="" type="checkbox"/> = Sending code 5 to the module via SMS mimics the operation of the Auto button.</p>
Start in Island Mode (Code 6)	<p><input type="checkbox"/> = Sending code 2 to the module via SMS does not issue a <i>Start in Island</i> command.</p> <p><input checked="" type="checkbox"/> = When in auto mode, the module performs the start sequence and transfers all the load to the Generator Bus and disconnects the mains, when code 2 is sent via SMS.</p>

2.9.2.4 TROUBLESHOOTING MODEM COMMUNICATIONS

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network is required, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

2.9.2.4.1 MODEM COMMUNICATION SPEED SETTING

First ensure the modem is set to communication with the DSE module at 9600 baud – Modems supplied by DSE are factory adjusted to operate with the DSE module. Only modems purchased from a third party may require adjustment.

To change the modems RS232 baud rate you need a command line terminal program (HyperTerminal by Microsoft is a good solution). Operation of this terminal program is not supported by DSE; contact your terminal program supplier.

Connect the modem RS232 port to your PCs RS232 port. You may need an additional card in your PC to provide this facility.

Use HyperTerminal (or similar) to connect to the modem at its current baud rate. You may need to contact your modem supplier to obtain this detail. If this is not possible, use 'trial and error' methods. Select a baud rate, attempt connection, press <ENTER> a few times. If the modem responds with **OK** then you are connected at the correct baud rate. Any other response (including nothing) means you are not connected so select another baud rate.

When connected, enter the following command:

AT+IPR=9600 and press <ENTER>
This sets the modem to 9600 baud.

Close the HyperTerminal connection (**do not** remove power from the modem) then open a new connection to the modem at 9600 baud.

Enter the following command:

AT&W and press <ENTER>

This saves the new setting in the modem. Power is now removed. The next time power is applied, the modem starts with the new settings (Baud rate = 9600), suitable to communicate with the DSE module.


2.9.2.4.2 GSM MODEM CONNECTION

Most GSM modems have a *Status* LED. The Wavecom Fastrack Supreme as recommended and previously supplied by DSE has a RED Status LED, operating as follows.

LED State	Description
Off	Modem is not powered
On Continuous	Not connected to GSM network
Flashing Slow (approximately once every two seconds)	Connected to GSM network
Flashing Fast (approximately twice per second)	Connected to GSM network data transmission in progress.

2.9.3 RS485 PORTS

NOTE: When the *RS485 Port Usage* is configured to “*PLC Comms*”, all other modules’ *Port Usage* must be configured to “*Gencomm*”. This allows the module configured as “*PLC Comms*” to act as a master and read from the module(s) configured to “*Gencomm*”. For details on how to configure the *PLC Editor* to read via its RS485, refer to DSE Publication: *057-314 Advanced PLC Software Manual* which is found on our website: www.deepseaelectronics.com



Parameter	Description
Slave ID	Select the Slave ID of the DSE module’s RS485 port. Every device on the RS485 link must have an individual Slave ID.
Baud Rate	Select the Baud Rate (speed of communication) of the DSE module’s RS485 port. Every device on the RS485 link must have the same Baud Rate. 1200 2400 4800 9600 14400 19200 28800 38400 57600 115200
Port Usage	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: In a system for a <i>PLC Comms</i> application, only one DSE module must be configured to act as the PLC master. For further details and instructions on using <i>the PLC Comms</i>, refer to DSE Publication: <i>057-314 Advanced PLC Software Manual</i> which is found on our website: www.deepseaelectronics.com</p> </div> <p>Select the RS485 Port1 usage. Gencomm: MODBUS RTU RS485 communication PLC Comms: The RS485 Port 1 is used to read the other controllers’ registers over the RS485 link which are defined in the <i>PLC Editor</i>.</p>
Master Inactivity Timeout	Set the time delay between a MODBUS RTU request and the receipt of a response. The module monitors by default the USB port for communications. When activity is detected on the RS485 port, the module monitors the port for further data. If no data activity is detected on the port for the duration of the <i>Master Inactivity Timer</i> , it reverts to looking at the USB port. This needs to be set longer than the time between MODBUS polls from the master.
Inter-frame Delay	Set the time delay between the DSE module receiving a MODBUS RTU request and the DSE module’s response.

2.9.4 ETHERNET

NOTE: Consult the network administrator of the host network before changing these settings. Incorrect settings cause network errors in the existing local area network. These settings must only be changed by qualified network administrators.

Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol

Obtain IP Address Automatically

Parameter	Description
Obtain IP Address Automatically	<input type="checkbox"/> = The Dynamic Host Configuration Protocol (DHCP) is disable and the unit has a fixed IP address as configured in the <i>IP Address</i> section. <input checked="" type="checkbox"/> = The Dynamic Host Configuration Protocol (DHCP) is enable and the unit automatically attains an IP address from the network it is connected to if it has DHCP enabled.

Names

Names

Domain Name	DSE Module
Host Name	Company
Vendor Name	Deep Sea Electronics

Parameter	Description
Domain Name	The hostname of the device which is used for DHCP requests and acknowledgements. Consult the network IT manager for suitable naming
Host Name	Additional description string for DHCP
Vendor Name	Additional description string for DHCP

IP Address

IP Addresses				
IP address	192	168	1	100
Subnet Mask	255	255	255	0
Gateway Address	0	0	0	0
DNS Address	0	0	0	0
Preferred Connection Address	0	0	0	0

Parameter	Description
IP Address	The static IP address of the module.
Subnet Mask	The subnet mask is to determine whether the module is on the local subnet or on a remote network.
Gateway Address	IP address of the internet router that module is connected to.
DNS Address	IP address of the Domain Name Service (DNS). Usually this is the same as the module's IP address.
Preferred Connection Address	The module allows up to five MODBUS masters to connect to it. The <i>Preferred Connection Address</i> enables the unit to reserve one of the five connections for a specific IP address, such as for a remote display module to ensure it always connects.

MODBUS

Modbus	
Modbus Port Number	502

Parameter	Description
Modbus Port Number	The port number which the module serves MODBUS traffic on.

2.9.4.1 FIREWALL CONFIGURATION FOR INTERNET ACCESS

As modem/routers differ enormously in their configuration, it is not possible for DSE to give a complete guide to their use with the DSE module. However it is possible to give a description of the requirements in generic terms. For details of how to achieve the connection to your modem/router you are referred to the supplier of your modem/router equipment.

The DSE module makes its data available to a configurable TCP port number. You must configure your modem/router to allow inbound traffic on this port. For more information you are referred to your WAN interface device (modem/router) manufacturer.

2.9.4.2 INCOMING TRAFFIC (VIRTUAL SERVER)

Network Address and Port Translation (NAPT) allows a single device, such as the modem/router gateway, to act as an agent between the Internet (or "public external network") and a local (or "internal private") network. This means that only a single, unique IP address is required to represent an entire group of computers.

For our DSE module application, this means that the WAN IP address of the modem/router is the IP address we need to access the site from an external (internet) location.

When requests reach the modem/router, we want this passed to a 'virtual server' for handling, in our case this is the DSE module.

Example:

Virtual Servers		
Filter Name	Source Port	Destination (LAN) Address
DSE8660 MKII	1003	192.168.1.45

IP Address of the DSE controller connected to the LAN.


User provided name for the Port Forwarding rule.

Port number of the communications (must match the configuration of the DSE controller).


Result : Traffic arriving from the WAN (internet) on port 1003 is automatically sent to IP address 192.168.1.45 on the LAN (DSE module) for handling.

2.9.5 NOTIFICATIONS

The *Notifications* page is subdivided into smaller sections. Select the required section with the mouse.



2.9.5.1 SNMP

 **NOTE: The SNMP V2c MIB file for the module is available to download from the DSE website: www.deepseaelectronics.com.**

The module supports SNMP v2c with GetRequest, SetRequest, GetNextRequest, GetBulkRequest and Response. The module also allows communication up to two different SNMP managers at the same time on different IP addresses.

A fixed MIB file is available for the module for use by external SNMP managers. The MIB file is a file used by the SNMP manager to give context to the information held within the module.

A screenshot of the 'SNMP Settings' configuration page. The page has a light blue header. Below the header, there is a section for 'Enable' with a checked checkbox. Below that are several input fields: 'Device Name' (DSE Module), 'Manager 1 Address' (192.168.1.99), 'Manager 2 Address' (empty), 'Manager Port' (161), 'Notification Port' (162), 'Read Community String' (public), and 'Write Community String' (private).

Parameter	Description
Enable	<input type="checkbox"/> = The SNMP function is disabled <input checked="" type="checkbox"/> = The SNMP function is enabled. The module communicates with the SNMP manager using its ethernet port.
Device Name	The name of the module which is attainable by SNMP requests using sysName OID contained within the standard RFC1213 MIB file.
Manager 1 Address	The static IP address of the first SNMP manager.
Manager 2 Address	The static IP address of the second SNMP manager.
Manager Port	The port number which the module serves SNMP GET, GET Next, Get Bulk, Get Subtree, Walk and SET messages.
Notification Port	The port number which the module sends SNMP TRAP messages via.
Read Community String	The SNMP <i>Read Community String</i> . (Factory setting <i>public</i>)
Write Community String	The SNMP <i>Write Community String</i> . (Factory setting <i>private</i>)

2.9.5.2 NOTIFICATIONS


The user is able to select the types of events which are sent to the SNMP managers as SNMP TRAP messages.

	SNMP Trap
Named Alarms	<input type="checkbox"/>
Unnamed Alarms	<input type="checkbox"/>
Mode Change	<input type="checkbox"/>
Power Up	<input type="checkbox"/>
Mains Fail	<input type="checkbox"/>
Mains Return	<input type="checkbox"/>
Bus Off Load	<input type="checkbox"/>
Bus On Load	<input type="checkbox"/>
Incorrect Password Entered	<input type="checkbox"/>


Parameter	Description
Named Alarms	<input type="checkbox"/> = No SNMP TRAPs are sent when a <i>Named Alarm</i> activates. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when a <i>Named Alarm</i> activates. A <i>Named Alarm</i> is a protection with a pre-set name, e.g. <i>Fail to Synchronise</i> .
Unnamed Alarms	<input type="checkbox"/> = No SNMP TRAPs are sent when an <i>Unnamed Alarm</i> activates. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when an <i>Unnamed Alarm</i> activates. An <i>Unnamed Alarm</i> is a protection with a user configured name, e.g. a digital input configured for <i>User Configured</i> .
Mode Change	<input type="checkbox"/> = No SNMP TRAPs are sent when the module changes operating mode. <input checked="" type="checkbox"/> = An SNMP TRAP is sent to indicate the operating mode has changed and what it has changed to.
Power Up	<input type="checkbox"/> = No SNMP TRAPs are sent when the module powers up. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the module powers up.
Mains Fail	<input type="checkbox"/> = No SNMP TRAPs are sent when module detects a Mains failure. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the module detects a Mains failure.
Mains Return	<input type="checkbox"/> = No SNMP TRAPs are sent when the module detects the Mains has returned. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the module detects the Mains has returned.
Bus Off Load	<input type="checkbox"/> = No SNMP TRAPs are sent when the Generator Bus switchgear opens . <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the Generator Bus switchgear opens.
Bus On Load	<input type="checkbox"/> = No SNMP TRAPs are sent when the Generator Bus switchgear closes. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the Generator Bus switchgear closes.
Incorrect Password Entered	<input type="checkbox"/> = No SNMP TRAPs are sent when the four digit PIN is entered incorrectly. <input checked="" type="checkbox"/> = SNMP TRAPs are sent when the four digit PIN password is entered incorrectly via the <i>Front Panel Editor Configurator</i> , or PC configuration read/write

2.10 SCHEDULER

The section is subdivided into smaller sections.



2.10.1 SCHEDULER OPTIONS



Function	Description
Enable Exercise Scheduler	<input type="checkbox"/> = The scheduler is disabled. <input checked="" type="checkbox"/> = The scheduler is enabled, Bank 1 and Bank 2 become editable.

2.10.2 BANK 1 / BANK 2

Each Bank of the Exercise Scheduler is used to give up to 8 scheduled runs per bank, 16 in total. This run schedule is configurable to repeat every 7 days (weekly) or every 28 days (monthly). The run is *On Load*, *Off Load* or *Auto Start Inhibit*.


Each scheduler bank configured differently either to weekly or monthly based exercises.

Week	Day	Run Mode	Start Time	Duration	
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear
First	Monday	Off Load	00:00	00:00	Clear

Function	Description
Schedule Period	Determines the repeat interval for the scheduled run. Options available are: Weekly: The schedule events occur every week. Monthly: The schedule events occur every month on the week selected.
Week	Specifies the week of the month, on which the scheduled run takes place
Day	Specifies the day of week, on which the scheduled run takes place
Run Mode	Determines the loading state mode of the Generator Bus when running on schedule Auto Start Inhibit: The Generator Bus is prevented from starting in <i>Auto</i> mode. Island: The module runs the Generator Bus in long term parallel operation for the duration of the schedule. Off Load: The module runs the Generator Bus on schedule with the Bus switchgear open. Parallel: The module runs the Generator Bus in island operation on schedule, transferring all the load to the Generator Bus and opening the Mains switchgear.
Start Time	Determines at what time of day the scheduled run starts
Duration	Determines the time duration in hours for the scheduled run
Clear	Resets the values for the Day, Start Time and Duration to defaults

2.11 EXPANSION


The *Expansion* page is subdivided into smaller sections. Select the required section with the mouse.



See overleaf for description of the different expansion modules.

2.11.1 DSE2130 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:

2130 Expansion Enable

2130 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Warning

Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2130 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.

2130 Expansion Inputs


[Analogue Input Configuration](#)
[Analogue Inputs](#)
[Digital Inputs](#)

2.11.1.1 ANALOGUE INPUT CONFIGURATION

Input Configuration

Parameter	Description
Analogue Input E to H	Select what the analogue input is to be used for: Not Used: The analogue input is disabled Digital Input: Configured on the 2130/Digital Inputs pages Flexible Analogue: Configured on the 2130/Analogue Inputs pages

2.11.1.2 ANALOGUE INPUTS

 **NOTE:** An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled *Analogue Input Configuration* elsewhere in this document for further details.

Sensor Description

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve Resistive: for sensors with maximum range of 0 Ω to 480 Ω Pressure: The input is configured as a pressure sensor Percentage: The input is configured as a percentage sensor Temperature: The input is configured as a temperature sensor


Parameter descriptions are continued overleaf...

Sensor Alarms


Parameter	Description
Alarm Arming	Select when the alarm becomes active: Always Active From Mains Parallel Never
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Alarm Action	NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.
Low Alarm String	The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.11.1.2.1 CREATING / EDITING THE SENSOR CURVE

While the *DSE Configuration Suite* holds sensor specifications for the most commonly used resistive sensors, occasionally it is required that the module be connected to a sensor not listed by the *DSE Configuration Suite*. To aid this process, a sensor curve editor is provided.




When creating a new sensor curve the measurement quantity and measured parameter are required.



Parameter	Description
X-Axis (Measured Quantity)	Select the electrical quantity that the sensor outputs. Resistive (Ohms): For sensors that output a resistance within a range 0 Ω to 480 Ω Current (mA): For sensors that output current within a range 0 mA to 20 mA Voltage (Volt): For sensors that output voltage within a range of 0 V to 10 V
Y-Axis	Select the parameter that is being monitored by the sensor Temperature (°C): For sensors that measure temperature. Pressure (Bar): For sensors that measure pressure. Percentage (%): For sensors that measure percentage.

Sensor curve creation / editor descriptions are continued overleaf...



Click *Interpolate* then select two points as prompted to draw a straight line between

Click to change the range of the X and Y Axes of the graph and the level of open circuit


Click **SAVE AS**, a prompt to name the curve...
 New Curve Name
 Enter a name for the new curve
 [Input Field]
 [OK] [Cancel]
 Click **OK** to save the curve.
Any saved curves become selectable in the Input Type selection list.

Click **OK** to accept the changes or **CANCEL** to ignore and lose the


Hint: Deleting, renaming or editing custom sensor curves that have been added is performed in the main menu, select *Tools | Curve Manager*.

2.11.1.3 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.11.1.3.1 DIGITAL INPUTS



Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: Electrical Trip Indication Warning</p>
Arming	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> </div> <p>Select when the input becomes active: Active From Mains Parallel Always Never</p>
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.11.1.3.2 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a digital input if it has been configured as Digital Input, refer to section entitled *Analogue Input Configuration* elsewhere in this document for further details.

Analogue Inputs E - H

Analogue Input E (Digital)

Function	User Configured
Polarity	Close to Activate
Action	Warning
Arming	Always
LCD Display	2130 ID0 Analogue E (Digital)
Activation Delay 0s	<input type="range"/>

Analogue Input F (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 3px double black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: Electrical Trip Indication Warning</p>
Arming	<div style="border: 3px double black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> </div> <p>Select when the input becomes active: Active From Mains Parallel Always Never</p>
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.11.2 DSE2131 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:

2131 Expansion Enable

2131 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Warning

Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2131 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.

2131 Expansion Inputs

[Analogue Input Configuration](#)
[Analogue Inputs](#)
[Digital Inputs](#)

2.11.2.1 ANALOGUE INPUT CONFIGURATION

Input Configuration	
Analogue Input A	Flexible Analogue ▾
Analogue Input B	Flexible Analogue ▾
Analogue Input C	Not Used ▾
Analogue Input D	Flexible Analogue ▾
Analogue Input E	Digital Input ▾
Analogue Input F	Digital Input ▾
Analogue Input G	Digital Input ▾
Analogue Input H	Flexible Analogue ▾
Analogue Input I	Digital Input ▾
Analogue Input J	Not Used ▾

Input Configuration

Parameter	Description
Analogue Input A to J	Select what the analogue input is to be used for: Not Used: The analogue input is disabled Digital Input: Configured on the <i>2131/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>2131/Analogue Inputs</i> pages

2.11.2.2 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled *Analogue Input Configuration* elsewhere in this document for further details.

Sensor Description

Sensor Description

Sensor Name

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

Input Type

VDO Ohm range (10-180)

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve Resistive: for sensors with maximum range of 0 Ω to 1920 Ω Current: for sensors with maximum range of 0 mA to 20 mA Voltage: for sensors with maximum range of 0 V to 10 V Percentage: The input is configured as a percentage sensor Pressure: The input is configured as a pressure sensor Temperature: The input is configured as a temperature sensor

Parameter descriptions are continued overleaf...

Sensor Alarms

Parameter	Description
Alarm Arming	Select when the alarm becomes active: Always Active From Mains Parallel Never
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Alarm Action	▲NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.
Low Alarm String	The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	▲NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.11.2.3 DIGITAL INPUTS

NOTE: An analogue input is only configurable as a digital input if it has been configured as Digital Input, refer to section entitled *Analogue Input Configuration* elsewhere in this document for further details.

Analogue Inputs A - C

Analogue Input A (Digital)

Function	Alarm Mute
Polarity	Close to Activate
Action	
Arming	
LCD Display	2131 ID0 Flexible Sensor A
Activation Delay	0s

Analogue Input B (Digital)



Function	User Configured
Polarity	Close to Activate
Action	Warning
Arming	Always
LCD Display	2131 ID0 Flexible Sensor B
Activation Delay	0s

Analogue Input C (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page


As this example shows a *predefined* function, these parameters are *greyed out* as they are not applicable.

Parameter descriptions are overleaf...

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: The input function is activated when the relevant terminal is connected. Open to Activate: The input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 2px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Indication Warning
Arming	<div style="border: 1px solid black; padding: 2px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the input becomes active: Active From Mains Parallel Always Never
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.


2.11.3 DSE2133 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:


2133 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2133 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.



2.11.3.1 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled *Analogue Input Configuration* elsewhere in this document for further details.

Sensor Description

Sensor Description

Sensor Name

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

Input Type

Parameter	Description
Input Type	Select the sensor type from the pre-defined list: 2 Wire PT100 3 Wire PT100 <i>Type J (Thermocouple)</i> <i>Type K (Thermocouple)</i>

Parameter descriptions are continued overleaf...

Sensor Alarms

Parameter	Description
Alarm Arming	Select when the alarm becomes active: Always Active From Mains Parallel Never
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Alarm Action	NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.
Low Alarm String	The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.11.4 DSE2152 OUTPUT MODULES

Select the DSENet ID of the output expansion to be configured. The ID of the expansion input module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:

2152 Expansion Enable

2152 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Electrical Trip ▼

Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2152 Expansion Outputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.

2152 Expansion Outputs

[Outputs A - F](#)

2.11.4.1 ANALOGUE OUTPUTS

Output Configuration


Parameter	Description
Output Name	Enter the <i>Output Name</i> , this text is shown on in the SCADA section when viewing the output.

Output Type


Parameter	Description
Source	Select the parameter that is to be mapped to the analogue output.
Curve	Select the output type and curve from a pre-defined list or create a user-defined curve Current: for sensors with maximum range of 0 mA to 20 mA Voltage: for sensors with maximum range of 0 V to 10 V

2.11.4.2 CREATING / EDITING THE OUTPUT CURVE

While the *DSE Configuration Suite* holds specifications for the most used output ranges, occasionally it is required that the expansion module's output be connected to a none standard device. To aid this process, a curve editor is provided.




When creating a new sensor curve the measurement quantity and measured parameter are required.



Parameter	Description
Y-Axis (Source)	The parameter measured by the DSE module that is to be mapped to the output.
X-Axis (Output)	Select the electrical quantity that the sensor outputs. Current (mA): For an output current within a range 0 mA to 20 mA Voltage (Volt): For an output voltage within a range of 0 V to 10 V

Curve creation / editor descriptions are continued overleaf...



Click *Interpolate* then select two points as prompted to draw a straight line between

Click to change the range of the X and Y Axes of the graph and the level of open circuit

Click SAVE AS, a prompt to name the curve...

New Curve Name

Enter a name for the new curve

OK Cancel

Click OK to save the curve.


Any saved curves become selectable in the *Output Type* selection list.

Click OK to accept the changes or CANCEL to ignore and lose the

Hint: Deleting, renaming or editing custom curves that have been added is performed in the main menu, select *Tools | Curve Manager*.


2.11.5 DSE2157 RELAY MODULES

Select the DSENet ID of the output expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.




The following options are then shown:

2157 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

Relay Outputs (Normally Open / Changeover)



Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital input polarity: Energise: When the output source is true, the output activates. De-Energise: When the output source is true, the output deactivates.


2.11.6 DSE2548 ANNUNCIATOR MODULES

Select the DSENet ID of the LED expansion to be configured. The ID of the expansion input module is set by rotary decimal switch accessible on the rear of the device.




The following options are then shown:

2548 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

Sounder Configuration



Parameter	Description
Follow Main Unit	<input type="checkbox"/> = If the <i>mute / lamp test</i> button is pressed, other DSE2548 modules and the host module does not respond to this. <input checked="" type="checkbox"/> = If the <i>mute / lamp test</i> button is pressed, other DSE2548 modules configured to <i>Follow main unit</i> and the host module also lamp test / mute their alarm and vice-versa.
Sounder Enabled	<input type="checkbox"/> = The DSE2548 internal sounder does not annunciate on a fault condition becoming active. <input checked="" type="checkbox"/> = The DSE2548 internal sounder annunciates on a fault condition becoming active.

Parameter descriptions are continued overleaf...

LED Indicators

LED Indicators		
A	System In Auto Mode	Lit
B	Mains Load Inhibited	Lit
C	Combined Remote Start Request	Lit
D	Common Alarm	Lit
E	Not Used	Lit
F	Not Used	Lit
G	Not Used	Lit
H	Not Used	Lit

Annunciator Insert Card

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital input polarity: Energise: When the output source is true, the output activates. De-Energise: When the output source is true, the output deactivates.
Annunciator Insert Card	Allows the user to create and print the custom text insert cards for the LEDs.

2.11.7 BATTERY CHARGERS

Select the DSENet ID of the battery charger to be configured. The ID of the expansion module is set by configuration of the device.



The following options are then shown:

DSENet ID

DSENet ID 0

Enable

Link Lost Alarm Action Electrical Trip

Modbus Slave ID 11

Display Instrumentation

Charger Name Charger ID0

Parameter	Description
Enable	<input type="checkbox"/> = The battery charger with the selected ID is not enabled. <input checked="" type="checkbox"/> = The battery charger with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.
Modbus Slave ID	The Slave ID used to address the battery charger via the host module's RS485 when using the host module as a MODBUS RTU pass through.
Display Instrumentation	<input type="checkbox"/> = The battery chargers' information is not shown on the host module's display. <input checked="" type="checkbox"/> = The battery charger information is shown on the host module's display.
Charger Name	Enter the <i>Charger Name</i> , this text is shown on the module display when viewing the battery charger instrumentation

Charger Shutdown Alarms

Charger Shutdown Alarms

Enable

Module Action Warning

Alarm String Charger ID0 Common Shutdown

Parameter	Description
Enable	<input type="checkbox"/> = The DSE module does not display any shutdown alarms from the battery charger. <input checked="" type="checkbox"/> = The DSE module displays shutdown alarms from the battery charger with the configured action.
Alarm String	The text that is displayed on the module's LCD when the DSE module detects a shutdown fault from the battery charger.

Charger Warning Alarms

Charger Warning Alarms

Enable


Module Action Warning

Alarm String Charger ID0 Common Warning

Parameter	Description
Enable	<input type="checkbox"/> = The DSE module does not display any warning alarms from the battery charger. <input checked="" type="checkbox"/> = The DSE module displays warnings alarms from the battery charger with the configured action.
Alarm String	The text that is displayed on the module's LCD when the DSE module detects a warning fault from the battery charger.

2.12 ADVANCED

The *Advanced* page is subdivided into smaller sections. Select the required section with the mouse.



2.12.1 ADVANCED OPTIONS

Out of Sync

Parameter	Description
Out of Sync Angle	<p>During parallel operation, the phase of both supplies is monitored. Being in parallel means that the phase difference is zero degrees (0 °) between the two supplies.</p> <p>If the angle exceeds the <i>Out of Sync Angle</i> for longer than the duration of the <i>Out of Sync Timer</i>, an alarm is generated with the configured <i>Action</i>.</p> <p>Select the type of alarm required from the list: Auxiliary Mains Failure Electrical Trip Warning</p>

Troubleshooting Out of Sync


This section describes the most common causes for an *Out of Sync* alarm:

- The switchgear does not close quickly enough. Ensure the switchgear closes within 100 ms of receiving the close signal.
- The *Out of Sync* timer is set too low. If this timer is raised away from the factory setting of 200 ms (0.2 s), ensure the consequences are fully understood.
- Something external has caused the switchgear to open, or has prevented it from closing. Typical examples are external G59 relays and other equipment operating directly on the switchgear to open it.
- The switchgear wiring 'logic' is not correct, causing the switchgear to 'fire through', where it triggers the close mechanism, but the switchgear doesn't actually mechanically close, it re-opens again.


Other Timers

Parameter	Description
Synchronisation Delay	Delays the synchronising process to allow the Generator Bus to stabilise and power parasitic loads or transformers (for instance) before the synchronising process begins.
Mains Decoupling Supervision	Delays the activation of the inbuilt Mains Decoupling detection when Bus switchgear closes in parallel with the mains. Upon closing into parallel, the timer is activated. After the timer has expired, the Mains decoupling protection becomes active.
Interlock Override Off	Timer to delay the <i>Interlock Override</i> de-energising once a breaker has opened.

Test Mode

Parameter	Description
Run Mode	Configures the operation of the Test  button as: Island Mode: The module performs the start sequence and transfers all the load to the Generator Bus. The Mains switchgear is left open and the Generator Bus runs in island mode. Parallel Mode: The module performs the start sequence and synchronises the generators Bus to the Mains to allow long term parallel operation; peak lopping when set to <i>Mains Mode</i> , or fixed export / base load when in <i>Bus Mode</i> .

Ramp

Parameter	Description
Alternative Ramping Scheme	<p> NOTE: The <i>Maximum Load Level</i> are configured within the SCADA section. For further details, refer to section entitled <i>Load Levels</i> contained within the SCADA section elsewhere within this document.</p> <p><input type="checkbox"/> = In <i>Bus Mode</i>, when the Mains returns the Generator Bus ramps up to the <i>Maximum Load Level</i> before ramping off to the Mains. <input checked="" type="checkbox"/> = In <i>Bus Mode</i>, when the Mains returns the Generator Bus ramps off from its current load level to the Mains</p>

Dead Bus Synchronising

Parameter	Description
Enable	<input type="checkbox"/> = All synchronising is performed 'the traditional' way by achieving a slip frequency and waiting for the voltage, frequency and phase to be within configured windows <input checked="" type="checkbox"/> = The Dead Bus Synchronising feature is activated as configured below.
Sync Mode	Always: Dead Bus sync is always used when the generators are required to be on line and in the <i>Auto</i> mode (Dead Bus sync does not operate in <i>Manual</i> mode under any circumstance). Disabled: The feature is not active On Input: Dead Bus sync is used when a digital input configured for <i>Remote Start Dead Bus Synchronising</i> is active. On Mains Failure: The generators are started in dead Bus sync whenever the Mains failure occurs.
Start Delay	Time delay used at start up to ensure the start request is not simply a fleeting request.

Manual Island Mode Bus Limits

NOTE: The *Manual Island Mode Bus Limits* feature is only applicable on the DSE8660 MKII when it is in *Island* mode or in *Manual* mode and generators running in island.

NOTE: The DSE module does not use the *Manual Island Mode Bus Limits* settings for the normal synchronisation and load share operation.


In certain applications it is required to ‘manually’ synchronise the generators bus to an external source ‘mains’ then to manually control the mains switchgear to parallel the generators bus with the mains. In this instance the DSE8660 MKII’s *Bus Voltage Adjust* and the *Bus Frequency Adjust* functions must be used to control the bus voltage and bus frequency levels when the generators are running in island. The *Bus Voltage Adjust* and the *Bus Frequency Adjust* levels are configured from the PLC Editor or through Modbus communication by writing to the *Bus Voltage Adjust* and the *Bus Frequency Adjust* GenComm registers.

The *Manual Island Mode Bus Limits* feature, applicable when generators running in island mode only, is to set limits to the bus voltage bias and the bus frequency bias that the DSE8660 MKII has to control the DSE8610 MKII generators over the MSC. The configuration of these settings depend on the generators’ control ranges capabilities. For example, if in a system one or more of the generators is only able to be controlled by +/-30 volts, then the *Manual Voltage Limit* must be configured to 30.0 Volt. In this way the DSE8660 MKII does not request more than what that generator is able to accept.

To control the bus voltage and the bus frequency through the *Bus Voltage Adjust* and the *Bus Frequency Adjust* functions, it is first required to enable the *Manual Bus Adjust* from the PLC Editor’s *Override Gencomm* functionality. It is also possible to enable the *Manual Bus Adjust* through GenComm.

The DSE8660 MKII uses the *Manual Island Mode Bus Limits* only when all the following conditions are satisfied:

- The DSE8660 MKII must be in *Island Mode* or in *Manual Mode* and not in parallel with the mains.
- The DSE8660 MKII must have the Control over the DSE8610 MKII modules.
- The *Manual Bus Adjust* must be set to active. Refer to the section entitled PLC elsewhere in this document for details on how to use the *PLC Editor*.




Parameter	Description
Manual Voltage Limit	This is the maximum voltage that the DSE8660 MKII increases or decreases around the <i>Bus Nominal Voltage</i> when requested to control the DSE8610 MKII generators’ bus voltage through the MSC whilst running in island.
Manual Frequency Limit	This is the maximum frequency that the DSE8660 MKII increases or decreases around the <i>Bus Nominal Frequency</i> when requested to control the DSE8610 MKII generators’ bus frequency through the MSC whilst running in island.


2.12.2 PLC

NOTE: For further details and instructions on the *PLC Editor*, refer to DSE Publication: *057-314 Advanced PLC Software Manual* which is found on our website: www.deepseaelectronics.com


NOTE: For the earlier software versions pre-V5 of the module, refer to DSE Publication: *057-175 PLC Programming Guide* which is found on our website: www.deepseaelectronics.com



Click to open the *PLC Editor*, then the *PLC Editor* opens as shown below.



2.12.3 CONFIGURABLE GENCOMM PAGES 166 TO 169



For advanced MODBUS users of the controller, configurable Gencomm pages are available. The intention is to allow the user to create personal collections of data in subsequent registers to minimise the number of MODBUS reads required by the master, and hence speed up data collection.

All configurable Gencomm registers are 32-bit unsigned format.

Gencomm Page 166							
Register	Value	Register	Value	Register	Value	Register	Value
0-1	<Not Used>	64-65	<Not Used>	128-129	<Not Used>	192-193	<Not Used>
2-3	<Not Used>	66-67	<Not Used>	130-131	<Not Used>	194-195	<Not Used>
4-5	<Not Used>	68-69	<Not Used>	132-133	<Not Used>	196-197	<Not Used>
6-7	<Not Used>	70-71	<Not Used>	134-135	<Not Used>	198-199	<Not Used>
8-9	<Not Used>	72-73	<Not Used>	136-137	<Not Used>	200-201	<Not Used>
10-11	<Not Used>	74-75	<Not Used>	138-139	<Not Used>	202-203	<Not Used>
12-13	<Not Used>	76-77	<Not Used>	140-141	<Not Used>	204-205	<Not Used>
14-15	<Not Used>	78-79	<Not Used>	142-143	<Not Used>	206-207	<Not Used>
16-17	<Not Used>	80-81	<Not Used>	144-145	<Not Used>	208-209	<Not Used>
18-19	<Not Used>	82-83	<Not Used>	146-147	<Not Used>	210-211	<Not Used>
20-21	<Not Used>	84-85	<Not Used>	148-149	<Not Used>	212-213	<Not Used>
22-23	<Not Used>	86-87	<Not Used>	150-151	<Not Used>	214-215	<Not Used>
24-25	<Not Used>	88-89	<Not Used>	152-153	<Not Used>	216-217	<Not Used>
26-27	<Not Used>	90-91	<Not Used>	154-155	<Not Used>	218-219	<Not Used>
28-29	<Not Used>	92-93	<Not Used>	156-157	<Not Used>	220-221	<Not Used>
30-31	<Not Used>	94-95	<Not Used>	158-159	<Not Used>	222-223	<Not Used>
32-33	<Not Used>	96-97	<Not Used>	160-161	<Not Used>	224-225	<Not Used>
34-35	<Not Used>	98-99	<Not Used>	162-163	<Not Used>	226-227	<Not Used>
36-37	<Not Used>	100-101	<Not Used>	164-165	<Not Used>	228-229	<Not Used>
38-39	<Not Used>	102-103	<Not Used>	166-167	<Not Used>	230-231	<Not Used>
40-41	<Not Used>	104-105	<Not Used>	168-169	<Not Used>	232-233	<Not Used>
42-43	<Not Used>	106-107	<Not Used>	170-171	<Not Used>	234-235	<Not Used>
44-45	<Not Used>	108-109	<Not Used>	172-173	<Not Used>	236-237	<Not Used>
46-47	<Not Used>	110-111	<Not Used>	174-175	<Not Used>	238-239	<Not Used>

The configurable MODBUS pages are:

Page	Hex Address	Decimal Address
166	A600	42496
167	A700	42752
168	A800	43008
169	A900	43264

Example of Gencomm Page Configuration:

The screenshot shows a configuration window titled "Page 166". Below the title is a section labeled "Register Value" containing four rows of bit ranges and their corresponding values:

Register Range	Value
0-1	Bus And Mains In Parallel
2-3	Mains Total Power
4-5	Combined Mains Failure
6-7	Remote Start Over MSC

The register address is obtained from the formula:
 $register_address = page_number * 256 + register_offset$.

To read the *Mains Total Power* from the above register, the MODBUS master device needs to read the data in two registers and then combine the data from the Most Significant Bit and the Least Significant Bit.

MSB address in Decimal = $(166 * 256) + 2 = 42498$

LSB address in Decimal = $(166 * 256) + 3 = 42499$

2.12.4 CONFIGURABLE EDITOR SCREENS

The *Configurable Editor Screens* enables the user to select six parameters to be editable through the module display. The editing of these parameters is not protected by the PIN (if enabled).


The screenshot shows a window titled "User Editable Module Parameters". Inside, there are six rows, each with a label "Editable Item X" and a dropdown menu. The selected options are: Config Select, Load Level Less Sets, Load Level More Sets, MSC Compatibility Enable, Nominal Voltage, and Nominal Frequency.

Parameter	Description
Editable Item 1 to 6	Select the required parameter to be shown and be editable from the module's screen.


3 SCADA

SCADA stands for Supervisory Control And Data Acquisition and is provided both as a service tool and also as a means of monitoring / controlling the Generator Bus.


As a service tool, the SCADA pages are to check the operation of the controller's inputs and outputs as well as checking the Mains operating parameters.



When connection is made...




The SCADA page is subdivided into smaller sections. Select the required section with the mouse.



3.1 MAINS IDENTITY

This section displays the module's configuration settings for *Site ID* and *Genset ID*. For further details on how to configure these items, refer to section entitled *Communications Options* elsewhere within this document.



3.2 MIMIC

This section provides a mimic of the module's fascia and allows the operator to change the control mode of the module. For information in regards to operating the DSE module, refer to DSE publication: **057-259 DSE8660 MKII Operation Manual** which is found on the DSE website: www.deepseaelectronics.com



3.3 DIGITAL INPUTS

This section displays the status of the module's digital inputs and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Digital Inputs* elsewhere within this document.

Shows if the input channel is active or not. This input is open and not active. The input is configured to be *Close to Activate*

Digital Inputs	Active	Open / Closed
A Remote Start On Load	●	⚡
B Transfer To Bus / Open Mains	●	⚡
C Transfer To Mains / Open Bus	●	⚡
D Bus Closed Auxiliary	●	⚡
E Mains Closed Auxiliary	●	⚡
F DSEP100 G59 Event	●	⚡
G Simulate Auto Button	●	⚡
H Remote Start In Island Mode	●	⚡
I External Panel Lock	●	⚡
J Digital Input J	●	⚡
K Vent Fan VSD Trip	●	⚡
L Digital Input L	●	⚡

State of the input (open or closed to battery negative)

3.4 DIGITAL OUTPUTS

This section displays the status of the module's digital outputs and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Digital Outputs* elsewhere within this document.

Digital Outputs (Volts Free)		Active	Open / Closed
C (N/C)	Close Mains Output	●	⏏
D	Close Bus Output	●	⏏

Digital Outputs (DC Supply Out)		Active	Open / Closed
E	Open Mains Output Pulse	●	⏏
F	Open Bus Output Pulse	●	⏏
G	Audible Alarm	●	⏏
H	Not Used	●	⏏
I	Not Used	●	⏏
J	Not Used	●	⏏

State of the output (open or closed)

Shows if the output channel is active or not. This output is closed and is active. The output is configured to be *Close Mains Energise*. As the module wants the Mains switchgear closed, the output is *Energised*.

3.5 VIRTUAL LEDS


This section displays the status of the module's *Virtual LEDs* and the functions they are configured for. These LEDs are not fitted to the module or expansion modules, they are not physical LEDs. They are provided to show status and appear only in the SCADA section of the DSE Configuration Suite, or read by third party PLC or Building Management Systems (for example) using the MODBUS protocol. For further details on how to configure these items, refer to section entitled *Digital Outputs* elsewhere within this document.

The screenshot shows a window titled "LED Status" with a list of 20 virtual LEDs. Each LED is represented by a green dot. The first dot is labeled "Active". Callouts provide additional information: one points to the "Active" label stating "State of the LED (on or off)", and another points to the "Common Shutdown" function for LED 6 stating "Shows what the virtual LED is configured to indicate."

LED ID	Function	State
LED 1	System In Auto Mode	Active
LED 2	Fuel Relay	Off
LED 3	Start Relay	Off
LED 4	Not Used	Off
LED 5	Common Alarm	Off
LED 6	Common Shutdown	Off
LED 7	Not Used	Off
LED 8	Not Used	Off
LED 9	Not Used	Off
LED 10	Not Used	Off
LED 11	Not Used	Off
LED 12	Not Used	Off
LED 13	Not Used	Off
LED 14	Not Used	Off
LED 15	Not Used	Off
LED 16	Not Used	Off
LED 17	Not Used	Off
LED 18	Not Used	Off
LED 19	Not Used	Off
LED 20	Not Used	Off

3.6 BUS

The *Bus* section is subdivided into smaller sections. Select the required section with the mouse.



3.6.1 FREQUENCY AND VOLTAGES

This section displays the module's measurement of the *Bus* supply.

Frequency		
49.98 Hz		
Phase Rotation		
L1-L2-L3		
Phase To Neutral Voltages		
L1 - N 240.3 V	L2 - N 240.2 V	L3 - N 239.8 V
Phase To Phase Voltages		
L1 - L2 416.2 V	L2 - L3 414.5 V	L3 - L1 415.4 V

3.6.2 LOAD

This section displays the module's measurement of the *Load* derived from the *Load CT*.

Current		
279.0 A		
Power		
Watts 183.98 kW	VA 192.9 kVA	VAr 8.5 kVAr
Power factor		
0.99		
Bus Derived Instrumentation		
Watts 0.00 kW	VAr 0.0 kVAr	

3.6.3 MSC LINK

NOTE: These settings are not saved within the module’s configuration file. They are stored in a different memory area and not transferred with the configuration file. The *Backup Module* feature transfers both the configuration file AND the settings of the *MSC Link, Sync and Load Levels* page.

Bus

Parameter	Description
Set On The Bus	The number of DSExx10 controllers that are connected on the MSC link.
Sets On Load	The number of DSExx10 controllers that are connected on the MSC link and closed onto the Generator Bus.
Mains Controllers On The Bus	The number of DSExx60 and DSExx80 controllers that are connected on the MSC link.

Mains

Parameter	Description
MSC ID	Select the MSC ID of the DSE module’s MSC port. Every module connected on the MSC link must have a unique MSC ID. The MSC ID is automatically set when all the modules are powered up “one at a time”. If all the modules a powered up together, this may result in the <i>MSC ID Error</i> alarm activating. Manually setting the MSC ID allows this alarm to be reset and prevents this from occurring.
Priority	<div style="border: 2px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: DSExx60 and DSExx80 modules cannot have the same <i>MSC Priority Number</i>.</p> </div> Select the Priority of the module. The priority dictates which DSExx60 performs the change over from Mains to Generator Bus (and vice versa) first.


Commissioning Screen

Parameter	Description
Enable	<input type="checkbox"/> = Commissioning screens are not shown on the module display <input checked="" type="checkbox"/> = The commissioning screens are shown at the bottom of the <i>Bus</i> section on the module display. These pages are useful for the commissioning and troubleshooting of a load share system.

3.6.4 SYNC


NOTE: These settings are not saved within the module's configuration file. They are stored in a different memory area and not transferred with the configuration file. The *Backup Module* feature transfers both the configuration file AND the settings of the *MSC Link, Sync and Load Levels* page.

Frequency Synchroniser




Parameter	Description
Slip Frequency	This is the frequency difference between the Generator Bus and the Mains which the module adjusts to during synchronising. This is done to match the phase of the Generator Bus supply to Mains supply. The phase of the supplies then drifts in and out of synchronism at a rate of $1/Slip\ Frequency$ times per second. e.g. with a <i>Slip Frequency</i> of 0.2 Hz, the supplies are in phase once every five seconds.

Load Share



Parameter	Description
Stability (I)	The setting for the Stability (I) of the control loop used for control the DSExx10's kW power production. In general, lower setting results in slow kW control, but too high a setting may cause instability (hunting). If this occurs, lower the stability setting.

Reactive Load



Parameter	Description
Stability (I)	The setting for the Stability (I) of the control loop used for control the DSExx10's kvar power production. In general, lower setting results in slow kvar control, but too high a setting may cause instability (hunting). If this occurs, lower the stability setting.

Bus Commissioning Screen

NOTE: The Commissioning Screen is used to gauge how well the module is controlling the generators bus for load sharing.

The commissioning screen is available to both aid the commissioning process and also to give additional information about the synchronising and load sharing process.

Bus Commissioning Screen	
Target Active Power (kW)	50.0 %
Actual Active Power (kW)	49.9 %
Bus Frequency	50.02 Hz
Target Reactive Power (kvar)	38.7 %
Actual Reactive Power (kvar)	40.5 %
Bus Average L-N Voltage	230.3 V
Bus Average L-L Voltage	400.1 V

Parameter
Target Active Power (kW)
Actual Active Power (kW)
Bus Frequency
Target Reactive Power (kvar)
Actual Reactive Power (kvar)
Bus Average L-N Voltage
Bus Average L-L Voltage

Mains Commissioning Screen

Mains Commissioning Screen	
Target Active Power (kW)	50.0 %
Actual Active Power (kW)	49.9 %

Item
Target Active Power (kW)
Actual Active Power (kW)


3.6.5 LOAD LEVELS

Levels

NOTE: The *Load Level* settings only have effect when the Generator Bus is in parallel with the mains.

For further details on how to configure the different power modes and their operation, refer to section entitled *Power Control* and *Voltage and Reactive Power Control* elsewhere within this document.


Parameter	Description
Mode: Bus	<p>Using the <i>Remote Start on Load</i> input to the module, the Generator Bus is instructed to go into continuous parallel operation with the mains. This may be required to only occur during specified times of the day.</p> <p>When the module is set to <i>Bus Mode</i>, this causes the Generator Bus to produce a fixed (base) level of <i>Active Power</i> (kW) and <i>Reactive Power</i> (kvar) against the Mains when in continuous parallel operation.</p> <div style="text-align: center;"> </div> <p>With <i>Bus Mode</i>, care must be taken if exporting power to the Mains supply is not allowed. For instance, if the <i>Maximum kW Level</i> is set to 100 kW and the site load is 75 kW, the Generator Bus exports 25 kW into the Mains supply.</p> <p>The <i>Maximum kW Level</i> and <i>Maximum kvar Level</i> are a percentage of each generators capacity that is connected to the Bus. E.g. on a multi set system where each Generator is rated at 500 kW and the <i>Maximum kW Level</i> was set to 50%, each Generator running produces 250 kW. Therefore, the actual kW and kvar produced varies depending on how many generators are closed onto the Bus.</p>

Parameter	Description
<p>Mode: Mains</p>	<p>NOTE: When operating in <i>Mains Mode</i>, the generators are never driven to more than 100% of their full load rating. When the generators reach 100% of their full load rating, the <i>Insufficient Capacity</i> alarm activates (if configured).</p> <p>Using the <i>Remote Start on Load</i> input to the module, the Generator Bus is instructed to go into continuous parallel operation with the Mains once the Mains power exceeds the <i>Maximum kW Level</i> setting. This may be required to only occur during specified times of the day.</p> <p>When the module is set to <i>Mains Mode</i>, this enables the Generator Bus to provide <i>Peaking Lopping/Shaving Parallel</i> operation when in continuous parallel with the mains.</p>  <p>With <i>Mains Mode</i>, the Generator Bus is used to provide a variable amount of <i>Active Power (kW)</i> to maintain the Mains import/export levels to the configured <i>Maximum kW Level</i>.</p> <p>The <i>Maximum kW Level</i> and <i>Maximum kvar Level</i> are a percentage the Mains rating. E.g. If the Mains rating was configured as 250 kW, the Generator Bus would supply the difference between 250 kW and total connected load. If the load was lower than 250 kW, Generator Bus comes off load performs a controlled stop.</p>
<p>Power Control Mode</p>	<p>NOTE: For further information on these operating modes, refer to section entitled <i>Power Control</i> elsewhere within this document.</p> <p>Allows selection of the <i>Power Control Mode</i> when running in <i>Bus Mode</i>. This is also selectable by activation of a configured digital input or via the <i>Running Editor</i>.</p>
<p>Reactive Power Control Mode</p>	<p>NOTE: For further information on these operating modes, refer to section entitled <i>Voltage and Reactive Power Control</i> elsewhere within this document.</p> <p>Allows selection of the <i>Reactive Power Control Mode</i> when running in <i>Bus Mode</i>. This is also selectable by activation of a configured digital input or via the <i>Running Editor</i>.</p>

Parameter	Description
Maximum Load Level	<p>NOTE: When in <i>Bus Mode</i> if <i>Maximum kW Level</i> is greater than the load, power is exported to the mains. If required, enable the module's <i>Mains Export Power</i> alarm to protect against undesired power export.</p> <p>The operation of this setting depends on the parallel mode selected:</p> <p>Bus: The percentage of total kW the Generator Bus to produce whilst in continuous parallel with the mains.</p> <p>Mains: The percentage of the Mains kW rating the Generator Bus is to maintain whilst in continuous parallel.</p>
Maximum var Level	<p>NOTE: When in <i>Bus Mode</i> if <i>Maximum kvar Level</i> is greater than the load, power is exported to the mains.</p> <p>The percentage of total kvar the Generator Bus to produce whilst in continuous parallel with the mains.</p>
Power Factor	The power factor the Generator Bus is to produce whilst in continuous parallel with the mains.

Ramp Rates


NOTE: These adjustable parameters do not change the module's configuration settings. These settings enable the user to change the values dynamically via SCADA or the module's internal PLC based on operating requirements.



Parameter	Description
Ramp Up Rate	The rate at which the Generator Bus is ramped onto the load.
Ramp Down Rate	The rate at which the Generator Bus is ramped off the load.
Power Ramp on Setpoint Change	When changing between <i>Power Control</i> modes or changing the set point, the <i>Ramp Rate</i> defines how fast the Generator Bus power changes in percentage points per second.
Reactive Power Ramp on Setpoint Change	When changing between <i>Reactive Power Control</i> modes or changing the set point, the <i>Ramp Rate</i> defines how fast the Generator Bus power changes in percentage points per second.

3.7 MAINS

The *Mains* section is subdivided into smaller sections. Select the required section with the mouse.



3.7.1 FREQUENCY AND VOLTAGES

This section displays the module's measurement of the *Mains* frequency, voltage and current supply.

Frequency		
50.01 Hz		
Phase Rotation		
L1-L2-L3		
Phase To Neutral Voltages		
L1 - N 226.3 V	L2 - N 226.4 V	L3 - N 226.3 V
Phase To Phase Voltages		
L1 - L2 391.7 V	L2 - L3 392.1 V	L3 - L1 392.1 V
Mains Current		
L1 82.0 A	L2 84.0 A	L3 87.0 A
Fault Ride Through		
27 Events		

3.7.2 POWER

This section displays the module's measurement of the *Power* the *Mains* is supplying.

Watts			
L1	L2	L3	Total
67.64 kW	59.64 kW	64.20 kW	191.64 kW 39.2 %

VA			
L1	L2	L3	Total
62.6 kVA	55.8 kVA	78.6 kVA	196.9 kVA

VAr			
L1	L2	L3	Total
4.2 kVAr	5.2 kVAr	6.0 kVAr	15.4 kVAr

Power factor			
L1	L2	L3	Average
0.97	0.94	1.00	1.00


Accumulated Power		
kWh	kVAh	kVArh
151004.9 kWh	155852.9 kVAh	2977.7 kVArh

3.8 ALARMS

This section displays the alarms that are currently active on the module. For information in regards to alarm descriptions, refer to DSE publication: **057-259 DSE8660 MKII Operation Manual** which is found on the DSE website: www.deepseaelectronics.com.

For information in regard to alarm severity, refer to section entitled *Alarm Types* elsewhere within this document.

Alarms



3.9 STATUS

This section displays the status information about the module.

Supervisor State At Rest	Software Version Main version: 5.1.2 Bootloader: 3.0.30 Co-Processor: 1.3.2 Auxiliary: 2.0.28
Mains Detection State Mains Failed	Module ID 691EBDF560
Load Switching State Mains On Load	Mode 
Heater Fitted No Heater Fitted	

3.10 EVENT LOG

This section displays the events which are recorded with the module's event log along with the time, date in which they occurred. For further details on how what events are recorded, refer to section entitled *Event Log* elsewhere within this document.

For information in regards to alarm descriptions, refer to DSE publication: **057-259 DSE8660 MKII Operation Manual** which is found on the DSE website: www.deepseaelectronics.com.

#	Date	Time	Hours Run	Event	Details
1	23/04/2019	14:15:17	0:00	Mains	Mains fail
2	23/04/2019	14:15:16	0:00	Warning	Mains Failed To Close
3	23/04/2019	14:15:14	0:00	Restart	Power Up
4	23/04/2019	14:12:16	0:00	Mains	Mains fail
5	23/04/2019	14:12:15	0:00	ETrip	Expansion Unit Watchdog Alarm
6	23/04/2019	14:12:15	0:00	ETrip	Expansion Unit Watchdog Alarm
7	23/04/2019	14:12:15	0:00	ETrip	Expansion Unit Watchdog Alarm
8	23/04/2019	14:12:15	0:00	ETrip	Expansion Unit Watchdog Alarm
9	23/04/2019	14:12:13	0:00	Restart	Power Up
10	13/04/2018	08:45:43	0:00	ETrip	Expansion Unit Watchdog Alarm
11	13/04/2018	08:45:43	0:00	ETrip	Expansion Unit Watchdog Alarm
12	13/04/2018	08:45:43	0:00	ETrip	Expansion Unit Watchdog Alarm
13	13/04/2018	08:45:43	0:00	ETrip	Expansion Unit Watchdog Alarm
14	13/04/2018	08:44:38	0:00	Mains	Mains fail
15	13/04/2018	08:44:36	0:00	Warning	Mains Failed To Close
16	13/04/2018	08:44:35	0:00	Restart	Power Up
17	13/04/2018	08:43:33	0:00	Mains	Mains fail
18	13/04/2018	08:43:31	0:00	Warning	Mains Failed To Close
19	13/04/2018	08:43:30	0:00	Restart	Power Up
20	13/04/2018	08:38:19	0:00	Mains	Mains fail
21	13/04/2018	08:38:17	0:00	Warning	Mains Failed To Close
22	13/04/2018	08:38:16	0:00	Restart	Power Up
23	13/04/2018	08:35:40	0:00	Mains	Mains fail
24	13/04/2018	08:35:38	0:00	Warning	Mains Failed To Close
25	13/04/2018	08:35:37	0:00	Restart	Power Up
26	13/04/2018	08:31:11	0:00	Mains	Mains fail

Export to Excel Export to CSV Export to PDF Print event log


Click to save the log to an Excel or csv file for use in an external spreadsheet

Click to save the log to a pdf (Adobe Acrobat) file.

Click to print the log


3.11 REMOTE CONTROL

This section displays and controls the status of the module's *Remote Control* functions. Any of the module's outputs, expansion outputs, LED indicators, expansion LEDs indicators or PLC Flag Tests are to be configured to *Remote Control 1 to 10*. They are provided to enable control using the SCADA section of the DSE Configuration Suite or by third party PLC or Building Management Systems (for example) using the MODBUS protocol. For further details on how to configure these items, refer to section entitled *Digital Outputs* elsewhere within this document.



3.12 MAINTENANCE

The *Maintenance* section is subdivided into smaller sections. Select the required section with the mouse.



3.12.1 EXPANSION CALIBRATION

This section allows the analogue sensor inputs of the DSE2130 and DSE2131 expansion modules to be calibrated to remove inaccuracies caused by the tolerance of the sensor devices. While the Generator Bus is running, the instruments are calibrated, and reference needs to be made to a third party accurate sensing device to ensure accurate recalibration.

Expansion Calibration
2130 DSENet ID 0
2130 DSENet ID 1
2130 DSENet ID 2
2130 DSENet ID 3
2131 DSENet ID 0
2131 DSENet ID 1
2131 DSENet ID 2
2131 DSENet ID 3

The screenshot displays the 'Expansion Calibration' interface with the following components and callouts:

- Analogue Input A:** A slider set to '0 Bar'. Callout: "The value for the sensor as displayed on the module's display".
- Analogue Input B:** A slider set to 'Not configured'. Callout: "Adjust the slider to alter the module's calibration for the sensor".
- Analogue Input C:** A slider set to 'Fault'.
- Analogue Input D:** A slider set to '20 %'.
- Reset:** A 'Reset to Default' button. Callout: "Click to reset all the recalibration settings back to default."

3.12.2 TIME

This section allows the date and time to be adjusted on the controller.

The screenshot displays a SCADA interface for time adjustment, divided into four sections:

- Module Date:** Shows the current date as 05/04/2019. A callout indicates: "Display of the module's current date and time".
- Module Time:** Shows the current time as 12:38:16. A callout indicates: "Type the new date / time or click the up and down arrows to change the settings".
- Set Date And Time:** Contains two dropdown menus for "Date" (05/04/2019) and "Time" (12:38:12), and a "Set" button. A callout for the dropdowns says: "Type the new date / time or click the up and down arrows to change the settings". A callout for the "Set" button says: "Click Set to adjust the module to the selected date/time."
- Set To PC Time:** Shows "Date 05/04/2019" and "Time 13:38:00" with a "Set To PC Time" button. A callout says: "Click Set to adjust the module to the date/time that the PC is set to."

3.12.3 ACCUMULATED INSTRUMENTATION

This section allows the Mains accumulated instrumentation to be adjusted on the controller.

The screenshot displays a control interface for accumulated instrumentation, organized into five horizontal sections:

- kWh:** Shows a current value of 30.6 kWh. A callout box points to the '30.6' value, stating: "Display of the module's current value for the parameter."
- kVAh:** Shows a current value of 38.2 kVAh. A callout box points to the '38.2' value, stating: "Type the new value or click the up and down arrows to change the settings."
- kVArh:** Shows a current value of 22.7 kVArh. A callout box points to the 'Set' button, stating: "Click Set to adjust the module to the selected value."
- Fault Ride Through:** Shows a current value of 19 Events. A callout box points to the 'Set' button, stating: "Click Set to adjust the module to the selected value."
- Reset:** Contains a button labeled "Reset all values to zero". A callout box points to this button, stating: "Click to reset all the accumulated instrumentation counters to zero."


3.12.4 MODULE PIN

! CAUTION!: If the module PIN is lost or forgotten, it is no longer possible to access or make changes to the module!

This section allows the user to configure a PINs (Personal Identification Number) within the module.


Module Configuration Write Password

This Write PIN must be entered to access the modules *Main Front Panel Configuration Editor* or, when writing a configuration / changing a value in SCADA using the DSE Configuration Suite PC Software.



Module Configuration Read Password

This Read PIN must be entered when reading a configuration / data log files, or accessing the SCADA section.




3.13 COMMUNICATIONS INFORMATION

This section displays the information about the configuration of the module's ethernet port. For further details on how to configure the module's ethernet port, refer to section entitled *Ethernet* elsewhere within this document.

IP address 192 . 168 . 1 . 100	MAC Address E8 : A4 : C1 : 2 : 8D : 7
Subnet Mask 255 . 255 . 255 . 0	DNS 8 . 8 . 8 . 8
Host DSE Host	MODBUS Preferred IP Address 192 . 168 . 1 . 99
Domain DSE Module	MODBUS Connection Port 502
Gateway 192 . 168 . 1 . 1	DHCP Off
	TCP Vendor DSE Vender

3.14 DATA LOG

This section displays and temporarily records the instruments configured within the module's *Data Logging* facility to the PC. The data which is temporarily recorded is only for the duration in which the *Data Log* section is viewed. For further details on how to configure these items, refer to section entitled *Data Logging* elsewhere within this document.




3.15 PLC

NOTE: This section is only available on the pre-version 5 software of the module. For further details and instructions on how to utilise the *PLC*, refer to DSE publication: *057-175 PLC Programming Guide for DSE Controllers*, which is found on the DSE website: www.deepseaelectronics.com.


NOTE: On module software versions 6.1 and later, the *Connect SCADA* is available within the *PLC Editor* accessed from the main configuration's PLC section. For further details and instructions on the *PLC Editor*, refer to DSE Publication: *057-314 Advanced PLC Software Manual* which is found on our website: www.deepseaelectronics.com

The *PLC* section is subdivided into smaller sections. Select the required section with the mouse.



3.15.1 PLC LOGIC

This section displays the real-time status of the *PLC Logic* configured within the module. This section is useful for assisting with fault finding issues relating to or caused by the *PLC Logic*.



3.15.2 PLC STORES

The *PLC Stores* section is subdivided into smaller sections. Select the required section with the mouse.



The selected section displays the value currently set for each *Store* and provides the user with the ability to change that value. *Stores* are used within the module's PLC to affect mathematical equations or change set points within the created PLC functions.

Store	Value	Control	Action
Store 1	0	Spin	Set
Store 2	0	Spin	Set
Store 3	0	Spin	Set
Store 4	0	Spin	Set
Store 5	0	Spin	Set
Store 6	0	Spin	Set
Store 7	0	Spin	Set
Store 8	0	Spin	Set
Store 9	0	Spin	Set
Store 10	0	Spin	Set
Store 11	0	Spin	Set
Store 12	0	Spin	Set
Store 13	0	Spin	Set
Store 14	0	Spin	Set
Store 15	0	Spin	Set
Store 16	0	Spin	Set
Store 17	0	Spin	Set
Store 18	0	Spin	Set
Store 19	0	Spin	Set
Store 20	0	Spin	Set


Display of the module's current value for the parameter.

Type the new value or click the up and down arrows to change the settings.

Click Set to adjust the module to the selected value.

3.16 EXPANSION

The *Expansion* section is subdivided into smaller sections. Select the required section with the mouse.



The selected section displays the status of the expansion module's inputs/outputs/LEDs etc and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Expansion* in the *Edit Config* section elsewhere within this document. An example status of a DSE2157 Output Expansion is shown below.

The screenshot shows the status of an expansion module with three main sections:

- Communications:** Shows "Communications OK" with a green indicator light. A callout explains: "State of communication to the expansion module".
- Relay Outputs (Normally Open):** Lists items A through D. Each has an "Active" indicator (green light) and an "Open / Closed" switch icon. A callout explains: "State of the output (open or closed)".
- Relay Outputs (Changeover):** Lists items E through H. Each has an "Active" indicator (green light) and an "Open / Closed" switch icon.

A detailed callout for item G (PLC Output Flag 6) states: "Shows if the output channel is active or not. This output is open and is active. The output is configured to be *PLC Output Flag 6 De-Energise*."

4 ALARM TYPES

The protection included with the DSE control modules provides increasing levels of notification, depending upon the severity of the situation:

Alarm Type	Description
Indication	No audible alarm or common warning signal occurs. <i>Indication</i> alarms are only used to illuminate indicators, activate outputs or checked by the module's internal PLC.
Warning	Audible alarm and common alarm signal is generated. The Generator Bus continues to run. <i>Warning alarms</i> are used to draw the operator's attention to a minor issue or to a problem that may escalate to an Electrical Trip if left untreated.
Electrical Trip	Audible alarm and common alarm signal are generated. The Generator Bus is taken off load and the cooling timer begins, after which the set is stopped. <i>Electrical Trip alarms</i> are series issues that require the Generator Bus to be taken off load. As the name implies, this is often electrical faults that occur 'after' the load switch. The Generator Bus is allowed to cool before stopping.
Auxiliary Mains Failure	The module operates as if the incoming Mains supply has fallen outside of limits, the Generator Bus is instructed to start and take the load. Deactivation of this alarm causes the module to act as the Mains has returned to within limits providing that the Mains sensing also indicates that the Mains is within limits.

5 ALARM ARMING

The protections on the DSE module are active during their configured *Alarm Arming* setting. The table below shows the timing segment for the different *Alarm Arming* options with regards to the Generator Bus status.

Timing Segment	Bus and Mains Open	Bus Available / Bus on Load	Mains Available / Mains on Load	Bus and Mains in Parallel
Active from Mains Parallel				
Always				
Never				

5.1 NEVER

The protection is never active on the controller. This is used to disable the protection.

5.2 ALWAYS

The protection is always active on the controller. This is used to constantly monitor statuses such as an external Mains protection device regardless of the state of the Generator Bus.

5.3 ACTIVE FROM MAINS PARALLEL

The protection is active when the Generator Bus is running in parallel with the mains.

Page is Left Intentionally Blank