



DEEP SEA ELECTRONICS

DSEL401 MKII Configuration Suite

PC Software Manual

Document Number: 057-222

Author: Ashley Senior





Deep Sea Electronics Ltd.

Highfield House
Hunmanby
North Yorkshire
YO14 0PH
England

Sales Tel: +44 (0) 1723 890099

E-mail: sales@deepseaelectronics.com

Website: www.deepseaelectronics.com

DSEL401 MKII Configuration Suite PC Software Manual

© Deep Sea Electronics Ltd.

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Ltd. at the address above.

The DSE logo and the names DSE^{Genset}®, DSE^{ATS}®, DSE^{Power}® and DSE^{Control}® are UK registered trademarks of Deep Sea Electronics Ltd.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Ltd. reserves the right to change the contents of this document without prior notice.

Amendments Since Last Publication

Issue	Comments
1	Initial release
1.1	Checked text and corrected minor typos
2	Amended to include new module features: <ul style="list-style-type: none">- Limit Audible Alarm Duration- Mains Supply- Light Output Override- Power Save Mode digital input- Auto Retry on Loss of Crank Disconnect
3	Amended to include new module features: <ul style="list-style-type: none">- Sunrise / Sunset scheduling options- Block Heater output- Fuel Pull In Coil output- Generator Within Standards output- Engine Interface 7 support- Increased mast control functionality
4	<ul style="list-style-type: none">- Generator Options changed to suit new DC Topology's- Manual Mode Description added
5	<ul style="list-style-type: none">- Added Crank Disconnect on Oil Pressure Delay- Updated Style of document

Typeface: The typeface used in this document is *Arial*. Care must be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

TABLE OF CONTENTS

SECTION	PAGE
1 INTRODUCTION.....	5
1.1 CLARIFICATION OF NOTATION.....	6
1.2 GLOSSARY OF TERMS	6
1.3 BIBLIOGRAPHY	8
1.3.1 INSTALLATION INSTRUCTIONS	8
1.3.2 MANUALS.....	8
1.3.3 TRAINING GUIDES.....	8
1.3.4 THIRD PARTY DOCUMENTS	9
1.4 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE	9
2 EDITING THE CONFIGURATION	10
2.1 SCREEN LAYOUT	10
2.2 MODULE.....	11
2.2.1 MODULE OPTIONS	11
2.2.2 CONFIGURABLE FRONT PANEL EDITOR.....	15
2.3 APPLICATION	16
2.4 INPUTS.....	17
2.4.1 OIL PRESSURE	17
2.4.2 COOLANT TEMPERATURE.....	19
2.4.3 FUEL LEVEL	21
2.4.3.1 FUEL LEVEL ALARMS.....	21
2.4.3.2 LOW FUEL OUTPUTS	25
2.4.4 CREATING / EDITING THE SENSOR CURVE	26
2.4.5 DIGITAL INPUTS.....	27
2.4.5.1 INPUT FUNCTIONS	28
2.5 DIGITAL OUTPUTS	31
2.5.1 OUTPUT SOURCES	32
2.6 TIMERS.....	37
2.6.1 START TIMERS	38
2.6.2 LOAD / STOPPING TIMERS	39
2.6.3 LIGHTING TIMERS	40
2.6.4 MODULE TIMERS.....	42
2.7 GENERATOR	43
2.7.1 GENERATOR OPTIONS	43
2.7.2 GENERATOR VOLTAGE	45
2.7.3 GENERATOR FREQUENCY.....	47
2.7.4 GENERATOR CURRENT	49
2.8 MAINS SUPPLY.....	50
2.9 LOAD CONTROL.....	53
2.10 ENGINE.....	54
2.10.1 ENGINE PROTECTION.....	54
2.10.2 DEF LEVEL	56
2.10.3 ENGINE OPTIONS.....	57
2.10.4 ENGINE HEATING OPTIONS	59
2.10.5 ECU (ECM) OPTIONS.....	61
2.10.6 ECU (ECM) ALARMS	63
2.10.6.1 ECU (ECM) DATA FAIL.....	63
2.10.6.2 DM1 SIGNALS	64
2.10.6.3 OTHER SPECIFIC SIGNALS.....	66
2.10.7 GAS ENGINE OPTIONS.....	69
2.10.8 CRANK DISCONNECT.....	70
2.10.9 SPEED SETTINGS.....	71
2.10.10 PLANT BATTERY	72
2.11 SCHEDULER.....	74
2.11.1 SCHEDULER OPTIONS.....	74
2.11.2 BANK 1 / BANK 2	76

2.12	MAINTENANCE ALARM	77
2.13	ALTERNATIVE CONFIGURATION	78
2.13.1	CONFIGURATION OPTIONS	78
2.13.2	ALTERNATIVE CONFIGURATIONS EDITOR	79
3	SCADA	80
3.1	MIMIC	81
3.2	DIGITAL INPUTS	82
3.3	DIGITAL OUTPUTS	82
3.4	GENERATOR	83
3.5	MAINS SUPPLY	84
3.6	POWER	85
3.7	ENGINE	86
3.8	FLEXIBLE SENSOR	86
3.9	ALARMS	87
3.10	STATUS	88
3.11	EVENT LOG	89
3.12	MAINTENANCE	90
3.12.1	MAINTENANCE ALARM RESET	90
3.12.2	HOURS RUN AND NUMBER OF STARTS	91
3.12.3	DATE AND TIME	91
3.12.4	ACCUMULATED INSTRUMENTATION	92
3.12.5	DPF REGENERATION	92
3.12.6	MODULE PIN	93
3.12.7	LCD CONTRAST	94
4	ALARM TYPES	95
5	ALARM ARMING	96
5.1	NEVER	97
5.2	ALWAYS	97
5.3	WHEN STATIONARY	97
5.4	FROM STARTING	97
5.5	OVERSHOOT	97
5.6	FROM SAFETY ON	97

1 INTRODUCTION

This document details the use of the *DSE Configuration Suite PC Software* with the DSEL401 MKII module, which is part of the DSE **Genset**® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. DSE do not automatically inform on updates. Any future updates of this document are included on the DSE website at www.deepseaelectronics.com




The *DSE Configuration Suite PC Software* allows the DSEL401 MKII module to be connected to a PC via USB A to USB B cable (USB printer cable). Once connected, the software allows easy, controlled access to various operating parameters within the module which can then be viewed and edited as required.

The *DSE Configuration Suite PC Software* must only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the panel / generating set to which it is fitted. Access to critical operational sequences and settings for use by qualified engineers, may be barred by a security code set by the generator provider.

The information contained in this manual must be read in conjunction with the information contained in the appropriate module documentation. This manual only details which settings are available and how they may be used. Separate manuals deal with the operation of the individual module and its ancillaries, refer to section entitled *Bibliography* elsewhere in this document for further information.

1.1 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

	NOTE:	Highlights an essential element of a procedure to ensure correctness.
	CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
	WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

1.2 GLOSSARY OF TERMS

Term	Description
DSEL4xx	All modules in the DSEL4xx range.
DSEL401 MKII	DSEL401 MKII module/controller
CAN	Controller Area Network Vehicle standard to allow digital devices to communicate to one another.
CT	Current Transformer An electrical device that takes a large AC current and scales it down by a fixed ratio to a smaller current.
DEF	Diesel Exhaust Fluid (AdBlue) A liquid used as a consumable in the SCR process to lower nitric oxide and nitrogen dioxide concentration in engine exhaust emissions.
DM1	Diagnostic Message 1 A DTC that is currently active on the engine ECU.
DM2	Diagnostic Message 2 A DTC that was previously active on the engine ECU and has been stored in the ECU's internal memory.
DPF	Diesel Particulate Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas.
DPTC	Diesel Particulate Temperature Controlled Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas which is temperature controlled.
DTC	Diagnostic Trouble Code The name for the entire fault code sent by an engine ECU.
ECU/ECM	Engine Control Unit/Management An electronic device that monitors engine parameters and regulates the fuelling.
FMI	Failure Mode Indicator A part of DTC that indicates the type of failure, e.g. high, low, open circuit etc.

Continued over page...

Term	Description
Fuel Tank Bund	An external tank used to collect fuel that may leak or overflow from the fuel tank. This tank may also be integral to the main fuel tank. A level switch is usually located within the Bund to indicate the presence of the leak or overflow condition. May be called Retention Tank in some locales.
HEST	High Exhaust System Temperature Initiates when DPF filter is full in conjunction with an extra fuel injector in the exhaust system to burn off accumulated diesel particulate matter or soot.
HMI	Human Machine Interface A device that provides a control and visualisation interface between a human and a process or machine.
IEEE	Institute of Electrical and Electronics Engineers
LED	Light Emitting Diode
OC	Occurrence Count A part of DTC that indicates the number of times that failure has occurred.
PGN	Parameter Group Number A CANbus address for a set of parameters that relate to the same topic and share the same transmission rate.
SCADA	Supervisory Control And Data Acquisition A system that operates with coded signals over communication channels to provide control and monitoring of remote equipment
SCR	Selective Catalytic Reduction A process that uses DEF with the aid of a catalyst to convert nitric oxide and nitrogen dioxide into nitrogen and water to reduce engine exhaust emission.
SPN	Suspect Parameter Number A part of DTC that indicates what the failure is, e.g. oil pressure, coolant temperature, turbo pressure etc.

1.3 BIBLIOGRAPHY

This document refers to, and is referred by the following DSE publications which are obtained from the DSE website: www.deepseaelectronics.com or by contacting DSE technical support: support@deepseaelectronics.com.

1.3.1 INSTALLATION INSTRUCTIONS

Installation instructions are supplied with the product in the box and are intended as a 'quick start' guide only.

DSE Part	Description
053-172	DSEL401 MKII Installation Instructions

1.3.2 MANUALS

Product manuals are obtained from the DSE website: www.deepseaelectronics.com or by contacting DSE technical support: support@deepseaelectronics.com.

DSE Part	Description
057-151	DSE Configuration Suite PC Software Installation & Operation Manual
057-004	Electronic Engines and DSE Wiring
057-221	DSEL401 MKII Operator Manual

1.3.3 TRAINING GUIDES

Training guides are provided as 'hand-out' sheets on specific subjects during training sessions and contain specific information regarding to that subject.

DSE Part	Description
056-005	Using CTs With DSE Products
056-006	Introduction to Comms
056-010	Over Current Protection
056-022	Switchgear Control
056-023	Adding New CAN Files
056-026	kVA, kW, kvar and Power Factor
056-029	Smoke Limiting
056-030	Module PIN Codes
056-051	Sending DSEGencomm Control Keys
056-055	Alternate Configurations
056-069	Firmware Update
056-076	Reading DSEGencomm Alarms
056-079	Reading DSEGencomm Status
056-080	MODBUS
056-081	Screen Heaters
056-082	Override Gencomm PLC Example
056-091	Equipotential Earth Bonding
056-092	Best Practices for Wiring Restive Sensors
056-095	Remote Start Input Functions
056-097	USB Earth Loops and Isolation
056-099	Digital Output to Digital Input Connection

1.3.4 THIRD PARTY DOCUMENTS

The following third party documents are also referred to:

Reference	Description
ISBN 1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Institute of Electrical and Electronics Engineers Inc
ISBN 0-7506-1147-2	Diesel generator handbook. L.L.J. Mahon
ISBN 0-9625949-3-8	On-Site Power Generation. EGSA Education Committee.


1.4 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE

For information in regards to installing and using the *DSE Configuration Suite PC Software*, refer to DSE publication: **057-151 DSE Configuration Suite PC Software Installation & Operation Manual** found on the DSE's website: www.deepseaelectronics.com

2 EDITING THE CONFIGURATION


The software is broken down into separate sections to provide simple navigation whilst editing the module's configuration to suit a particular application.

2.1 SCREEN LAYOUT




2.2 MODULE

The *Module* section is subdivided into smaller sections. Select the required section with the mouse.





2.2.1 MODULE OPTIONS

Module Options




Parameter	Description
Lamp Test At Power Up	<input type="checkbox"/> = Feature disabled <input checked="" type="checkbox"/> = All the LEDs on the module's fascia illuminate when the DC power is applied as a 'lamp test' feature.
Protected Start Mode	<input type="checkbox"/> = Pressing the Start button on the module initiates the starting sequence <input checked="" type="checkbox"/> = The Start button needs to be pressed twice to confirm a manual start request. When the Start button is pressed once the module waits for 30 seconds for the next press to start the generator in Manual mode, if the Start button is not pressed a second time within the next 30 seconds, the mode changes to Stop mode for safety.
Power Save Mode Enable	<input type="checkbox"/> = Normal operation <input checked="" type="checkbox"/> = Module goes into power save (low current) mode after 1m of inactivity in STOP mode. Press any button to 'wake' the module.

Parameters are continued overleaf...

Parameter	Description
Deep Sleep Mode Enable	 NOTE: Available only if Power Save Mode is Enabled <input type="checkbox"/> = Normal operation <input checked="" type="checkbox"/> = When enabled, the module goes into a deeper sleep state with maximum power saving
Display SPN Strings	<input type="checkbox"/> = The module displays CAN messages in manufacturer numerical code. <input checked="" type="checkbox"/> = The module displays CAN messages in ENGLISH text alongside the manufacturer numerical code.
Event Log in Hours Run	<input type="checkbox"/> = Recorded events in the module's event log include the date/time stamp <input checked="" type="checkbox"/> = The engine run hours is added to the recorded event in the event log
Enable Fast Loading	 NOTE: Enabling Fast Loading is only recommended where steps have been taken to ensure rapid start up of the engine is possible. (For example when fitted with engine heaters, electronic governors etc.) <input type="checkbox"/> = Normal Operation, the safety on timer is observed in full. This feature is useful if the module is to be used with some small engines where premature termination of the delay timer leads to overspeed alarms on start up. <input checked="" type="checkbox"/> = The module terminates the safety on timer once all monitored parameters have reached their normal settings. This feature is useful if the module is to be used as a standby controller as it allows the generator to start and go on load in the shortest possible time.
Maintenance PIN Protected Enable	<input type="checkbox"/> = PIN is not required to reset maintenance alarms through the front panel. <input checked="" type="checkbox"/> = Maintenance alarm reset through the front panel is PIN protected.
Enable Cooldown in Stop Mode	<input type="checkbox"/> = Normal operation. Pressing the Stop button instantly opens the load switch and stops the generator. <input checked="" type="checkbox"/> = Alternative operation. Pressing the Stop button instantly opens the load switch and puts the generator into a cooling run. Pressing the Stop button again instantly stops the generator.
Power Up in Mode	Select the mode that the module enters when DC power is applied. Available modes to select from: Auto Manual Stop
Auto Light Control Enable	<input type="checkbox"/> = Feature is disabled. <input checked="" type="checkbox"/> = An additional control screen is shown under the module's Manual Control display section. When the set is started in Manual mode, the light outputs are controlled via the module's <i>Manual</i> Control display section. The light outputs follow the <i>Start Up Timers</i> and <i>Shutdown Timers</i> automatically.
All Light Control Enable	<input type="checkbox"/> = Feature is disabled. <input checked="" type="checkbox"/> = An additional control screen is shown under the module's <i>Manual Control</i> display section for controlling all light outputs together in Manual mode.
Individual Light Control Enable	<input type="checkbox"/> = Feature is disabled. <input checked="" type="checkbox"/> = Additional control screens are shown under the module's <i>Manual Control</i> display section for controlling light outputs individually in Manual mode.

Parameters are continued overleaf...

Parameter	Description
Auto Light Initiation When Started in Manual Mode	<input type="checkbox"/> = When the set is started in Manual mode, the light outputs are controlled via digital inputs or via the light control screens on the module display. <input checked="" type="checkbox"/> = When the set is started in Manual mode, the light outputs follow the <i>Start Up Timers</i> and <i>Shutdown Timers</i> automatically.
Disable Warnings	<input type="checkbox"/> = All Warnings are displayed on the front screen, in SCADA, logged in the event log and activate configured output sources. <input checked="" type="checkbox"/> = Warnings are suppressed from the front screen, SCADA and the event log. Configured output sources continue to follow warning state.
All Warnings Are Latched	<input type="checkbox"/> = Normal Operation, the warnings and pre-alarms automatically reset once the triggering condition has cleared. <input checked="" type="checkbox"/> = Warnings and pre-alarms latch when triggered. Resetting the alarm is performed by either an external reset applied to one of the inputs or, the 'Stop/Reset' pushbutton must be operated (once the triggering condition has been cleared).
Enhanced Tier IV Home Screen	<input type="checkbox"/> = Normal operation, the module shows the default home screen <input checked="" type="checkbox"/> = The module's home screen is changed to show the Tier IV Lamps
Manual Mode	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">  NOTE: Should manual mast and light control be required in Manual Mode ensure <i>Manual Mast Control</i> and <i>All Light Control Enabled</i> are enabled. </div> <p>The mode allows the controller to be used in a generator only application.</p> <input type="checkbox"/> = Automatic control of the lights and mast is enabled when in manual mode. <input checked="" type="checkbox"/> = Automatic control of Mast and lights is disabled when in manual mode. Should the mast be deployed and the lights active they will automatically stow and turn off upon manual mode selection.
Manual Mast Control	<input type="checkbox"/> = The mast control in Manual mode is disabled. <input checked="" type="checkbox"/> = Normal operation, the mast control is enabled in both Manual and Auto modes.
Limit Audible Alarm Duration	<input type="checkbox"/> = Normal operation, the configured <i>Audible Alarm</i> digital output is active when any alarm is active on the controller. The <i>Audible Alarm</i> digital output is inactive when the alarm is muted or reset. <input checked="" type="checkbox"/> = The configured <i>Audible Alarm</i> digital output is active when any alarm is active on the controller for the duration of the <i>Audible Alarm Duration</i> timer. The <i>Audible Alarm</i> digital output is inactive when the alarm is muted or reset or when the <i>Audible Alarm Duration</i> timer expires.
Lower Mast on Electrical Trip	<input type="checkbox"/> = The mast is lowered upon activation of an Electrical Trip alarm. <input checked="" type="checkbox"/> = The mast is lowered upon activation of an Electrical Trip alarm.

Instrumentation Suppression

Instrumentation Suppression

Suppress the following instrumentation on the module screen

Generator Frequency <input type="checkbox"/>	Generator Voltage <input type="checkbox"/>
Mains Supply Frequency <input type="checkbox"/>	Mains Supply Voltage <input type="checkbox"/>
Current <input type="checkbox"/>	Power Factor <input type="checkbox"/>
kW <input type="checkbox"/>	kWh <input type="checkbox"/>
kVAr <input type="checkbox"/>	kVAh <input type="checkbox"/>
kVA <input type="checkbox"/>	kVAh <input type="checkbox"/>

Parameter	Description
Generator Frequency	<input type="checkbox"/> = The <i>Generator Frequency Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Generator Frequency Instrumentation</i> is suppressed.
Generator Voltage	<input type="checkbox"/> = The <i>Generator Voltage Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Generator Voltage Instrumentation</i> is suppressed.
Mains Supply Frequency	<input type="checkbox"/> = The <i>Mains Frequency Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Mains Frequency Instrumentation</i> is suppressed.
Mains Supply Voltage	<input type="checkbox"/> = The <i>Mains Voltage Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Mains Voltage Instrumentation</i> is suppressed.
Current	<input type="checkbox"/> = The <i>Current Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Current Instrumentation</i> is suppressed.
Power Factor	<input type="checkbox"/> = The <i>Power Factor Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Power Factor Instrumentation</i> is suppressed.
kW	<input type="checkbox"/> = The <i>kW Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kW Instrumentation</i> is suppressed.
kWh	<input type="checkbox"/> = The <i>kWh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kWh Instrumentation</i> is suppressed.
kvar	<input type="checkbox"/> = The <i>kvar Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kvar Instrumentation</i> is suppressed.
kvarh	<input type="checkbox"/> = The <i>kvarh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kvarh Instrumentation</i> is suppressed.
kVA	<input type="checkbox"/> = The <i>kVA Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kVA Instrumentation</i> is suppressed.
kVAh	<input type="checkbox"/> = The <i>kVAh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kVAh Instrumentation</i> is suppressed.

2.2.2 CONFIGURABLE FRONT PANEL EDITOR

The *Configurable Front Panel Editor* allows generator OEMs to create a PIN protected, customised *Front Panel Editor* with up to two security access levels. Items may be added or removed as required by the generator supplier.

The screenshot shows the 'Configurable Front Panel Editor' window. At the top, there is an 'Enable' checkbox which is checked. Below it is a table titled 'Module (33 items)' with two columns: 'Item' and 'Access'. The table lists various items and their corresponding access levels. At the bottom of the window, there are four input fields for PINs and confirmations for Level 1 and Level 2 access.

Item	Access
Contrast	Level 2 PIN
Fast Loading Enabled	No PIN
All Warnings Latched	Level 1 PIN
Lamp Test at Startup	Level 1 PIN
Power Save Mode Enable	No PIN
Deep Sleep Mode Enable	No PIN
Protected Start Enable	No PIN
Event Log Display Format	No PIN
DTC String Enable	Level 1 PIN
Pin Protected Maintenance Reset	Level 2 PIN
Stop Button Cooldown	Level 2 PIN
Use Module Oil Pressure	Level 1 PIN
Use Module Coolant Temp	No PIN

Level 1 PIN: **** Confirmation: ****
 Level 2 PIN: **** Confirmation: ****

Parameter	Description
Enable	<input type="checkbox"/> = Configuration parameters are all accessible from Front Panel Editor. <input checked="" type="checkbox"/> = The Configuration parameters depend on their Access level.
Access	Permits the relevant item to be edited through the Front Panel Editor of the module. Not in FPE: The item cannot be edited through the Front Panel Editor No PIN: Allowing access to edit the item with no PIN Level 1 PIN: The Front Panel Editor asks for the configured <i>Level 1 PIN</i> to allow access to the relevant item. Level 2 PIN: The Front Panel Editor asks for the configured <i>Level 2 PIN</i> to allow access to the relevant item.
Level 1 PIN	Set four digit PIN number, then repeat the PIN in the <i>Confirmation</i> to configure <i>Level 1 PIN</i> for this access level.
Level 2 PIN	Set four digit PIN number, then repeat the PIN in the <i>Confirmation</i> to configure <i>Level 2 PIN</i> for this access level.

2.3 APPLICATION

 **NOTE:** For further details and instructions on ECU options and connections, refer to DSE Publication: *057-004 Electronic Engines and DSE Controllers* which are found on our website: www.deepseaelectronics.com

ECU (ECM) Options

Engine Type Generic J1939

Alternative Engine Speed ☐

Parameter	Description
Engine Type	<p>Select the appropriate engine type</p> <p>Conventional Engine: Select this for a traditional (non-electronic) engine, either Energise to Run or Energise to Stop.</p> <p>Conventional Gas Engine: Select this for a traditional (non-electronic) engine and require Gas engine functionality. This enables control of configurable outputs for <i>Gas Choke</i> and <i>Gas Ignition</i> and instructs the module to follow the gas engine timers.</p> <p>Other Engines: The list of supported CAN (or Modbus) engines is constantly updated, check the DSE website at www.deepseaelectronics.com for the latest version of Configuration Suite software.</p>
Alternative Engine Speed	<p><input type="checkbox"/> = The engine is instructed to run at its <i>Nominal Speed</i> as configured by the Engine Manufacturer.</p> <p><input checked="" type="checkbox"/> = The engine is instructed to run at its <i>Alternative Speed</i> as configured by the Engine Manufacturer.</p>

2.4 INPUTS

The *Inputs* section is subdivided into smaller sections.
Select the required section with the mouse.

Inputs

[Oil Pressure](#)
[Coolant Temperature](#)
[Fuel Level](#)
[Digital Inputs](#)

2.4.1 OIL PRESSURE

Input Type

Input Type

Input Type Pressure Sensor ▾

Parameter	Description
Input Type	Select what the analogue input is to be used for: Digital Input: Configured as an additional digital input. Pressure Sensor: Configured to measure engine oil pressure. <i>Low Oil Pressure</i> protection configured under the <i>Engine</i> section of the configuration.

Pressure Sensor

 **NOTE:** Only applicable when *Input Type* is configured as *Pressure Sensor*.

Pressure Sensor

Input Type VDO 10 Bar ▾ Edit...

Click to edit the sensor curve. See section entitled *Editing The Sensor Curve*.

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve

Oil Sensor Open Circuit Alarm

 **NOTE:** Only applicable when *Input Type* is configured as *Pressure Sensor*.

Oil Sensor Open Circuit Alarm


Enable Open Circuit Alarm ☒



Parameter	Description
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Oil Pressure Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected

Analogue Input A (Digital)

 **NOTE:** Only applicable when *Input Type* is configured as *Digital Input*.

Analogue Input A (Digital)

Function	User Configured ▼
Polarity	Close to Activate ▼
Action	Shutdown ▼
Arming	Never ▼
Activation Delay	0s 

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Shutdown Warning
Arming	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the alarm generated by the input becomes active: Always From Safety On From Starting Never
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.4.2 COOLANT TEMPERATURE

Input Type

Input Type

Input Type Temperature Sensor

Parameter	Description
Input Type	Select what the analogue input is to be used for: Digital Input: Configured as an additional digital input. Temperature Sensor: Configured to measure engine coolant temperature. <i>High Coolant Temperature</i> protection configured under the <i>Engine</i> section of the configuration.

Pressure Sensor

 **NOTE:** Only applicable when *Input Type* is configured as *Temperature Sensor*.

Temperature Sensor

Input Type VDO 120 °C Edit...

Click to edit the sensor curve. See section entitled *Editing The Sensor Curve*.

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve

Oil Sensor Open Circuit Alarm

 **NOTE:** Only applicable when *Input Type* is configured as *Temperature Sensor*.

Temperature Sensor Open Circuit Alarm

Enable Open Circuit Alarm ☐



Parameter	Description
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Coolant Sensor Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected

Analogue Input B (Digital)

 **NOTE:** Only applicable when *Input Type* is configured as *Digital Input*.

Analogue Input B (Digital)

Function	User Configured ▼
Polarity	Close to Activate ▼
Action	Warning ▼
Arming	Never ▼
Activation Delay 0s	<div style="width: 100%; height: 10px; background: linear-gradient(to right, #add8e6, #ffffff); border: 1px solid #add8e6; position: relative;"> <div style="position: absolute; right: 0; top: -5px; bottom: -5px; width: 10px; height: 10px; background-color: #add8e6; border-radius: 5px;"></div> </div>

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Shutdown Warning
Arming	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the alarm generated by the input becomes active: Always From Safety On From Starting Never
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.4.3 FUEL LEVEL

The *Fuel Level* section is subdivided into smaller sections.
Select the required section with the mouse.

Fuel Level

[Fuel Level Alarms](#)

[Low Fuel Outputs](#)

2.4.3.1 FUEL LEVEL ALARMS

Sender Usage

Sender Usage

Use sender as Fuel level sensor

Parameter	Description
Use Sender As	Select what the analogue input is to be used for: Fuel Level Sensor: Configured to measure engine fuel level. Flexible Sensor: Input can be configured as an additional digital input or a flexible analogue input.

Sensor Description

 **NOTE:** Only applicable when *Sender Usage* is configured as *Flexible Sensor*.

Sensor Description

Sensor Type Percentage Sensor

Parameter	Description
Sensor Type	Select what the analogue input is to be used for: Not Used: Analogue input is disabled. Digital Input: Configured as an additional digital input. Percentage Sensor: Configured as an additional level sensor. Pressure Sensor: Configured as an additional pressure sensor. Temperature Sensor: Configured as an additional temperature sensor.

Input Type

 **NOTE:** Not applicable when *Sender Usage* is configured as *Digital Input*.

Input Type


VDO Ohm range (10-180) Edit

Click to edit the sensor curve. See section entitled *Editing The Sensor Curve*.

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve

Sensor Alarms

 **NOTE:** Not applicable when *Sender Usage* is configured as *Digital Input*.



Sensor Alarms

Low Alarm Enable ☒

Action Shutdown

Low Alarm 10 %

Delay 0s

Low Pre-alarm Enable ☒

Low Pre-alarm Trip 25 %

Low Pre-alarm Return 30 %

Delay 0s

High Pre-alarm Enable ☒

High Pre-alarm Return 65 %

High Pre-alarm Trip 70 %



Delay 0s

High Alarm Enable ☒


Action Shutdown

High Alarm 90 %

Delay 0s

Parameter	Description
Alarm Arming	 NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. Select when the alarm generated by the analogue input becomes active: Always From Safety On From Starting
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Alarm Action	 NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. Select the type of alarm required from the list: Electrical Trip Shutdown
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.

Parameter descriptions are continued overleaf...

Parameter	Description
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	<div style="border: 1px solid black; padding: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: <i>Electrical Trip</i> <i>Shutdown</i>


Tank

 NOTE: Only applicable when <i>Sender Usage</i> is configured as <i>Fuel Level Sensor</i>.
--

Tank

Tank Size

Units Litres






Parameter	Description
Tank Size	Enter the size of the fuel tank where the fuel level sensor is fitted.
Units	Select the type of units to be used for the fuel level: <i>Imperial Gallons</i> <i>Litres</i> <i>US Gallons</i>

Analogue Input C (Digital)

 **NOTE:** Only applicable when *Input Type* is configured as *Digital Input*.


Analogue Input C (Digital)

Function	User Configured ▼
Polarity	Close to Activate ▼
Action	Shutdown ▼
Arming	Always ▼
Activation Delay	0s 

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Shutdown Warning
Arming	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the alarm generated by the input becomes active: Always From Safety On From Starting Never
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.4.3.2 LOW FUEL OUTPUTS

Low Fuel Shutdown Output 1 to 4 Alarm

 **NOTE:** Only applicable when *Sender Usage* is configured as *Fuel Level Sensor*.

Low Fuel Shutdown Output 1 Alarm

Enable ☒

Percentage 80 %

Delay 0s

Parameter	Description
Enable	<input type="checkbox"/> = The <i>Light Outputs</i> are not affected by the <i>Fuel Level</i> . <input checked="" type="checkbox"/> = The <i>Light Outputs</i> are automatically deactivated when the <i>Fuel Level</i> drops below <i>Low Fuel Shutdown Output</i> alarm level for the duration of the <i>Delay</i> time.

2.4.4 CREATING / EDITING THE SENSOR CURVE

While the *DSE Configuration Suite* holds sensor specifications for the most commonly used resistive sensors, occasionally it is required that the module be connected to a sensor not listed by the *DSE Configuration Suite*. To aid this process, a sensor curve editor is provided.

The sensor curve that is to be used by the analogue input or edited.

Click to edit the selected sensor curve or create a curve if a curve is not selected.

Input Type

Not Used

Create...

Sender Curve Editor

Custom sender curve: Unnamed curve

Click and drag the points on the graphs to change the settings

Use the mouse to select the graph point, then enter the value in the box or click up/down to change the value

Click *Interpolate* then select two points as prompted to draw a straight line between them.

Click SAVE AS, a prompt to name the curve...

New Curve Name

Enter a name for the new curve

OK

Cancel

Click OK to save the curve.


Click OK to accept the changes or CANCEL to ignore and lose the



Hint: Deleting, renaming or editing custom sensor curves that have been added is performed in the main menu, select *Tools | Curve Manager*.

Any saved curves become selectable in the *Input Type* selection list.

2.4.5 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div>  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Shutdown Warning
Arming	<div>  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the alarm generated by the input becomes active: Always From Safety On From Starting Never
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.


2.4.5.1 INPUT FUNCTIONS

Where a digital input is NOT configured as “user configured”, a selection is made from a list of predefined functions. The selections are as follows:

Under the scope of IEEE 37.2, *function numbers are also used to represent functions in microprocessor devices and software programs*. Where the DSE input functions are represented by IEEE 37.2, the function number is listed below.

Function	Description
Alarm Mute	This input is used to silence the audible alarm from an external source, such as a remote mute switch.
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the generator.
Alternative Configuration	These inputs are used to instruct the module to follow the <i>alternative</i> configuration settings instead of the <i>main</i> configuration settings.
Auto Start Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide an override function to prevent the controller from starting the generator in the event of a remote start condition occurring. If this input is active and a remote start signal occurs the module does not give a start command to the generator. When this input signal is removed, the controller operates as if a remote start has occurred, starting and loading the generator. This function is used to give an ‘ AND ’ function so that a generator is only called to start if a remote start occurs and another condition exists which requires the generator to run. If the ‘Auto start Inhibit’ signal becomes active once more it is ignored until the next remote start request. This input does not prevent starting of the engine in MANUAL mode.
Controlled Shutdown	This input allows an external source to tell the controller to lower the mast, i.e. a wind gauge at the top of the mast closes a relay switch. The light outputs deactivate and the normal stopping sequence is initiated.
Coolant Temperature Switch	This input is used to give a <i>Coolant Temperature High</i> shutdown from a digital normally open or closed switch. It allows coolant temperature protection.
Disable Mast Control	This input is used to ensure the light mast is kept in the current position. When active, the <i>Light Mast Up</i> and <i>Light Mast Down</i> outputs are constantly deactivated.
DPF Auto Regen Inhibit	This input is used to override the ECU (ECM) function and prevent the automatic regeneration of the diesel particulate filter
DPF Force Regeneration	This input is used to override the ECU (ECM) function and activate the regeneration of the diesel particulate filter
DPF Regeneration Interlock	This input is used to stop a manual regeneration from occurring
Emergency Stop	Provides an immediate engine hot shutdown, used in emergency situations
External Panel Lock	Locks the mode buttons on the module front fascia.
Fuel Tank Bund Level High	This input is connected to the fuel tank bund level switch. It provides feedback to the module that the level of fuel in the bund is too high, indicative of a leaking fuel tank.
Holding Supports Open	This input is used to provide a feedback to the module that the supports are open and is safe to activate the <i>Light Mast Up</i> digital output.

Function	Description
Inhibit Light Output 1, 2, 3 & 4 IEEE 37.2 - 52 Ac Circuit Breaker	This input is used to prevent the module from activating the corresponding light output. If the light output was already activated, activating this input causes the light output de-activation. Removing the input allows the light output to become active again.
Inhibit Scheduled Run IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide a mean of disabling a scheduled run.
Lamp Test	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LEDs illuminate.
Light Mast Fully Closed	This input is used to provide a feedback to the module that the light mast is fully closed. This input overrides the module's control for closing the mast both in Automatic and Manual modes.
Light Mast Fully Open	This input is used to provide a feedback to the module that the light mast is fully open. This input overrides the module's control for opening the mast both in Automatic and Manual modes.
Light Output Activate 1, 2, 3, & 4	If the module is running the genset off load, this input activates the corresponding light output.
Light Output Override	This is used to activate the digital outputs <i>Light Output 1, 2, 3 & 4</i> ; irrespective of the status of the generator supply and the <i>Mains Supply Active</i> digital input. This is useful for powering up the light outputs from an external supply. The light mast control is not affected by this input function.
Low Fuel Level Switch IEEE 37.2 - 71 Liquid Level Switch	Used to give a digital input function to provide a low fuel level alarm
Mains Supply Active	When this input is active the module's display changes the generator icon to mains. AC parameters such as Voltage, Frequency and Current are shown as Mains parameters. the generator starting is inhibited when this input is active. For further details, see the section entitled <i>Mains Supply</i> elsewhere in this document.
Maintenance Reset Alarm Air	Provides an external digital input to reset the maintenance alarm
Maintenance Reset Alarm Fuel	Provides an external digital input to reset the maintenance alarm
Maintenance Reset Alarm Oil	Provides an external digital input to reset the maintenance alarm
Oil Pressure Switch	A digital normally open or closed oil pressure switch gives this input. It allows low oil pressure protection.
Override Fuel Shutdown	This input provides a mean to prevent all Low Fuel Shutdown Output Alarms
Photocell Start	When in auto mode, the module performs the start sequence and activate all configured Light Outputs.
Power Save Mode	This is used to force the module into <i>Power Save Mode</i> .
Raise/Lower Mast	When this input becomes active, the <i>Light Mast Up</i> output is activated for the duration of the <i>Mast Up Time</i> timer. Upon removal of the input, the <i>Light Mast Down</i> output is activated for the duration of the <i>Mast Down Time</i> timer. This allows complete mast control via a single input function.
Remote Start Off Load	If this input is active, operation is similar to the 'Remote Start on load' function except that the generator is not instructed to take the load. This function are used where an engine only run is required e.g. for exercise.
Remote Start On Load	When in auto mode, the module performs the start sequence and activate all configured Light Outputs.

Function	Description
Simulate Auto Button	<p> NOTE: If a call to start is present when AUTO MODE is entered, the starting sequence begins. Call to Start comes from a number of sources depending upon module type and configuration and includes (but is not limited to) : Remote start input present, Scheduled run.</p> <p>This input mimic's the operation of the 'Auto' button and is used to provide a remotely located Auto mode push button.</p>
Simulate Start Button	This input mimic's the operation of the 'Start' button and is used to provide a remotely located start push button.
Simulate Stop Button	This input mimic's the operation of the 'Stop' button and is used to provide a remotely located stop/reset push button.
Smoke Limiting IEEE 37.2 – 18 Accelerating Or Decelerating Device	This input instructs the module to give a <i>run at idle speed</i> command to the engine either via an output configured to <i>smoke limit</i> or by data commands when used with supported electronic engines.
Water in Fuel	This input provides feedback from the water indicator switch on the fuel water separators and indicates water ingress in the fuel supply.

2.5 DIGITAL OUTPUTS

The screenshot shows a configuration window titled "Digital Outputs". It contains a list of outputs from Output A to Output J. Each output has a "Source" dropdown menu and a "Polarity" dropdown menu. The "Source" dropdowns are set to "Fuel Relay" for Output A, "Start Relay" for Output B, and "Light Output 1" through "Light Output 4" for Outputs C through F. The "Polarity" dropdowns are set to "Energise" for Outputs A through F, and "De-Energise" for Outputs G through J. Two callouts are present: one on the left stating "These labels match the typical wiring" pointing to the output labels, and one on the right stating "As this example shows outputs A and B are greyed out as the engine type is selected as Conventional Diesel." pointing to the greyed-out "Source" dropdowns for Output A and B.

These labels match the typical wiring

As this example shows outputs A and B are greyed out as the engine type is selected as Conventional Diesel.

Output	Source	Polarity
Output A	Fuel Relay	Energise
Output B	Start Relay	Energise
Output C	Light Output 1	De-Energise
Output D	Light Output 2	Energise
Output E	Light Output 3	Energise
Output F	Light Output 4	Energise
Output G	Preheat During Preheat Timer	Energise
Output H	Common Alarm	Energise
Output I	Common Warning	Energise
Output J	Common Shutdown	Energise

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital output polarity: De-Energise: When the output source is true, the output deactivates. Energise: When the output source is true, the output activates.


2.5.1 OUTPUT SOURCES

The list of output sources available for configuration of the module relay.



Under the scope of IEEE 37.2, *function numbers are also used to represent functions in microprocessor devices and software programs*. Where the DSE output functions are represented by IEEE 37.2, the function number is listed below.

The outputs are in alphabetical order with the *parameter* first. For instance for over frequency output, it's listed as *Generator Over Frequency*

Output Source	Active...	Inactive....
Not Used	The output does not change state (Unused)	
Air Filter Maintenance	Indicates that the air filter maintenance alarm is due	
Air Flap Relay	Used to control an air flap, this output becomes active upon an Emergency Stop or Over-speed situation.	Inactive when the set has come to rest
Analogue Input A, B & C (Digital)	Active when the relevant analogue input, configured as digital input, is active	
Audible Alarm IEEE 37.2 – 74 Alarm Relay	Use this output to activate an external sounder or external alarm indicator. Operation of the Mute pushbutton resets this output once activated.	Inactive if no alarm condition is active or if the Mute pushbutton was pressed.
Battery Over Voltage IEEE 37.2 – 59DC Overvoltage Relay	This output indicates that a Battery Over voltage alarm has occurred.	Inactive when battery voltage is not High
Battery Under Voltage IEEE 37.2 – 27DC Undervoltage Relay	This output indicates that a Battery Under Voltage alarm has occurred.	Inactive when battery voltage is not Low
Block Heater	Activated by the <i>Block Heater</i> function, in conjunction with the Coolant Temperature Sensor	
Charge Alternator Warning/Shutdown	Active when the charge alternator alarm is active	
Combined Gen/Mains Failure	Active when either the Generator or Mains supplies has failed	
Combined Mains Supply Failure	Active when a <i>Mains Failure</i> is detected	
Common Alarm	Active when one or more alarms (of any type) are active	The output is inactive when no alarms are present
Common Electrical Trip	Active when one or more <i>Electrical Trip</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Shutdown	Active when one or more <i>Shutdown</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Warning	Active when one or more <i>Warning</i> alarms are active	The output is inactive when no warning alarms are present
Controlled Shutdown	Active when the Controlled Shutdown input is active	
Coolant Temperature Switch IEEE 37.2 – Apparatus Thermal Device	Active when the Coolant Temperature Switch input is active	

Output Source	Active...	Inactive....
Cooling Down	Active when the Cooling timer is in progress	The output is inactive at all other times
DEF Level Low	Active when <i>DEF Level Low</i> CAN alarm is active.	
Digital Input A to F	Active when the relevant digital input is active	
Display Heater Fitted and ON	 NOTE: For further information on the display heater, refer to DSE Publication: 056-081 Screen Heaters which are found on our website: www.deepseaelectronics.com	
	Active when the LCD screen heater is active	
DPF Auto Regeneration Inhibit Request	Active when the <i>DPF Auto Regeneration Inhibit</i> is active	
DPF Forced Regeneration Requested	Active when the <i>DPF Force Regeneration</i> is active	
DPF Non Mission State	Active when the <i>DPF Non-Mission State</i> is active	
DPF Regeneration In Progress	Active when the <i>DPF Regeneration</i> is in progress	
DPF Regeneration Interlock Active	Active when the <i>DPF Regeneration Interlock</i> is active	
DPTC Filter	Active when the diesel particulate filter CAN alarm is active	
ECU (ECM) Data Fail	Becomes active when no CANbus data is received from the ECU after the safety delay timer has expired	Inactive when: <ul style="list-style-type: none"> • CANbus data is being received • The set is at rest During the starting sequence before the safety delay timer has expired
ECU (ECM) Power	Used to switch an external relay to power the CANbus ECU (ECM). Exact timing of this output is dependent upon the type of the engine ECU (ECM)	
ECU (ECM) Shutdown	The engine ECU (ECM) has indicated that a Shutdown alarm is present.	Inactive when no Shutdown alarm from the ECU (ECM) is present
ECU (ECM) Stop	Active when the DSE controller is requesting that the CANbus ECU (ECM) stops the engine.	
ECU (ECM) Warning	The engine ECU (ECM) has indicated that a Warning alarm is present.	Inactive when no Warning alarm from the ECU (ECM) is present
Emergency Stop	Active when the Emergency Stop alarm is active.	
Energise To Stop	Normally used to control an <i>Energise to Stop</i> solenoid, this output becomes active when the controller wants the set to stop running.	Becomes inactive a configurable amount of time after the set has stopped. This is the <i>ETS Hold Time</i> .
Fuel Filter Maintenance	Indicates that the fuel filter maintenance alarm is due	
Fuel Level High Alarm	Active when the level detected by the fuel level sensor has risen above the high fuel level alarm setting.	
Fuel Level High Pre-Alarm	Active when the level detected by the fuel level sensor has risen above the high fuel level pre-alarm setting.	
Fuel Level Low Alarm	Active when the level detected by the fuel level sensor has fallen below the low fuel level alarm setting.	
Fuel Level Low Pre-Alarm	Active when the level detected by the fuel level sensor has fallen below the low fuel level pre-alarm setting.	
Fuel Pull in Coil	Becomes active for the <i>Fuel Pull Coil Duration</i> amount of time when the <i>Fuel Relay</i> output is energised.	Becomes inactive when the <i>Fuel Pull Coil Duration</i> timer expires, or when the Fuel Relay output is de-energised.


Output Source	Active...	Inactive....
Fuel Relay	Becomes active when the controller requires the governor/fuel system to be active.	Becomes inactive whenever the set must be stopped, including between crank attempts, upon controlled stops and upon fault shutdowns.
Fuel Sender Trip 1, 2, 3 & 4	Active when the corresponding Low Fuel Shutdown Output Alarm is active	
Fuel Bund Level High	Active when the <i>Fuel Bund Level High Alarm</i> input is active.	
Gas Choke On	Becomes active during starting for the duration of the Gas Choke timer. Normally used to choke a gas engine.	Inactive at all other times
Gas Ignition	Becomes active during starting.	Becomes inactive a configurable amount of time after the <i>Fuel Relay</i> becomes inactive. This is the <i>Gas Ignition Off</i> timer.
Gen/Mains Over Frequency	Active when an <i>Over Frequency</i> alarm is detected on either the Gen or Mains	
Gen/Mains Over Voltage	Active when an <i>Over Voltage</i> alarm is detected on either the Gen or Mains	
Gen/Mains Under Frequency	Active when an <i>Under Frequency</i> alarm is detected on either the Gen or Mains	
Gen/Mains Under Voltage	Active when an <i>Under Voltage</i> alarm is detected on either the Gen or Mains	
Generator Available	Becomes active when the generator is available to take load.	Inactive when <ul style="list-style-type: none"> • <i>Loading voltage</i> and <i>loading frequency</i> have not been reached • After <i>electrical trip</i> alarm • During the starting sequence before the end of the warming timer.
Generator Over Frequency Delayed Pre-alarm	Active when the <i>Generator Over Frequency Delayed Pre-alarm</i> is active.	
Generator Over Frequency Delayed Alarm	Active when the <i>Generator Over Frequency Delayed Alarm</i> is active.	
Generator Over Frequency Overshoot Pre-alarm	Active when the <i>Generator Over Frequency Overshoot Pre-alarm</i> is active.	
Generator Over Frequency Overshoot Alarm	Active when the <i>Generator Over Frequency Overshoot Alarm</i> is active.	
Generator Over Frequency Pre-Alarm	Active when the generator frequency exceeds the <i>Over Frequency</i> pre-alarm trip level during normal running.	
Generator Over Frequency Alarm	Active when the generator frequency exceeds the <i>Over Frequency</i> alarm trip level during normal running.	
Generator Over Voltage Pre-Alarm	Active when the generator voltage exceeds the <i>Over Voltage</i> pre-alarm trip level during normal running.	
Generator Over Voltage Alarm	Active when the generator voltage exceeds the <i>Over Voltage</i> alarm trip level.	
Generator Under Frequency Pre-Alarm	Active when the generator frequency falls below the <i>Under Frequency</i> pre-alarm trip level during normal running.	
Generator Under Frequency Alarm	Active when the generator frequency falls below the <i>Under Frequency</i> alarm trip level during normal running.	
Generator Under Voltage Pre-Alarm	Active when the generator voltage falls below the <i>Under Voltage</i> pre-alarm level during normal running.	

Output Source	Active...	Inactive....
Generator Under Voltage Alarm	Active when the generator voltage falls below the <i>Under Voltage</i> alarm trip level during normal running.	
Generator Within Standards	When configured, the <i>Generator Within Standards</i> output is active when both the voltage and frequency are within the pre-alarm limits. Once the voltage or frequency deviate out of the configured pre-alarm limits, the output deactivates but no pre-alarm is indicated by the module. The voltage and frequency shutdown alarms continue to function as normal.	
HEST Active	Active when the High Exhaust System Temperature CAN alarm is active	
High Coolant Temperature Shutdown	Active when the high coolant temperature shutdown alarm is active	
Light Mast Down	<div>  NOTE: Activating the <i>Emergency Stop</i> immediately deactivates this output. </div> <p>Active when the light mast is needed to be lowered. In Auto mode, the module activates this output after the <i>Return Delay</i> timer expires. The output remains active until the <i>Light Mast Fully Closed</i> digital input is activated or the <i>Mast Down Time</i> delay expires. In Manual mode, holding the down button on the mast control screen activates this output. The output remains active until the down button is released or if the <i>Light Mast Fully Closed</i> digital input is active.</p>	
Light Mast Up	<div>  NOTE: Activating the <i>Emergency Stop</i> immediately deactivates this output. </div> <p>Active when the light mast is needed to be raised. In Auto mode, the module activates this output after the <i>Warming Up</i> timer expires. The output remains active until the <i>Light Mast Fully Open</i> digital input is activated or the <i>Mast Up Time</i> delay expires. In Manual mode, holding the up button on the mast control screen activates this output. The output remains active until the up button is released or if the <i>Light Mast Fully Open</i> digital input is active.</p>	
Light Output 1, 2, 3 & 4	Provide delayed outputs for controlling the lights.	
Low Battery Start	Active when the <i>Start On Low Battery</i> function is active.	
Low Current Alarm	Becomes active when the low current alarm is active.	
Low Fuel Switch	Active when the <i>Low Fuel Level Switch</i> input is active.	
Low Oil Pressure Shutdown	Active when the Low Oil Pressure Shutdown alarm is activated.	
Mains Supply Active	Active when the <i>Mains Supply Active</i> digital input is activated.	
Mains Supply Over Frequency Pre-Alarm	Active when the Mains Supply frequency exceeds the pre-alarm trip level.	
Mains Supply Over Frequency Alarm	Active when the <i>Mains Over Frequency Alarm</i> is active.	
Mains Supply Over Voltage Pre-Alarm	Active when the Mains Supply voltage exceeds the pre-alarm trip level.	
Mains Supply Over Voltage Alarm	Active when the <i>Mains Over Voltage Alarm</i> is active.	
Mains Supply Under Frequency Pre-Alarm	Active when the Mains Supply frequency falls below the pre-alarm trip level.	
Mains Supply Under Frequency Alarm	Active when the <i>Mains Under Frequency Alarm</i> is active.	


Output Source	Active...	Inactive....
Mains Supply Under Voltage Pre-Alarm	Active when the Mains Supply voltage falls below the pre-alarm trip level.	
Mains Supply Under Voltage Alarm	Active when the <i>Mains Under Voltage Alarm</i> is active.	
Oil Filter Maintenance	Indicates that the oil filter maintenance alarm is due	
Oil Pressure Sender Open Circuit	Active when the Oil Pressure Sensor is detected as being open circuit.	
Oil Pressure Switch	Active when the <i>Oil Pressure Switch</i> input is active.	
Over Current Delayed Alarm	Active when an overcurrent condition has caused the Overcurrent Delayed alarm to trigger	
Over Current Immediate Warning IEEE 37.2 – 50 Instantaneous Overcurrent Relay	Active when an overcurrent condition exceeds the Overcurrent alarm Trip setting. At the same time, the controller begins following the IDMT curve. If the overload condition exists for an excess time, the Overcurrent IDMT alarm activates.	
Over Speed Shutdown IEEE 37.2 – 12 Over Speed Device	Active if the engine speed exceeds the <i>Over Speed Shutdown</i> setting during normal operation.	
Overspeed Delayed Shutdown	Active when the <i>Overspeed Delayed Shutdown</i> alarm is active.	
Overspeed Overshoot Alarm	Active when the <i>Overspeed Overshoot Alarm</i> is active.	
Preheat During Preheat Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : • The set is stopped The preheat timer has expired
Preheat Until End Of Cranking	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : • The set is stopped The set has reached <i>crank disconnect</i> conditions
Preheat Until End Of Safety Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : • The set is stopped The set has reached the end of the <i>safety delay</i> timer
Preheat Until End of Warming Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : • The set is stopped The set has reached the end of the <i>warming</i> timer
SCR Inducement	Active when <i>SCR Inducement CAN Alarm</i> is active	
Smoke Limiting	Becomes active when the controller requests that the engine runs at idle speed. As an output, this is used to give a signal to the <i>Idle input</i> of an engine speed governor (if available)	Becomes inactive when the controller requests that the engine runs at rated speed.
Start Relay	Active when the controller requires the cranking of the engine.	
System in Auto Mode	Active when Auto mode is selected	
System in Manual Mode	Active when Manual mode is selected	
System in Stop Mode	Active when Stop mode is selected	
Temperature Sensor Open Circuit	Active when the Temperature Sensor is detected as being open circuit.	
Under Speed Shutdown	Active when the engine speed falls below the under speed Shutdown setting	
Water In Fuel	Active when the <i>Water in Fuel</i> input is active, or when the module is informed of the <i>Water in Fuel</i> CAN message from the ECU.	


2.6 TIMERS

Many timers are associated with alarms. Where this occurs, the timer for the alarm is located on the same page as the alarm setting. Timers not associated with an alarm are located on the timers page. The *Timers* page is subdivided into smaller sections. Select the required section with the mouse.




2.6.1 START TIMERS



Parameter	Description
Start Delay	The amount of time delay before starting in AUTO mode. This timer is activated upon the respective start command being issued. Typically, this timer is applied to prevent starting upon fleeting start signals.
Pre-heat	The amount of 'pre start' time during which the <i>Preheat</i> output becomes active (if configured)
Delay Crank	The amount of time delay between the fuel relay and the crank relay energising. This is typically used to allow fuel systems to prime.
Cranking	The amount of time for each crank attempt
Crank Rest	The amount of time between multiple crank attempts.
Fuel Pull in Coil Duration	<div>  NOTE: A digital output must be configured for <i>Fuel Pull in Coil</i> to configure this timer. </div> <p>The amount of time for the <i>Fuel Pull in Coil</i> output stay energised when the <i>Fuel Relay</i> output is energised.</p>
Smoke Limiting	The amount of time that the engine is requested to run at idle speed upon starting. This is typically used to limit emissions at startup.
Smoke Limiting Off	The amount of time that the engine takes to run up to rated speed after removal of the command to run at idle speed. If this time is too short, an <i>Underspeed</i> alarm is detected. If the time is too long, <i>Underspeed</i> protection is disabled until the <i>Smoke Limit Time Off</i> time has expired.
DPF Ramp	The amount of time that the engine takes to run up to rated speed after a DPF session.
Safety On Delay	The amount of time at startup that the controller ignores oil pressure and engine speed and other delayed alarms. This is used to allow the engine to run up to speed before protections are activated.
Warming	The amount of time the engine runs before being allowed to take load. This is used to warm the engine to prevent excessive wear.
ECU (ECM) Override	The amount of time the CAN ECU Power stays energised when the Start button is pressed in Stop mode.

2.6.2 LOAD / STOPPING TIMERS







Parameter	Description
Return Delay Off Load	The amount of time, in Auto mode only, that allows for short term removal of the request to stop the set before action is taken. This is used to ensure the set remains on load before accepting that the start request has been removed.
Cooling	The amount of time that the set is made to run off load before stopping. This allows the set to cooldown and is particularly important for engines with turbo chargers.
Cooling At Idle	The amount of time the module instructs the engine to run at idle speed after the <i>Cooling Time</i> .
ETS Solenoid Hold	The amount of time the <i>Energise to Stop</i> output is kept energised after the engine has come to rest. This is used to ensure the set has fully stopped before removal of the stop solenoid control signal.
Fail To Stop Delay	The amount of time when the set is called to stop and is still running after the <i>Fail To Stop</i> delay, a <i>Fail to Stop</i> alarm is generated.
Generator Transient Delay	Used to delay the generator under/over volts/frequency alarms. Typically this is used to prevent spurious shutdown alarms caused by large changes in load levels.
Mains Supply Transient Delay	Used to delay the mains under/over volts/frequency alarms. Typically this is used to prevent spurious alarms caused by mains brownouts.

2.6.3 LIGHTING TIMERS

 **NOTE:** Timers are greyed out when the respective *Light Output* is not configured.

Start Up Timers





Start Up Timers


Light 1 Start Up	0s		<input type="text"/>
Light 2 Start Up	0s		<input type="text"/>
Light 3 Start Up	0s		<input type="text"/>
Light 4 Start Up	0s		<input type="text"/>

Parameter	Description
Light 1 to 4 Start Up	When the generator becomes available and after the activation of the <i>Light Mast Fully Open</i> digital input or the expiry of the <i>Mast Up Time</i> delay, the corresponding light output is delayed for this amount of time before activating

Shutdown Timers





Shutdown Timers

Light 1 Shutdown	0s		<input type="text"/>
Light 2 Shutdown	0s		<input type="text"/>
Light 3 Shutdown	0s		<input type="text"/>
Light 4 Shutdown	0s		<input type="text"/>

Parameter	Description
Light 1 to 4 Shutdown	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: The Light Mast Down digital output activates after the longest Light Shutdown timer has expired. </div> After the Return Delay time expires, the corresponding light output remains active for this amount of time.

Re-strike Timers



Re-strike Timers

Light 1 Re-strike	0m		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>
Light 2 Re-strike	0m		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>
Light 3 Re-strike	0m		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>
Light 4 Re-strike	0m		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>

Parameter	Description
Light 1 to 4 Re-strike	When a light output has been de-energised, this is the amount of time for the light to cool down before the light output is energised again.

Mast Control Timers

Mast Control Timers

Mast Up Time	0s		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>
Mast Down Time	0s		<div style="border: 1px solid #ccc; height: 15px; width: 100%;"></div>

Parameter	Description
Mast Up Time	The amount of time required for the light mast to fully open. If this timer expires before the <i>Light Mast Fully Open</i> digital input is activated, the <i>Light Mast Up</i> digital output becomes inactive.
Mast Down Time	The amount of time required for the light mast to fully close. If this timer expires before the <i>Light Mast Fully Closed</i> digital input is activated, the <i>Light Mast down</i> digital output becomes inactive.

2.6.4 MODULE TIMERS

Module Timers

Power Save Mode Delay
1m

Deep Sleep Delay
1m 30s


Page Delay
5m

Audible Alarm Duration
20s

Timer	Description
Power Save Mode Delay	If the module is left unattended in Stop mode for the duration of the <i>Power Save Mode Delay</i> , it enters low power consumption mode (Power Save Mode).
Deep Sleep Delay	When the module is in Power Save Mode, if left unattended for the duration of the <i>Deep Sleep Mode Delay</i> timer, it enters a lower power consumption mode (Deep Sleep Mode)
Page Delay	If the module is left unattended for the duration of the <i>Page Delay Timer</i> , it reverts to show the Status page.
Audible Alarm Duration	When an alarm is active on the module, this is the time duration during which the <i>Audible Alarm</i> digital output is active. This is configurable when the <i>Limit Audible Alarm Duration</i> option is enabled under <i>Module Options</i> .


2.7 GENERATOR

The *Generator* section is subdivided into smaller sections. Select the required section with the mouse.




2.7.1 GENERATOR OPTIONS

Alternator



Parameter	Description
Alternator Fitted	<input type="checkbox"/> = There is no alternator in the system, it is an <i>engine only</i> application <input checked="" type="checkbox"/> = An alternator is fitted to the engine, it is a generator application.
Poles	The number of poles on the alternator

System Topology



Parameter	Description
System Topology	<p>Select the AC topology of the generator from the following list:</p> <ul style="list-style-type: none"> 2 Phase, 3 Wire L1 - L2 2 Phase, 3 Wire L1 - L3 2 Wire Unearthed DC 3 Phase, 3 Wire 3 Phase, 4 Wire 3 Phase, 4 Wire Delta L1 - N - L2 3 Phase, 4 Wire Delta L1 - N - L3 3 Phase, 4 Wire Delta L2 - N - L3 Single Phase, 2 Wire Single Phase, 3 Wire L1 - L2 Single Phase, 3 Wire L1 - L3

2.7.2 GENERATOR VOLTAGE

Under Voltage Alarms

Under Voltage Alarms

Alarm ☒ Trip 318 V PhPh

Pre-Alarm ☒ Trip 339 V PhPh

Click and drag to change the setting.

Parameter	Description
Generator Under Voltage Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give an alarm <input checked="" type="checkbox"/> = Generator Under Volts gives an alarm in the event of the generator output falling below the configured <i>Under Volts Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Under-volts Alarm Trip</i> value is adjustable to suit user requirements.
Generator Under Voltage Pre-Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Volts gives a warning alarm in the event of the generator output falling below the configured <i>Under Volts Pre-Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Under-volts Pre-Alarm Trip</i> value is adjustable to suit user requirements.

Loading Voltage

Loading Voltage

358 V PhPh

Type the value or click the up and down arrows to change the settings

Parameter	Description
Loading Voltage	This is the minimum voltage the generator must be operating at before the module considers it available to take the load. It is also the voltage above the under voltage trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With an under voltage trip of 184 V and a loading voltage of 207 V, the output voltage must return to 207 V following an under voltage event to be considered within limits.)

Over Voltage Alarms

Over Voltage Alarms

Pre-Alarm ☒

Return 439 V PhPh

Trip 458 V PhPh

Alarm

Trip 479 V PhPh 479V PhPh

Click to enable or disable the alarms. The relevant values below appears *greyed out* if the alarm is disabled.

Parameter	Description
Generator Over Voltage Pre-Alarm IEEE 37.2 – 59 AC Overvoltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Volts gives a warning alarm in the event of the generator output voltage rising above the configured <i>Over Volts Pre-Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Warning</i> is automatically reset when the generator output voltage falls below the configured <i>Return</i> level. The <i>Over Volts Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Generator Over Voltage Alarm IEEE 37.2 – 59 AC Overvoltage Relay	Generator Over Volts gives a <i>Shutdown</i> alarm in the event of the generator output rising above the configured <i>Over Volts Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Over-volts Alarm Trip</i> value is adjustable to suit user requirements.

2.7.3 GENERATOR FREQUENCY

Under Frequency Alarms

Under Frequency Alarms

Alarm ☒ Trip 40.0 Hz

Pre-Alarm ☒ Trip 42.0 Hz 84.0%

Click and drag to change the setting.

Parameter	Description
Generator Under Frequency Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give an alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives an alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Under-frequency Alarm Trip</i> value is adjustable to suit user requirements.
Generator Under Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives a warning alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Pre-Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Under Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.

Loading Frequency

Loading Frequency

45.0 Hz 90.0%

Parameter	Description
Loading Frequency	This is the minimum frequency the generator must be operating at, before the module considers it available to take the load. It is also the frequency above the under frequency trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With an under-frequency trip of 42.0 Hz and a loading frequency of 45.0 Hz, the output frequency must return to 45.0 Hz following an under frequency event to be considered within limits.)

Nominal Frequency

Nominal Frequency

50.0 Hz 100%

Parameter	Description
Nominal Frequency	This is used to calculate the percentages of the alarm and to instruct the ECU what speed to run the engine at.

Over Frequency Alarms

Over Frequency Alarms

Pre-Alarm ☒

Return 54.0 Hz

Trip 55.0 Hz

Alarm ☒

Trip 57.0 Hz

Type the value or click the up and down arrows to change the settings

Parameter	Description
Generator Over Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Frequency gives a warning alarm in the event of the generator output frequency rising above the configured <i>Over frequency Pre-Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Warning</i> is automatically reset when the generator output frequency falls below the configured <i>Return</i> level. The <i>Over Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Generator Over Frequency Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Frequency gives a <i>Shutdown</i> alarm in the event of the generator output rising above the configured <i>Over Frequency Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Over Frequency Alarm Trip</i> value is adjustable to suit user requirements.

2.7.4 GENERATOR CURRENT

Generator Current Options

Generator Current Options

Enable CT Support ☒

CT Primary (L1,L2,L3,N) 600 A

Full Load Rating 500 A

This is the primary rating of the CT. The module only supports a secondary rating of 5 A.

Parameter	Description
CT Primary (L1, L2, L3, N)	Primary rating of the three phase current transformers.
Full Load Rating	This is the full load current rating of the alternator.

Overcurrent Alarm

Overcurrent Alarm

Immediate Warning ☒

Delayed Alarm ☒

Delayed Alarm Action Electrical Trip

Delay 1m

Trip 100 % 500 A

Click to enable or disable the option. The relevant values below appears greyed out if the alarm is disabled.

Parameter	Description
Immediate Warning IEEE 37.2 -50 Instantaneous Overcurrent Relay	<input type="checkbox"/> = <i>Immediate Overcurrent Warning</i> is disabled. <input checked="" type="checkbox"/> = The <i>Immediate Overcurrent Warning</i> activates as soon as the <i>Trip</i> level is reached. The alarm automatically resets once the generator loading current falls below the <i>Trip</i> level (unless <i>All Warnings are latched</i> is enabled). For further advice, consult the generator supplier.
Delayed Alarm IEEE 37.2 -51 AC Time Overcurrent Relay	<input type="checkbox"/> = <i>Delayed Overcurrent Alarm</i> is disabled. <input checked="" type="checkbox"/> = The <i>Delayed Overcurrent Alarm</i> activates when the current exceeds the <i>Trip</i> setting for longer than the configured <i>Delay</i> time.
Delayed Alarm Action	Select the type of alarm required from the list: Electrical Trip Shutdown Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

2.8 MAINS SUPPLY

NOTE: To enable these parameters, a *Digital Input* must be configured for the function *Mains Supply Active*.

A configured *Mains Supply Active* digital input allows the controller to monitor the AC sensing terminals being fed from an external supply without the generator running. When this input is active, the module expects the supply on the AC sensing terminals to be within the *Mains Supply* voltage and frequency limits in order to operate the light outputs. This requires a manual changeover panel to transfer the supply between the mains and the generator.

Under Voltage Alarms

Parameter	Description
Mains Under Voltage Alarm IEEE 37.2 - 27AC Undervoltage Relay	<p><input type="checkbox"/> = <i>Mains Under Voltage Alarm</i> does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = <i>Mains Under Voltage Alarm</i> gives an alarm in the event of the mains voltage falling below the configured <i>Under Voltage Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Under Voltage Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains voltage rises above the configured <i>Under Voltage Alarm Return</i> level. When the alarm activates all <i>Light Outputs</i> are turned off.</p>
Mains Under Voltage Pre-Alarm IEEE 37.2 - 27AC Undervoltage Relay	<p><input type="checkbox"/> = <i>Mains Under Voltage Pre-Alarm</i> does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = <i>Mains Under Voltage Pre-Alarm</i> gives a warning alarm in the event of the mains voltage falling below the configured <i>Under Voltage Pre-Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Under Voltage Pre-Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains voltage rises above the configured <i>Under Voltage Pre-Alarm Return</i> level.</p>

Over Voltage Alarms

Over Voltage Alarms

Pre-Alarm ☒

Return V PhPh

Trip V PhPh

Alarm ☒

Return V PhPh

Trip V PhPh

Parameter	Description
Mains Over Voltage Pre-Alarm IEEE 37.2 – 59 AC Overvoltage Relay	<p><input type="checkbox"/> = Mains Over Voltage Pre-Alarm does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Over Voltage Pre-Alarm gives a warning alarm in the event of the mains voltage rising above the configured <i>Over Voltage Pre-Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Over Voltage Pre-Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains voltage falls below the configured <i>Over Voltage Pre-Alarm Return</i> level.</p>
Mains Over Voltage Alarm IEEE 37.2 – 59 AC Overvoltage Relay	<p><input type="checkbox"/> = Mains Over Voltage Alarm does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Over Voltage Alarm gives an alarm in the event of the mains voltage rising above the configured <i>Over Voltage Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Over Voltage Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains voltage falls below the configured <i>Over Voltage Alarm Return</i> level. When the alarm activates all <i>Light Outputs</i> are turned off.</p>

Under Frequency Alarms

Under Frequency Alarms

Alarm ☒

Trip Hz

Return Hz

Pre-Alarm ☒

Trip Hz

Return Hz

Parameter	Description
Mains Under Frequency Alarm IEEE 37.2 – 81 Frequency Relay	<p><input type="checkbox"/> = Mains Under Frequency Alarm does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Under Frequency Alarm gives an alarm in the event of the mains frequency falling below the configured <i>Under Frequency Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Under Frequency Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains frequency rises above the configured <i>Under Frequency Alarm Return</i> level. When the alarm activates all <i>Light Outputs</i> are turned off.</p>
Mains Under Frequency Pre-Alarm IEEE 37.2 – 81 Frequency Relay	<p><input type="checkbox"/> = Mains Under Frequency Pre-Alarm does NOT give an alarm</p> <p><input checked="" type="checkbox"/> = Mains Under Frequency Pre-Alarm gives a warning alarm in the event of the mains frequency falling below the configured <i>Under Frequency Pre-Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i>. The <i>Under Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains frequency rises above the configured <i>Under Frequency Pre-Alarm Return</i> level.</p>

Over Frequency Alarms

The screenshot shows a configuration window titled "Over Frequency Alarms". It contains two main sections: "Pre-Alarm" and "Alarm". Each section has a checked checkbox, a "Return" value with a slider, and a "Trip" value with a slider. The "Pre-Alarm" section has Return set to 54.0 Hz and Trip set to 55.0 Hz. The "Alarm" section has Return set to 56.0 Hz and Trip set to 57.0 Hz. Each value is accompanied by a horizontal slider bar with a green indicator.

Parameter	Description
Mains Over Frequency Pre-Alarm IEEE 37.2 – 81 Frequency Relay	<input type="checkbox"/> = <i>Mains Over Frequency Pre-Alarm</i> does NOT give an alarm <input checked="" type="checkbox"/> = <i>Mains Over Frequency Pre-Alarm</i> gives a warning alarm in the event of the mains frequency rising above the configured <i>Over Frequency Pre-Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i> . The <i>Over Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains frequency falls below the configured <i>Over Frequency Pre-Alarm Return</i> level.
Mains Over Frequency Alarm IEEE 37.2 – 81 Frequency Relay	<input type="checkbox"/> = <i>Mains Over Frequency Alarm</i> does NOT give an alarm <input checked="" type="checkbox"/> = <i>Mains Over Frequency Alarm</i> gives an alarm in the event of the mains frequency rising above the configured <i>Over Frequency Alarm Trip</i> value for longer than the <i>Mains Transient Delay</i> . The <i>Over Frequency Alarm Trip</i> value is adjustable to suit user requirements. The alarm is reset when the mains frequency falls below the configured <i>Over Frequency Alarm Return</i> level. When the alarm activates all <i>Light Outputs</i> are turned off.

2.9 LOAD CONTROL

Low Current Alarm

Parameter	Description
Low Current Alarm	<input type="checkbox"/> = <i>Low Current Alarm</i> is disabled. <input checked="" type="checkbox"/> = <i>Low Current Alarm</i> activates when the total current is less than the configured <i>Percentage</i> of expected current of the active light outputs as set by the <i>Current Ratings</i> , for longer than the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Electrical Trip Shutdown Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.

Current Rating

 **NOTE:** Outputs are greyed out when the respective *Light Output* is not configured.

Parameter	Description
Output 1 to 4	Define the maximum current consumption of each <i>Light Output</i> . These ratings are used to calculate the expected current the generator produces based on active <i>Light Outputs</i> .


2.10 ENGINE

The *engine* page is subdivided into smaller sections.
Select the required section with the mouse.




2.10.1 ENGINE PROTECTION

High Coolant Temperature Alarm



Parameter	Description
High Coolant Temperature Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Coolant Temperature Shutdown Alarm</i> is active when the measured coolant temperature rises above the configured <i>Trip</i> level.

Low Oil Pressure Shutdown



Parameter	Description
Low Oil Pressure Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Shutdown Alarm</i> is active when the measured oil pressure drops below the configured <i>Trip</i> level.

Water In Fuel

NOTE: *Water in Fuel* settings are greyed out unless a ECU (ECM) or *Digital Input for Water in Fuel* is configured.

Water In Fuel

Action: Warning

Arming: Always

Activation Delay: 0s

Parameter	Description
Water in Fuel	<p>Select the type of action when the <i>Water In Fuel</i> alarm occurs after the <i>Activation Delay</i> time.</p> <p>Select the type of alarm required from the list:</p> <p>Electrical Trip</p> <p>Shutdown</p> <p>Warning</p> <p>For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p>
Arming	<p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> <p>Select when the alarm generated by the input becomes active:</p> <p>Always</p> <p>From Safety On</p> <p>From Starting</p> <p>Never</p> <p>When Stationary</p>

Fuel Tank Bund

NOTE: *Fuel Tank Bund* alarm is greyed out unless a *Digital Input for Fuel Tank Bund* is configured.

Fuel Tank Bund

Action: Warning

Parameter	Description
Fuel Tank Bund	<p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> <p>Select the type of alarm required when the digital input configured for <i>Fuel Tank Bund</i> activates from the list:</p> <p>Electrical Trip</p> <p>Shutdown</p> <p>Warning</p>

2.10.2 DEF LEVEL

NOTE: Configuration of alarms in this section only has effect when the ECU (ECM) supports DEF Level.

NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CANbus message; however, the ECU (ECM) still shuts down the engine depending on the alarm severity.

DEF Level is a CANbus message from the ECU (ECM). The following parameters allow configuration of how the DSE module responds to the DEF Level.

The screenshot shows a configuration window titled "Level Alarms". It contains two main sections:

- Low Alarm Enable:** This section has a checked checkbox. Below it, the "Action" is set to "Shutdown" via a dropdown menu. The "Trip" level is set to 10% using a slider, and the "Delay" is set to 0s.
- Low Pre-alarm Enable:** This section also has a checked checkbox. It includes a "Trip" slider set to 30%, a "Return" slider set to 40%, and a "Delay" set to 0s.

Parameter	Description
DEF Level Low Alarm	<input type="checkbox"/> = Disable the alarm <input checked="" type="checkbox"/> = <i>DEF Low Alarm</i> is activated when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Shutdown Electrical Trip For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
DEF Level Low Pre-Alarm	<input type="checkbox"/> = The Pre-alarm is disabled. <input checked="" type="checkbox"/> = <i>DEF Low Pre-Alarm</i> is activated when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time. The Pre-Alarm is deactivated when the <i>DEF Level</i> rises above the <i>Return</i> level.

2.10.3 ENGINE OPTIONS

ECU (ECM) Options

Parameter	Description
Module to Measure Oil Pressure	<input type="checkbox"/> = Oil pressure is read from the ECU. <input checked="" type="checkbox"/> = Oil pressure is read from the <i>Oil Pressure Sensor</i> .
Module to Measure Coolant Temperature	<input type="checkbox"/> = Coolant Temperature is read from the ECU. <input checked="" type="checkbox"/> = Coolant Temperature is read from the <i>Coolant Temperature Sensor</i> .
Module to Record Engine Hours	<input type="checkbox"/> = Engine hours are read from the ECU. <input checked="" type="checkbox"/> = Engine hours counted by the DSE module.
Module To Use Engine Speed	<input type="checkbox"/> = Engine speed is read from the ECU. <input checked="" type="checkbox"/> = Engine speed is determined from measured generator frequency.
Module to Use Charge Alt Voltage	<input type="checkbox"/> = Charge alternator voltage is read from the ECU. <input checked="" type="checkbox"/> = Charge alternator voltage is read from the module.
Disable ECM Speed Control	<input type="checkbox"/> = The module sends the speed control message to the ECU over CAN. <input checked="" type="checkbox"/> = The module is inhibited from sending the speed control message to the ECU over CAN. This is useful if an external device is used to control engine speed, for example a remote speed potentiometer.

Miscellaneous Options

NOTE: For a full list of the J1939-75 alarms and instrumentation, refer to DSE Publication: *057-221 DSEL401 MKII Operator Manual* found on DSE's website: www.deepseaelectronics.com

Parameter	Description
J1939-75 Instrumentation Enable	<input type="checkbox"/> = J1939-75 Instrumentation is not broadcast by the DSE module. <input checked="" type="checkbox"/> = J1939-75 Instrumentation is broadcast by the DSE module.
J1939-75 Alarms Enable	<input type="checkbox"/> = J1939-75 Alarms are not broadcast by the DSE module. <input checked="" type="checkbox"/> = J1939-75 Alarms are broadcast by the DSE module.
CAN Source Address (Instrumentation)	Set the <i>CAN Source Address</i> for the DSE module over which other CANbus devices read the generator set instrumentation.

Startup Options

Startup Options

Start Attempts

Parameter	Description
Start Attempts	<p>The number of starting attempts the module makes.</p> <p>If the module does not detect that the engine has fired before the end of the <i>Cranking Time</i>, then the current start attempt is cancelled and the <i>Crank Rest</i> time takes place before the next crank attempt begins.</p> <p>If, after all configured <i>start attempts</i>, the engine is not detected as running, the <i>Fail to Start</i> shutdown alarm is generated.</p> <p>The engine is detected as running by checking all methods of <i>Crank Disconnect</i>. For further details, see the section entitled <i>Crank Disconnect</i> elsewhere in this document.</p>

Overspeed Options

Overspeed Options

Overspeed Overshoot %
Overshoot Delay 2s

Parameter	Description
Overspeed Overshoot %	<p>To prevent spurious overspeed alarms at engine start up, the module includes configurable <i>Overspeed Overshoot</i> protection. This allows the engine speed to 'overshoot' the Overspeed setting during the starting process for a short time.</p>
Overshoot Delay	<p>Rather than 'inhibiting' the Overspeed alarms, the levels are temporarily raised by the <i>Overspeed Overshoot</i> % for the duration of the <i>Overspeed Overshoot</i> delay from starting.</p>

2.10.4 ENGINE HEATING OPTIONS

Block Heater

NOTE: For this feature to have effect, configure a digital output for *Block Heater*.

Block Heater

Enabled ☒

Max Temperature °C

Duration

Parameter	Description
Enabled	<input type="checkbox"/> = Block Heater is disabled. <input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>Max Temperature</i> , the <i>Block Heater</i> digital output is activated for the set <i>Duration</i> of time before cranking, or the <i>Pre-Heat</i> function if configured.
On	Set the coolant temperature below which the <i>Block Heater</i> output is activated.
Duration	Set the time delay during which the <i>Block Heater</i> digital output remains active before cranking, or the <i>Pre-Heat</i> function if configured.

Pre-heat

NOTE: For this feature to have effect, configure a digital output for *Pre-Heat*.

NOTE: Depending on *Engine Type* configuration, this is controlled direct by the ECU (ECM).

Pre-heat

Enabled ☒

On °C

Duration

Parameter	Description
Enabled	<input type="checkbox"/> = Pre-heat is not temperature dependent. <input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time before cranking.
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active before cranking

Post-heat



NOTE: For this feature to have effect, configure a digital output for *Pre-Heat*.



NOTE: Depending on *Engine Type* configuration, this is controlled direct by the ECU (ECM).

Post-heat

Enabled ☒

On 50 °C 122 °F

Duration 0s

Parameter	Description
Enabled	<input type="checkbox"/> = Post-heat is not temperature dependent. <input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time after cranking and before the set is considered available.
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active after cranking and before the engine is considered available.

2.10.5 ECU (ECM) OPTIONS

DPF Regeneration Control

DPF Regeneration Control

Allow Non-Mission Regeneration ☐

Parameter	Description
DPF Regeneration Control	Available for ECUs (ECM) which require the engine speed to drop during a manual regeneration cycle. During this time, the generator is not available to supply power and the under speed and under frequency alarms are not active.

ECU Wakeup

ECU Wakeup

Enable ☐

Periodic Wakeup Time 1h

Coolant Measurement Persistence ☐

Parameter	Description
ECU Wakeup Enable	<input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = When the engine is stopped, the DSE module sends a wakeup signal to the ECU (ECM) and keeps it powered up for the <i>ECU Override</i> time (configured in <i>Start Timers</i>) to read the ECU (ECM) parameters. This is periodically repeated depending on the configured <i>Periodic Wakeup Time</i> .
Coolant Measurement Persistence	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> NOTE: Available only when <i>ECU Wakeup</i> is enabled. </div> <input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = The <i>Coolant Temperature</i> measurement is used for the <i>Coolant Temperature Control</i> .

SPN Ignore List

SPN Ignore List


	SPN	FMI		SPN	FMI
1 <input checked="" type="checkbox"/>	8	Any	6 <input type="checkbox"/>		
2 <input checked="" type="checkbox"/>	12	Any	7 <input type="checkbox"/>		
3 <input checked="" type="checkbox"/>	52	Any	8 <input type="checkbox"/>		
4 <input type="checkbox"/>			9 <input type="checkbox"/>		
5 <input type="checkbox"/>			10 <input type="checkbox"/>		

Parameter	Description
SPN Ignore List	Choose the specific SPN for the module to ignore. The module allows the engine to keep running when the ignored SPN occurs; however, depending on the severity, the engine shuts down based on the ECU (ECM) calibration. This is used to mask certain indications or warnings on the ECU (ECM) and not display them on the DSE module.

Miscellaneous

Miscellaneous

CAN source address (engine messages) 220

Parameter	Description
CAN Source Address (Engine Messages)	<div>  NOTE: Although automatically pre-set upon selection of the Engine Type, this parameter is available for change if required. </div> <p>Set the <i>CAN Source Address</i> that the module is to read instrumentation from. This is typically the Source Address of the engine ECU.</p>

2.10.6 ECU (ECM) ALARMS



NOTE: This section is only available when the module is connected to an ECU.

The *ECU (ECM) Alarms* section is subdivided into smaller sections.
Select the required section with the mouse.

Engine

- [ECU \(ECM\) Data Fail](#)
- [DM1 Signals](#)
- [Other Specific Signals](#)

2.10.6.1 ECU (ECM) DATA FAIL

ECU (ECM) Data Fail

Action Shutdown

Arming Engine Protection Activation

Activation Delay 0s

Parameter	Description
ECU (ECM) Data Fail Action	Provides protection against failure of the ECU (ECM) CAN data link. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Shutdown Warning
Arming	Select when the <i>CAN ECU (ECM) Data Fail</i> alarm is active. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Engine Protection Activation From Safety On From Starting
Activation Delay	The amount of time before the module activates the <i>CAN ECU (ECM) Data Fail</i> after a failure.

2.10.6.2 DM1 SIGNALS

NOTE: Configuration of parameters in this section only has effect when the ECU (ECM) supports these features.

NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CAN message; however, the ECU (ECM) still shuts down the engine depending on the alarm severity.

DM1 signals are messages from the CAN (ECM) ECU. The following parameters allows configuration of how the DSE module responds to these messages.

ECU Amber

The screenshot shows a configuration window titled "ECU Amber". It contains three settings:

- Action:** A dropdown menu currently showing "Warning".
- Arming:** A dropdown menu currently showing "Always".
- Activation Delay:** A slider bar set to "0s".

Parameter	Description
ECU Amber Action	The action the DSE module takes when receiving an ECU Amber fault condition. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the DSE module activates its <i>ECU Amber</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Always From Safety On From Starting Never
Activation Delay	The amount of time before the module activates the <i>ECU Amber</i> alarm after receiving an ECU Amber fault condition from the ECU.

ECU Red

ECU Red

Action: Shutdown

Arming: From Safety On

Activation Delay: 0s

Parameter	Description
ECU Red Action	<p>The action the DSE module takes when receiving an ECU Red fault condition.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>None Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>ECU Red</i> alarm.</p> <p>Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always From Safety On From Starting Never</p>
Activation Delay	<p>The amount of time before the module activates the <i>ECU Red</i> alarm after receiving an ECU Red fault condition from the ECU.</p>

2.10.6.3 OTHER SPECIFIC SIGNALS

DPTC Filter

DPTC Filter

Enabled ☒

Action Warning

Arming From Safety On

Parameter	Description
DPTC Filter Enabled	<p><input type="checkbox"/> = The DSE module's <i>DPTC Filter</i> alarm is disabled, it does not act upon any DPTC Filter fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>DPTC Filter</i> alarm is enabled. The action the DSE module takes when receiving a DPTC Filter fault condition from the ECU. The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip Indication Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>DPTC Filter</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always From Safety On From Starting</p>

HEST Active

HEST Active

Enabled ☒

Action Warning

Arming From Safety On

Parameter	Description
HEST Active Enabled	<p><input type="checkbox"/> = The DSE module's <i>HEST</i> alarm is disabled, it does not act upon any HEST fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>HEST</i> alarm is enabled. The action the DSE module takes when receiving a HEST fault condition from the ECU. The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Indication Warning</p>
Arming	<p>Select when the DSE module activates its <i>HEST</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always From Safety On From Starting</p>

Parameter descriptions are continued overleaf...

DEF Level

DEF Level

Enabled

☒

Action

Warning

Arming

From Safety On

Activation Delay

0s

Parameter	Description
DEF Level Enabled	<p><input type="checkbox"/> = The DSE module's <i>DEF Level</i> alarm is disabled, it does not act upon any DEF Level fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>DEF Level</i> alarm is enabled. The action the DSE module takes when receiving a DEF Level fault condition from the ECU. The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>DEF Level</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always From Safety On From Starting Loading Alarms Activation Never: When Stationary</p>
Activation Delay	<p>The amount of time before the module activates the <i>DEF Level</i> alarm after a receiving a DEF Level fault condition from the ECU.</p>

SCR Inducement

SCR Inducement

Enabled ☒

Action Warning




Arming From Safety On

Activation Delay 0s

Parameter	Description
SCR Inducement Enabled	<p><input type="checkbox"/> = The DSE module's <i>SCR Inducement</i> alarm is disabled, it does not act upon any SCR Inducement fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>SCR Inducement</i> alarm is enabled. The action the DSE module takes when receiving a SCR Inducement fault condition from the ECU.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip</p> <p>Shutdown</p> <p>Warning</p>
Arming	<p>Select when the DSE module activates its <i>SCR Inducement</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always</p> <p>From Safety On</p> <p>From Starting</p> <p>Loading Alarms Activation</p> <p>Never:</p> <p>When Stationary</p>
Activation Delay	<p>The amount of time before the module activates the <i>SCR Inducement</i> alarm after a receiving a SCR Inducement fault condition from the ECU.</p>

2.10.7 GAS ENGINE OPTIONS

Gas Engine Timers

Choke	2s	
Gas on Delay	2s	
Ignition Off Delay	2s	


Parameter	Description
Choke Timer	Controls the amount of time that the Gas Choke output is active during the starting sequence.
Gas On Delay	Controls the amount of time between energising the Gas Ignition and energising the Fuel output. Used in the starting sequence to purge old gas from the engine.
Ignition Off Delay	Controls the amount of time between de-energising the Fuel output and de-energising the Gas Ignition output. Used in the stopping sequence to purge unburnt gas from the engine before it is stopped.

2.10.8 CRANK DISCONNECT

Crank disconnect settings are used to detect when the set fires during the starting sequence. As the set is cranked, the first parameter that passes its *crank disconnect* setting results in the cessation of the cranking signal.

Having more than one *crank disconnect* source allows for a faster crank disconnect response. This result in less wear on the engine flywheel and starter motor. It also provides added safety in case one source is lost, for example by a blown or tripped fuse.

Options



Options

Crank Disconnect on Oil Pressure ☒

Check Oil Pressure Prior to Starting ☒


Auto retry on loss of crank disconnect ☒

Retry attempts 3

When *Check Oil Pressure Prior to Starting* is enabled, the cranking is not allowed if the oil pressure is not seen as being low. This is used as a *double check* that the engine is stopped before the starter is engaged.

Parameter	Description
Crank Disconnect on Oil Pressure	<input type="checkbox"/> = Oil pressure is not used to disconnect the crank motor. <input checked="" type="checkbox"/> = When starting, the crank is disconnected when the measured oil pressure value rises above the configured <i>Oil Pressure Crank Disconnect</i> level.
Check Oil Pressure Prior to Starting	<input type="checkbox"/> = Oil pressure is not checked prior to engaging the crank motor. <input checked="" type="checkbox"/> = The cranking is not allowed if the oil pressure is not seen as being low. This used as a double check that the engine is stopped before the starter is engaged.
Auto Retry on Loss of Crank Disconnect	<input type="checkbox"/> = Normal operation. <input checked="" type="checkbox"/> = After a crank disconnect, if the engine fails to start and the set is seen to be at rest, the module activates an unlatched shutdown alarm and repeats the starting sequence. The number of retries is defined by the <i>Retry Attempts</i> .

Crank Disconnect



Crank Disconnect

Generator Frequency 21.0 Hz

Engine Speed 600 RPM


Oil Pressure 2.00 Bar

Delay 2.0s

Parameter	Description
Generator Frequency	The DSE module disengages the starter motor when the generator frequency rises above the configured level.
Engine Speed	The DSE module disengages the starter motor when the engine speed rises above the configured level.
Oil Pressure	The DSE module disengages the starter motor when the engine oil pressure rises above the configured level for longer than the configured <i>Delay</i> .


2.10.9 SPEED SETTINGS

Under Speed Shutdown



Parameter	Description
Under Speed Alarm	<input type="checkbox"/> = <i>Under Speed</i> alarm is disabled <input checked="" type="checkbox"/> = Under Speed gives an alarm in the event of the engine speed falling below the configured <i>Under Speed Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Underspeed Alarm Trip</i> value is adjustable to suit user requirements.

Over Speed Shutdown



Parameter	Description
Over Speed Alarm	Over Speed gives a <i>Shutdown</i> alarm in the event of the engine speed rising above the configured <i>Over Speed Alarm Trip</i> value for longer than the <i>Generator Transient Delay</i> . The <i>Over Speed Alarm Trip</i> value is adjustable to suit user requirements.

2.10.10 PLANT BATTERY

Voltage Alarms

Voltage Alarms

Under Voltage ☒

Pre-Alarm V DC

Return V DC

Delay

Over Voltage ☒

Return V DC

Pre-Alarm V DC

Delay

Parameter	Description
Plant Battery Under Voltage IEEE 37.2 -27 DC Undervoltage Relay	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the battery voltage drops below the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage rises above the configured <i>Return</i> level, the alarm is deactivated.
Plant Battery Over Voltage IEEE 37.2 -59 DC Overvoltage Relay	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the battery voltage rises above the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage drops below the configured <i>Return</i> level, the alarm is deactivated.

Charge Alternator Alarms

Charge Alternator Alarm

Shutdown ☒

Trip V DC

Delay

Warning ☒

Trip V DC

Delay

Parameter	Description
Charge Alternator Alarm	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.
Charge Alternator Pre-Alarm	<input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = The alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.

Start on Low Battery

Start On Low Battery

Enable ☒

Threshold

18.0 V DC

Engine Run Duration

1h


Start Delay

5s

Alarm	Description
Start on Low Battery	<p><input type="checkbox"/> = <i>Start on Low Battery</i> is disabled.</p> <p><input checked="" type="checkbox"/> = Select to enable autostart upon the battery voltage falling below the <i>Threshold</i> level for the duration of the <i>Start Delay</i> timer. The engine starts and run for the specified <i>Engine Run Duration</i>. This occurs only if the module is in AUTO mode</p>


2.11 SCHEDULER

The *Scheduler* page is subdivided into smaller sections. Select the required section with the mouse.




2.11.1 SCHEDULER OPTIONS

Exercise Scheduler



Parameter	Description
Scheduler Edit From Fascia	<input type="checkbox"/> = Scheduled is configurable only using the DSE Configuration Suite software <input checked="" type="checkbox"/> = Scheduled is configurable through the module front panel
Scheduler Enable From Fascia	<input type="checkbox"/> = Scheduled is enabled or disabled only using the DSE Configuration Suite software <input checked="" type="checkbox"/> = Scheduler is possible to enable and disable through the module front panel
Enabled	<input type="checkbox"/> = Scheduled runs are disabled <input checked="" type="checkbox"/> = Enables the Scheduler

Location



Parameter	Description
Latitude	Set the latitude at the site location to enable correct calculation of sunrise and sunset times.
Longitude	Set the longitude at the site location to enable correct calculation of sunrise and sunset times.
Timezone	Set the timezone at the site location to enable correct calculation of sunrise and sunset times.
Daylight Savings Offset	Set the daylight savings time offset at the site location to enable correct calculation of sunrise and sunset times.

Start and Stop Offsets

Start and Stop Offsets

Sunset Start Offset

0h 0m

Sunrise Stop Offset

0h 0m

Parameter	Description
Sunset Start Offset	Add an offset, of up to two hours difference from the calculated sunset time, for commencing the scheduled run.
Sunrise Stop Offset	Add an offset, of up to two hours difference from the calculated sunrise time, for stopping the scheduled run.

2.11.2 BANK 1 / BANK 2

Bank 1

Schedule Period: Weekly

Week	Day	Run Mode	Auto	Start Time	Duration	
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear
	Monday	Off Load	<input type="checkbox"/>	00:00	00:00	Clear

Parameter	Description
Schedule Period	Determines the repeat interval for the scheduled run. Options available are: Weekly, Monthly, Daily
Week	Specifies the week of the month, on which the scheduled run takes place
Day	Specifies the day of week, on which the scheduled run takes place
Run Mode	Determines the loading state mode of the generator when running on schedule Lights Only: The module powers the lights but does not start the generator. Off Load: The module runs the generator on schedule with the load switch open On Load: The module runs the generator on schedule and closes the load switch
Auto	<input type="checkbox"/> = The module follows the Start Time and Duration for the scheduled run. <input checked="" type="checkbox"/> = The module follows the sunrise / sunset times for the scheduled run.
Start Time	Determines at what time of day the scheduled run starts
Duration	Determines the time duration in hours for the scheduled run
Clear	Resets the values for the Day, Start Time and Duration to defaults

2.12 MAINTENANCE ALARM

Maintenance Alarm Oil, Air and Fuel

Maintenance Alarm Oil


Enable ☒

Action Warning

Engine Run Hours 10 hrs

There are three ways to reset the maintenance alarm:

- 1) Activate a digital input configured to "Maintenance Reset Alarm".
- 2) Use the SCADA | Maintenance | Maintenance Alarm section of this PC Software.
- 3) Through the Front Panel Editor of the module

Function	Description
Enable	<input type="checkbox"/> = The maintenance alarm is disabled. <input checked="" type="checkbox"/> = The maintenance alarm is activated with the configured <i>Action</i> when the engine hours increase more than the <i>Engine Run Hours</i>
Action	<div>  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Shutdown Warning
Engine Run Hours	The value the engine hours must increase by to trigger the maintenance alarm.

2.13 ALTERNATIVE CONFIGURATION

An Alternative Configuration is provided to allow the system designer to cater for different AC requirements utilising the same generator system. Typically this feature is used by Rental Set Manufacturers where the set is capable of being operated at (for instance) 120 V 50 Hz and 240V 50 Hz using a selector switch.


The Alternative Configuration is selected using either:

- Configuration Suite Software (Selection for 'Default Configuration')
- Module Front Panel Editor
- Via external signal to the module input configured to "Alternative Configuration" select.




2.13.1 CONFIGURATION OPTIONS

Enable Configuration



Parameter	Description
Enable Configuration	<input type="checkbox"/> = <i>Alternative Configuration</i> is disabled. <input checked="" type="checkbox"/> = <i>Alternative Configuration</i> is enabled. The configuration is enabled by changing the <i>Default Configuration</i> , activating a digital input or through the module's <i>Front Panel Editor</i> .


Configuration




Parameter	Description
Default Configuration	Select the 'default' configuration that is used when there is no instruction to use an 'alternative configuration'.

2.13.2 ALTERNATIVE CONFIGURATIONS EDITOR

The Alternative Configurations Editor allows for editing of the parameters that are to be changed when an Alternative Configuration is selected.



Alternative configuration options contain a subset of the main configuration. The adjustable parameters are not discussed here as they are identical to the main configuration options :




Configuration menus for the *Alternative Configuration*. For information about the configuration items within this section, refer to their description in the 'main' configuration.

3 SCADA

SCADA stands for **S**upervisory **C**ontrol **A**nd **D**ata **A**cquisition and is provided both as a service tool and also as a means of monitoring / controlling the generator set.

As a service tool, the SCADA pages are to check the operation of the controller's inputs and outputs as well as checking the generators operating parameters.




The SCADA page is subdivided into smaller sections. Select the required section with the mouse.




3.1 MIMIC

This screen provides a mimic of the control module and allows the operator to change the control mode of the module.




3.2 DIGITAL INPUTS

This section displays the status of the module's digital inputs and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Digital Inputs* elsewhere within this document.



3.3 DIGITAL OUTPUTS

This section displays the status of the module's digital outputs and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Digital Outputs* elsewhere within this document.




3.4 GENERATOR

This section displays the module's measurement of the *Generator* frequency, voltage and current supply.



3.5 MAINS SUPPLY

This section displays the module's measurement of the *Mains* frequency, voltage and current supply.

Mains Supply		
Mains Supply Active 		
Frequency		
Phase To Neutral Voltages		
L1 - N	L2 - N	L3 - N
Phase To Phase Voltages		
L1 - L2	L2 - L3	L3 - L1
Current		
L1	L2	L3

3.6 POWER

This section displays the module's measurement of the *Generator* or *Mains* power output.

Watts				
L1		L2		Total
33.0 kW		34.0 kW		100.0 kW

VA				
L1		L2		Total
41.0 kVA		42.0 kVA		125.0 kVA

VAr				
L1		L2		Total
24.0 kVAr		24.0 kVAr		72.0 kVAr

Power Factor				
L1		L2		Average
Lag	0.80	Lag	0.80	Lag 0.79

Accumulated Power			
kWh		kVAh	kVArh
15.5 kWh		19.2 kVAh	10.7 kVArh

3.7 ENGINE

This section displays the measurement of the *Engine* parameters. These measurements come from either the module's inputs or from the engine ECU/ECM. For further details on how to configure these items, refer to section entitled *Application* elsewhere within this document.

Coolant Temperature 59 °C, 138 °F	Plant Battery 24.1 v DC
Oil Pressure 5.03Bar, 73 PSI, 503 KPa	Charge Altenator 22.3 v DC
Speed 1497 RPM	Hours Run 00:12
Fuel Level 52 %	Number of Starts 3
Fuel Capacity 260	Fuel Unit Litres

3.8 FLEXIBLE SENSOR


This section displays the status and instrumentation measured by the module's analogue inputs and the functions they are configured for. For further details on how to configure these items, refer to section entitled *Fuel Level* elsewhere within this document.

Flexible Sensor C
Not Used

3.9 ALARMS

This section displays the alarms that are currently active on the module. For information in regards to alarm descriptions, refer to DSE publication: **057-221 DSEL401 MKII Operator Manual** found DSE's the DSE website: www.deepseaelectronics.com.

For information in regards to alarm severity, refer to section entitled *Alarm Types* elsewhere within this document.




The image shows a SCADA alarm display interface with a light blue background and rounded rectangular panels. It is organized into four main sections:

- Shutdown Alarms:** Located in the top-left, containing a list of three active alarms: "Emergency Stop", "Oil Pressure Sensor Open Circuit", and "Temperature Sensor Open Circuit".
- Warning Alarms:** Located in the top-right, represented by a large, empty rectangular box.
- Electrical Trip Alarms:** Located in the middle-left, represented by an empty rectangular box.
- Engine Alarms:** Located at the bottom, represented by a wide, empty rectangular box.

3.10 STATUS

This section displays the status information about the module.

Supervisor State Running On Load	Software Version 1.0
Engine/Generator State Running	Module ID 218DDA17D
Load Switching State Closed To Generator	Mode 
Heater Fitted	

3.11 EVENT LOG

This section displays the events which are recorded with the module's event log along with the time, date and engine hours in which they occurred. For further details on how what events are recorded, refer to section entitled *Event Log* elsewhere within this document.

For information in regards to alarm descriptions, refer to DSE publication: **057-221 DSEL401 MKII Operator Manual** found on DSE's website: www.deepseaelectronics.com.

#	Date	Time	Hours Run	Event	Details
1	02/10/2008	11:41:20	0:12	Shutdown	Oil Pressure Sensor Open Circuit
2	02/10/2008	11:41:19	0:12	Mains	Mains fail
3	02/10/2008	11:41:18	0:12	Restart	Power Up
4	28/09/2008	08:24:43	0:12	Shutdown	Oil Pressure Sensor Open Circuit
5	28/09/2008	08:24:42	0:12	Mains	Mains fail
6	28/09/2008	08:24:40	0:12	Restart	Power Up
7	27/09/2008	07:48:17	0:12	Shutdown	Oil Pressure Sensor Open Circuit
8	27/09/2008	07:48:16	0:12	Mains	Mains fail
9	27/09/2008	07:48:14	0:12	Restart	Power Up
10	27/09/2008	07:31:00	0:12	Shutdown	Oil Pressure Sensor Open Circuit
11	27/09/2008	07:30:59	0:12	Mains	Mains fail
12	27/09/2008	07:30:57	0:12	Restart	Power Up
13	26/09/2008	07:48:19	0:12	Shutdown	Oil Pressure Sensor Open Circuit
14	26/09/2008	07:48:18	0:12	Mains	Mains fail
15	26/09/2008	07:48:17	0:12	Restart	Power Up
16	26/09/2008	07:45:58	0:12	Restart	Power Up
17	26/09/2008	06:54:11	0:12	Shutdown	Oil Pressure Sensor Open Circuit
18	26/09/2008	06:54:10	0:12	Mains	Mains fail
19	26/09/2008	06:54:09	0:12	Restart	Power Up
20	25/09/2008	08:56:38	0:12	Shutdown	Oil Pressure Sensor Open Circuit
21	25/09/2008	08:56:37	0:12	Mains	Mains fail
22	25/09/2008	08:56:35	0:12	Restart	Power Up
23	25/09/2008	08:52:50	0:12	Mains	Mains fail
24	25/09/2008	08:52:48	0:12	Restart	Power Up
25	25/09/2008	06:55:04	0:12	Shutdown	Oil Pressure Sensor Open Circuit
26	25/09/2008	06:55:03	0:12	Mains	Mains fail

Export to Excel
Export to CSV
Export to PDF
Print event log


Click to save the log to an Excel or csv file for use in an external spreadsheet program.

Click to save the log to a pdf (Adobe Acrobat)

Click to print the log


3.12 MAINTENANCE

The *Maintenance* section is subdivided into smaller sections. Select the required section with the mouse.



3.12.1 MAINTENANCE ALARM RESET

This section allows the module's three maintenance alarms to be reset and when the alarm is due to activate.



3.12.2 HOURS RUN AND NUMBER OF STARTS

This section allows the Hours Run and Number of Starts to be customised on the controller. Typically, this is used when fitting a new controller to an older engine so that the controller display matches the amount of work previously done by the system.

The screenshot shows two sections: 'Hours Run' and 'Number Of Starts'. In the 'Hours Run' section, the value '1848:39' is displayed, with a callout box indicating that users can type the value or use up/down arrows to change it. Below this, the 'Number Of Starts' section shows the value '59', also with a callout box explaining the input methods.

3.12.3 DATE AND TIME

This section allows the date and time to be adjusted on the controller.

The screenshot displays four sections: 'Module Date', 'Module Time', 'Set Date And Time', and 'Set To PC Time'.

- 'Module Date' shows '05/04/2019' with a callout: 'Display of the module's current date and time'.
- 'Module Time' shows '12:38:16'.
- 'Set Date And Time' contains input fields for 'Date' (05/04/2019) and 'Time' (12:38:12), both with callouts: 'Type the new date / time or click the up and down arrows to change the settings'. Below these fields is a 'Set' button with a callout: 'Click Set to adjust the module to the selected date/time.'.
- 'Set To PC Time' shows the current 'Date' as '05/04/2019' and 'Time' as '13:38:00', with a 'Set To PC Time' button and a callout: 'Click Set to adjust the module to the date/time that the PC is set to.'.

3.12.4 ACCUMULATED INSTRUMENTATION

This section allows the generators accumulated instrumentation to be adjusted on the controller.

The screenshot displays the 'Accumulated Instrumentation' interface. It consists of four main sections: kWh, kVAh, kVArh, and a Reset section. Each section shows a current value and a control interface. Callouts provide instructions for each section:

- kWh:** Shows a current value of 55.3 kWh. A callout points to the value, stating: "Display of the module's current value for the parameter."
- kVAh:** Shows a current value of 66.1 kVAh. A callout points to the up and down arrows, stating: "Type the new value or click the up and down arrows to change the settings."
- kVArh:** Shows a current value of 9.0 kVArh. A callout points to the 'Set' button, stating: "Click Set to adjust the module to the selected value."
- Reset:** Contains a button labeled "Reset all values to zero". A callout points to this button, stating: "Click to reset all the accumulated instrumentation counters to zero."

3.12.5 DPF REGENERATION

This section allows settings within the engine's ECU to be altered when supported.

The screenshot displays the 'DPF Regeneration' interface. It contains two main controls:

- DPF Auto Regen Inhibit:** A checkbox that is currently unchecked.
- DPF Force Regeneration:** A button. A callout points to this button, stating: "Click to start the DPF Regeneration Manually"

Parameter	Description
DPF Auto Regen Inhibit	<input type="checkbox"/> = The ECU's DPF Auto Regeneration happens automatically. <input checked="" type="checkbox"/> = The ECU's DPF Auto Regeneration is inhibited from activating.

3.12.6 MODULE PIN

⚠ CAUTION!: If the module PIN is lost or forgotten, it is no longer possible to access or make changes to the module!

This section allows the user to configure a PIN (Personal Identification Number) within the module. This PIN must be entered to access the modules *Main Front Panel Configuration Editor* or, when writing a configuration / changing a value in SCADA using the DSE Configuration Suite PC Software.


The screenshot shows a software window titled "Module Access Password". Inside, there are two rows of four spinners each. The first row is labeled "Password" and the second row is labeled "Confirmation". Each spinner currently displays the number "0". Below these rows, there is a warning message: "Warning - care should be taken when adjusting these controls. If the password is lost or forgotten, it will not be possible to access the module." At the bottom of the window is a button labeled "Set PIN".

Enter the desired PIN and confirmation

Click to set the PIN within the module.

3.12.7 LCD CONTRAST

This section allows the user to adjust the module's display contrast. This is useful when the contrast is set to a level where the display is no longer visible and therefore cannot be configured through the Front Panel Editor.



4 ALARM TYPES

The protection included with the DSE control modules provides increasing levels of notification, depending upon the severity of the situation:

Alarm type	Description
Warning	Audible alarm and common alarm signal is generated. The set continues to run. <i>Warning alarms</i> are used to draw the operator's attention to a minor issue or to a problem that may escalate to an Electrical Trip or Shutdown Alarm if left untreated.
Electrical Trip	Audible alarm and common alarm signal is generated. The set is taken off load and the cooling timer begins, after which the set is stopped. <i>Electrical Trip alarms</i> are series issues that require the set to be taken off load. As the name implies, this is often electrical faults that occur 'after' the load breaker. The set is allowed to cool before stopping.
Shutdown	Audible alarm and common alarm signal is generated. The set is taken off load and immediately stopped. <i>Shutdown alarms</i> are serious issues that demand immediate stopping of the generator. For instance Emergency Stop or Overspeed alarms require immediate shutdown.

5 ALARM ARMING

The protections on the DSE module are active during their configured *Alarm Arming* setting. The table below shows the timing segment for the different *Alarm Arming* options with regards to the generator status.

Timing Segment	Stopped	Start Delay	ECU Wake Up Delay	Preheat	Cranking	Safety on Delay	Smoke Limiting	Smoke Limiting Off	Warming Up	Gen Available	Gen On Load	Cooling	Cooling in Idle
Never													
Always													
When Stationary													
From Starting													
Overfrequency / Overspeed Overshoot													
From Safety On													

5.1 NEVER

The protection is never active on the controller. This is used to disable the protection.

5.2 ALWAYS

The protection is always active on the controller. This is used to constantly monitor statuses such as a fuel level switch irrespective of the engine running state.

5.3 WHEN STATIONARY

The protection is active from the moment the engine stops until the beginning of engine cranking.

5.4 FROM STARTING

The protection is active from the beginning of engine cranking, until the engine stops.

5.5 OVERSHOOT

Active during the *Safety Delay* timer, this allows for a temporary raise of the overspeed/overfrequency trip points during start-up.

Protection Level	Over Frequency Trip Level	Over Speed Trip Level
Immediate Shutdown	Over Frequency + Overshoot %	Over Speed + Overshoot %
Delayed Shutdown (Overspeed Overshoot Delay)	Over Frequency	Over Speed

Example

57 Hz *Over Frequency* setting, 10% *Overspeed Overshoot*

During *Safety Delay* a generator frequency above $(57 \text{ Hz} \times 1.1) = 62.7 \text{ Hz}$ results in an immediate shutdown without delay.

After *Safety delay*, a generator frequency above 57 Hz for the period of the *Generator Transient Delay* results in a shutdown

5.6 FROM SAFETY ON

The protection is active when the set is running at nominal speed, until the engine stops.

Page is Left Intentionally Blank